



**Document Identifier: DSP2053**

**Date: 2026-04-02**

**Version: 2026.1**

# Redfish Property Guide

**Supersedes: 2025.4**

**Document Class: Informational**

**Document Status: Published**

**Document Language: en-US**

**Copyright Notice**

Copyright © 2019-2026 DMTF. All rights reserved.

DMTF is a not-for-profit association of industry members dedicated to promoting enterprise and systems management and interoperability. Members and non-members may reproduce DMTF specifications and documents, provided that correct attribution is given. As DMTF specifications may be revised from time to time, the particular version and release date should always be noted.

Implementation of certain elements of this standard or proposed standard may be subject to third party patent rights, including provisional patent rights (herein "patent rights"). DMTF makes no representations to users of the standard as to the existence of such rights, and is not responsible to recognize, disclose, or identify any or all such third party patent right, owners or claimants, nor for any incomplete or inaccurate identification or disclosure of such rights, owners or claimants. DMTF shall have no liability to any party, in any manner or circumstance, under any legal theory whatsoever, for failure to recognize, disclose, or identify any such third party patent rights, or for such party's reliance on the standard or incorporation thereof in its product, protocols or testing procedures. DMTF shall have no liability to any party implementing such standard, whether such implementation is foreseeable or not, nor to any patent owner or claimant, and shall have no liability or responsibility for costs or losses incurred if a standard is withdrawn or modified after publication, and shall be indemnified and held harmless by any party implementing the standard from any and all claims of infringement by a patent owner for such implementations.

For information about patents held by third-parties which have notified DMTF that, in their opinion, such patent may relate to or impact implementations of DMTF standards, visit <http://www.dmtf.org/about/policies/disclosures.php>.

This document's normative language is English. Translation into other languages is permitted.

CONTENTS

- 1 Overview ..... 4
  - 1.1 Who should read this document? ..... 4
  - 1.2 How can I provide feedback? ..... 4
  - 1.3 Where can I find more information? ..... 4
  - 1.4 Related documents ..... 5
- 2 Using this guide ..... 7
- 3 Reference guide. .... 8
- 4 Redfish documentation generator ..... 324
- 5 ANNEX A (informative) Change log. .... 325

# 1 Overview

---

The Redfish standard comprises a set of specifications maintained by the Redfish Forum, a working group within DMTF. The standard defines a protocol that uses RESTful interfaces to provide access to data and operations associated with the management of systems and networks. One of the strengths of the Redfish protocol is that it works with a wide range of servers: from stand-alone servers to rack-mount and bladed environments to large-scale data centers and cloud environments.

The Redfish standard addresses several key issues for infrastructures that require scalability. Large infrastructures often consist of many simple servers of different makes and types. This hyper-scale usage model requires a new approach to systems management. The Redfish protocol addresses these needs by providing a standard protocol based on out-of-band systems management.

With these goals in mind, the Redfish protocol was designed as an open-industry standard to meet scalability requirements in multi-vendor deployments. It easily integrates with commonly used tools, using RESTful interfaces to perform operations and using JSON for data payloads.

## 1.1 Who should read this document?

---

This document is intended primarily as a reference for schema authors to locate existing property definitions within the Redfish schema. End users and other consumers of Redfish data may also use this guide to look up property definitions without regard to their location in the schema.

## 1.2 How can I provide feedback?

---

Feedback on all Redfish specifications and documents is encouraged. Feedback can be directed to DMTF and the Redfish Forum by the following means:

- **Redfish User Forum:** <https://redfishforum.com> - User forum monitored by DMTF Redfish Forum personnel to answer questions about any Redfish-related topics.
- **DMTF Feedback Portal:** <https://www.dmtf.org/standards/feedback> - Formal submission portal for enhancements or proposals to DMTF and the Redfish Forum.

## 1.3 Where can I find more information?

---

The following web sites provide more information about the Redfish standard:

- **Redfish Developer Hub**

Resources for developers who use Redfish to build applications. Contains an interactive schema explorer, hosted schema, and other links.

- **Redfish Specification Forum**

DMTF Redfish-monitored user forum. Answers questions about Redfish-related topics.

- **DMTF GitHub repositories**

Open source tools and libraries for working with Redfish.

- **Redfish standards**

Schemas, specifications, mockups, white papers, FAQ, educational material, and more.

- **DMTF Redfish Forum**

Working group that maintains the Redfish standard. Site lists member companies, future work and schedules, charter, and information about joining.

## 1.4 Related documents

---

The following documents are part of the Redfish development effort. They can be accessed or downloaded from DMTF's Redfish Standards web site: <https://www.dmtf.org/standards/redfish>

- **DSP0218** - Platform Level Data Model (PLDM) for Redfish Device Enablement Specification - Binary-encoded JSON (BEJ) and dictionary-based mapping of Redfish schemas and properties into PLDM messages.
- **DSP0266** - Redfish Specification - Main Redfish Specification.
- **DSP0268** - Redfish Data Model Specification - Normative descriptions and additional text for every schema defined in DSP8010 and example payloads for every resource.
- **DSP0270** - Redfish Host Interface Specification - "In-band" or "OS-based" Redfish host interface.
- **DSP0272** - Redfish Interoperability Profiles Specification - Structure and JSON document that is used to define and publish an interoperability profile that checks an implementation's conformance to a defined minimum set of functionality.
- **DSP2043** - Redfish Mockups Bundle - Set of mockups that can be used as sample output from `GET` responses from a Redfish service. Informative in nature, it was used to develop the schema. A person can set up an NGINX or similar server and configure it to output JSON format and then use this directory for demonstration purposes.
- **DSP2044** - Redfish White Paper - Non-normative document helping those new to Redfish understand how to interact with the Redfish service and understand common functions and tasks.
- **DSP2046** - Redfish Resource and Schema Guide - Informative documentation regarding common Redfish resource properties and a listing of properties that can be found in each of the Redfish resources.
- **DSP2053** - Redfish Property Guide - Informative documentation providing an index to individual property definitions across all Redfish schema.
- **DSP2065** - Redfish Message Registry Guide - Informative documentation providing details regarding the

messages defined in Redfish standard message registries.

- [DSP8010](#) - Redfish Schema - Redfish schema definitions. These files are normative in nature and are normatively referenced by the *Redfish Specification*. The three schema formats are CSDL (OData Common Schema Definition Language format, which is in XML), JSON Schema, and OpenAPI schema. These schema definitions should be functionally equivalent, thus specifying the schema in three different languages.
- [DSP8011](#) - Redfish Standard Registries - Redfish registry definitions. This bundle of Redfish registries includes message registries used for Redfish-defined messages including events and privilege maps.
- [DSP8013](#) - Redfish Interoperability Profiles Bundle - Bundle of published Redfish interoperability profile documents and supporting schema and sample documents used for creating profiles.

## 2 Using this guide

---

Every Redfish response consists of a JSON payload containing properties that are strictly defined by a schema for that resource. The schema that defines a resource can be determined from the value of the `@odata.type` property returned in every Redfish response. This guide details the definitions for every Redfish standard property defined in DMTF-published Redfish schemas.

The property-level details include:

Column	Purpose
Property Name	The name of the JSON property as it appears, case sensitive, in the JSON payload.
Defined in Schemas	The names of the Redfish schemas where this property is defined, and therefore in which resources it may appear. For properties that appear within embedded JSON objects, the object name appears in parentheses.
Type	The JSON data types for the property, which can include boolean, number, string, or object. String types that use defined enumerations state <code>(enum)</code> . Number types state units, where used.
Description	The description of the property, as copied directly from the schema <code>Description</code> definition, or, for properties that appear in multiple schemas, a general description of its usage in any of the listed schemas.

## 3 Reference guide

To produce this guide, DMTF's [Redfish Documentation Generator](#) merges DMTF's Redfish Schema Bundle (DSP8010) contents with supplemental text.

Property Name	Defined In Schema(s)	Type	Description
<b>AbsoluteHumidity</b>	EnvironmentMetrics, PowerDistributionMetrics	object	Absolute humidity (g/m <sup>3</sup> ).
<b>AbsoluteSessionTimeout</b>	SessionService	integer (seconds)	The maximum number of seconds that a session is open before the service closes the session regardless of activity.
<b>AbsoluteSessionTimeoutEnabled</b>	SessionService	boolean	An indication of whether an absolute session timeout is applied to sessions.
<b>AccelerationFunction</b>	Processor (FPGA > ReconfigurationSlots)	object	The link to the acceleration function that the code programmed into a reconfiguration slot provides.
<b>AccelerationFunctions</b>	Processor	object	The link to the collection of acceleration functions associated with this processor.
<b>AccelerationFunctionType</b>	AccelerationFunction	string (enum)	The acceleration function type.
<b>AcceleratorID</b>	Processor (UALink)	integer	The UALink Accelerator ID of the processor.
<b>AccessCapabilities</b>	Connection (MemoryChunkInfo), Connection (MemoryRegionInfo), Connection (VolumeInfo)	array	Supported I/O access capabilities.
	Volume	array	Supported IO access capabilities.
	Connection (Actions > AddVolumeInfo (Action))	array	The supported I/O access capabilities to assign to the volume. Clients are required to provide either LUN , AccessCapabilities , or both.
<b>AccessKey</b>	Endpoint (ConnectedEntities > GenZ)	string	The Access Key for the entity.

Property Name	Defined In Schema(s)	Type	Description
	Connection (ConnectionKeys > GenZ)	string	The Access Key for this connection.
	AddressPool (GenZ)	string	The Access Key required for this address pool.
<b>AccessKeyViolations</b>	PortMetrics (GenZ)	integer	The total number of Access Key Violations detected.
<b>AccessMode</b>	ManagerNetworkProtocol (SNMP > CommunityStrings)	string (enum)	The access level of the SNMP community.
<b>AccessState</b>	StorageController (NVMeControllerProperties > ANACharacteristics)	string (enum)	Reported ANA access state.
	Connection (MemoryChunkInfo), Connection (MemoryRegionInfo), Connection (VolumeInfo)	string (enum)	The access state for this connection.
	EndpointGroup	string (enum)	The access state for this group.
<b>AccountExpiration</b>	ManagerAccount	string	Indicates the date and time when this account expires. If <code>null</code> , the account never expires.
<b>AccountLockoutCounterResetAfter</b>	AccountService	integer (seconds)	The period of time, in seconds, between the last failed login attempt and the reset of the lockout threshold counter. This value must be less than or equal to the <code>AccountLockoutDuration</code> value. A reset sets the counter to <code>0</code> .
<b>AccountLockoutCounterResetEnabled</b>	AccountService	boolean	An indication of whether the threshold counter is reset after <code>AccountLockoutCounterResetAfter</code> expires. If <code>true</code> , it is reset. If <code>false</code> , only a successful login resets the threshold counter and if the user reaches the <code>AccountLockoutThreshold</code> limit, the account will be locked out indefinitely and only an administrator-issued reset clears the threshold counter. If this property is absent, the default is <code>true</code> .

Property Name	Defined In Schema(s)	Type	Description
<b>AccountLockoutDuration</b>	AccountService	integer (seconds)	The period of time, in seconds, that an account is locked after the number of failed login attempts reaches the account lockout threshold, within the period between the last failed login attempt and the reset of the lockout threshold counter. If this value is <code>0</code> , no lockout will occur. If the <code>AccountLockoutCounterResetEnabled</code> value is <code>false</code> , this property is ignored.
<b>AccountLockoutThreshold</b>	AccountService	integer	The number of allowed failed login attempts before a user account is locked for a specified duration. If <code>0</code> , the account is never locked.
<b>AccountProviderType</b>	AccountService (ActiveDirectory), AccountService (LDAP), AccountService (OAuth2), AccountService (TACACSPplus), ExternalAccountProvider	string (enum)	The type of external account provider to which this service connects.
<b>Accounts</b>	AccountService	object	The collection of manager accounts.
<b>AccountService</b>	ServiceRoot	object	The link to the account service.
<b>AccountTypes</b>	ManagerAccount	array	The list of services in the manager that the account is allowed to access.
<b>Accuracy</b>	MetricDefinition	number	The estimated percent error of measured versus actual values.
	Control, Sensor	number (%)	The estimated percent error of measured versus actual values.
<b>ACME</b>	CertificateEnrollment	object	ACME (Automatic Certificate Management Environment) protocol specific configuration for automatic certificate enrollment.
<b>Actions</b>	<i>various</i> (AccelerationFunction, AccountService ... )	object	The available actions for this resource.
<b>Activate (Action)</b>	UpdateService (Actions)	object	This action activates specified software inventory instance.

Property Name	Defined In Schema(s)	Type	Description
	SoftwareInventory (Actions)	object	This action activates this software inventory instance.
<b>Activation</b>	<i>various</i> (Sensor (Thresholds > LowerCaution), Sensor (Thresholds > LowerCautionUser) ... )	string (enum)	The direction of crossing that activates this threshold.
<b>Active</b>	SoftwareInventory	boolean	This image is active on one or more devices.
<b>ActiveCoreCount</b>	OperatingConfig (TurboProfile)	integer	The number of active cores to be configured with the specified maximum clock speed.
<b>ActiveDirectory</b>	AccountService	object	The first Active Directory external account provider that this account service supports.
<b>ActiveLinkTechnology</b>	NetworkPort	string (enum)	Network port active link technology.
<b>ActiveMainsId</b>	PowerDistribution (TransferConfiguration)	string	The mains circuit that is switched on and qualified to supply power to the output circuit.
<b>ActivePersonalities</b>	Drive (NVMe), Storage (NVMeSubsystemProperties)	array	The active personality settings of the NVMe subsystem.
<b>ActivePool</b>	CompositionService	object	The link to the collection of resource blocks within the active pool. Resource blocks in the active pool are contributing to at least one composed resource as a result of a composition request.
<b>ActiveSoftwareImage</b>	NetworkAdapter (Controllers > Links)	object	The link to the software inventory resource that represents the active firmware image for this controller.
	Manager (Links)	object	The link to the software inventory resource that represents the active firmware image for this manager.
	TrustedComponent (Links)	object	The link to the software inventory resource that represents the active firmware image for this trusted component.

Property Name	Defined In Schema(s)	Type	Description
	Bios (Links)	object	The link to the software inventory that represents the active BIOS firmware image.
	Drive (Links)	object	The link to the software inventory that represents the active drive firmware image.
<b>ActiveTargets</b>	SoftwareInventory (Links)	array	An array of devices where this software image is currently running.
<b>ActiveWidth</b>	Port	integer	The number of active lanes for this interface.
<b>Add</b>	Manager (Actions > ModifyRedundancySet (Action))	array	An array of managers to add to the redundancy set.
<b>AddCapacityPoliciesSupported</b>	PCIeDevice (CXLDevice > DynamicCapacity)	array	The set of selection policies supported by the CXL device when dynamic capacity is added.
<b>AddElements (Action)</b>	Aggregate (Actions)	object	This action is used to add one or more resources to the aggregate.
<b>AddEndpoint (Action)</b>	Zone (Actions)	object	This action adds an endpoint to a zone.
<b>AdditionalCommonNames</b>	Certificate (Issuer), Certificate (Subject)	array	Additional common names of the entity.
<b>AdditionalData</b>	TelemetryData	string	A Base64-encoded string of the associated telemetry data.
<b>AdditionalDataSizeBytes</b>	TelemetryData	integer	The size of the data available at location specified by <code>AdditionalDataURI</code> .
	Event (Events)	integer (bytes)	The size of the additional data for this event.
	LogEntry	integer (bytes)	The size of the additional data for this log entry.
<b>AdditionalDataURI</b>	Event (Events)	string	The URI at which to access the additional data for the event, such as diagnostic data, image captures, or other files.

Property Name	Defined In Schema(s)	Type	Description
	LogEntry	string	The URI at which to access the additional data for this log entry, such as diagnostic data, image captures, or other files.
	TelemetryData	string	The URI at which to access the associated telemetry data.
	LogService (Actions > PushDiagnosticData (Action))	string	The URI of the diagnostic data to transfer to the URI specified by the <code>TargetURI</code> parameter.
<b>AdditionalExternalAccountProviders</b>	AccountService	object	The additional external account providers that this account service uses.
<b>AdditionalFirmwareVersions</b>	Manager	object	The additional firmware versions of the manager.
	Processor	object	The additional firmware versions of the processor.
<b>AdditionalManagementAddressesIPv4</b>	Port (Ethernet > LLDPTransmit)	array	Additional IPv4 management addresses advertised on this link.
	Port (Ethernet > LLDPReceive)	array	Additional IPv4 management addresses received from the remote partner across this link. <code>ManagementAddressIPv4</code> contains the first IPv4 address received.
<b>AdditionalManagementAddressesIPv6</b>	Port (Ethernet > LLDPTransmit)	array	Additional IPv6 management addresses advertised on this link.
	Port (Ethernet > LLDPReceive)	array	Additional IPv6 management addresses received from the remote partner across this link. <code>ManagementAddressIPv6</code> contains the first IPv6 address received.
<b>AdditionalOrganizationalUnits</b>	Certificate (Issuer), Certificate (Subject)	array	Additional organizational units of the entity.
<b>AdditionalProtocols</b>	NetworkDeviceFunction (Ethernet)	array	The protocols supported by the hardware or firmware on the device.
<b>AdditionalVersions</b>	SoftwareInventory	object	The additional versions of this software.
<b>AdditiveName</b>	CoolingLoop (Coolant)	string	The name of the additive.

Property Name	Defined In Schema(s)	Type	Description
<b>AdditivePercent</b>	CoolingLoop (Coolant)	number (%)	The percent additives contained in the coolant.
<b>AddResourceBlock (Action)</b>	ComputerSystem (Actions)	object	This action adds a resource block to a system.
<b>Address</b>	AddressPool (Ethernet > EBGp > BGPNeighbor), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor)	string	Border Gateway Protocol (BGP) neighbor address.
	ComputerSystem (KeyManagement > KMIPServers)	string	The KMIP server address.
<b>AddressParityError</b>	MemoryMetrics (HealthData > AlarmTrips)	boolean	An indication of whether an address parity error was detected that a retry could not correct.
<b>AddressPools</b>	Endpoint (Links)	array	An array of links to the address pools associated with this endpoint.
	Zone (Links)	array	An array of links to the address pools associated with this zone.
	Fabric	object	The collection of links to the address pools that this fabric contains.
<b>AddressRangeOffsetMiB</b>	MemoryChunks	integer (mebibytes)	Offset of the memory chunk in the address range in MiB.
<b>AddressRangeType</b>	MemoryChunks	string (enum)	Memory type of this memory chunk.
<b>AddVolumeInfo (Action)</b>	Connection (Actions)	object	This action adds a volume to the connection. Volumes are added to the <code>VolumeInfo</code> property.
<b>AdjustedMaxAllowableOperatingValue</b>	Thermal (Temperatures)	integer (Celsius)	Adjusted maximum allowable operating temperature for this equipment based on the current environmental conditions present.
	Sensor	number	The adjusted maximum allowable operating value for this equipment based on the environmental conditions.

Property Name	Defined In Schema(s)	Type	Description
<b>AdjustedMinAllowableOperatingValue</b>	Thermal (Temperatures)	integer (Celsius)	Adjusted minimum allowable operating temperature for this equipment based on the current environmental conditions present.
	Sensor	number	The adjusted minimum allowable operating value for this equipment based on the environmental conditions.
<b>AdvertiseInactiveRoutesEnabled</b>	AddressPool (Ethernet > EBG > BGPRoute), AddressPool (Ethernet > MultiProtocolEBG > BGPRoute), AddressPool (Ethernet > MultiProtocolIBG > BGPRoute)	boolean	Advertise inactive route status.
<b>AEAD</b>	SecurityPolicy (SPDM > Allowed > Algorithms), SecurityPolicy (SPDM > Denied > Algorithms)	array	The AEAD algorithms.
<b>AffiliatedInterfaces</b>	EthernetInterface (Links)	array	The links to the Ethernet interfaces that are affiliated with this interface, such as a VLAN or a team that uses this interface.
<b>Aggregates</b>	AggregationService	object	The link to the collection of aggregates associated with this service.
<b>AggregationEnabled</b>	NetworkAdapter (PortAggregation)	boolean	Indicates whether port aggregation is enabled.
<b>AggregationService</b>	ServiceRoot	object	The link to the aggregation service.
<b>AggregationSources</b>	ConnectionMethod (Links)	array	An array of links to the access points using this connection method.
	AggregationService	object	The link to the collection of aggregation sources associated with this service.
<b>AggregationType</b>	AggregationSource	string (enum)	The type of aggregation used towards the aggregation source.
<b>AirFlowCubicMetersPerMinute</b>	ThermalMetrics	object	The air flow through the chassis (m <sup>3</sup> /min).
<b>AlarmTrips</b>	MemoryMetrics (HealthData)	object	Alarm trip information about the memory.

Property Name	Defined In Schema(s)	Type	Description
<b>AlertCapabilities</b>	MemoryMetrics (CXL)	object	The conditions that would generate an alert to the CXL Fabric Manager or host.
<b>Algorithm</b>	Drive (Actions > SetPersonalityKey (Action)), Storage (Actions > SetPersonalityKey (Action))	string (enum)	The type of authentication algorithm for the key.
<b>Algorithms</b>	SecurityPolicy (SPDM > Allowed), SecurityPolicy (SPDM > Denied)	object	The SPDM algorithms.
	SecurityPolicy (TLS > Client > Allowed), SecurityPolicy (TLS > Client > Denied), SecurityPolicy (TLS > Server > Allowed), SecurityPolicy (TLS > Server > Denied)	object	The TLS algorithms.
<b>Alias</b>	BootOption	string (enum)	The alias of this boot source.
<b>AliasBootOrder</b>	ComputerSystem (Boot)	array	Ordered array of boot source aliases representing the persistent boot order associated with this computer system.
<b>AllocatedBandwidth</b>	CXLLogicalDevice (QoS)	integer (%)	The bandwidth allocated to this CXL logical device as a percentage.
<b>AllocatedCompletionQueues</b>	StorageController (NVMeControllerProperties)	integer	The number of I/O completion queues allocated to this NVMe I/O controller.
<b>AllocatedPools</b>	Volume	object	An array of references to StoragePools allocated from this Volume.
<b>AllocatedSubmissionQueues</b>	StorageController (NVMeControllerProperties)	integer	The number of I/O submission queues allocated to this NVMe I/O controller.
<b>AllocatedWatts</b>	PowerSubsystem (Allocation)	number (watts)	The total amount of power that has been allocated or budgeted to this subsystem.

Property Name	Defined In Schema(s)	Type	Description
<b>Allocation</b>	PowerSubsystem	object	Power allocation for this subsystem when it represents a subset of the power infrastructure for the chassis or its upstream chassis, such as a chassis containing multiple server blades.
<b>AllocationAlignmentMiB</b>	Memory	integer (mebibytes)	The boundary that memory regions are allocated on, measured in mebibytes (MiB).
<b>AllocationIncrementMiB</b>	Memory	integer (mebibytes)	The size of the smallest unit of allocation for a memory region in mebibytes (MiB).
<b>AllocationLength</b>	StorageController (Actions > SecurityReceive (Action))	integer	Allocated size for received data.
<b>AllocationPercent</b>	Port (FunctionMaxBandwidth)	integer (%)	The maximum bandwidth allocation percentage allocated to the corresponding network device function instance.
	Port (FunctionMinBandwidth)	integer (%)	The minimum bandwidth allocation percentage allocated to the corresponding network device function instance.
<b>AllowableMax</b>	<i>various</i> (AutomationInstrumentation (NodeControl), AutomationInstrumentation (PID) ... )	number	The maximum possible setting for this control.
<b>AllowableMin</b>	<i>various</i> (AutomationInstrumentation (NodeControl), AutomationInstrumentation (PID) ... )	number	The minimum possible setting for this control.
<b>AllowableNumbers</b>	ActionInfo (Parameters)	array	The allowable numeric values or duration values, inclusive ranges of values, and incremental step values for this parameter as applied to this action target.
	JobDocument (ParameterMetadata)	array	The allowable numeric values or duration values, inclusive ranges of values, and incremental step values for this parameter.

Property Name	Defined In Schema(s)	Type	Description
<b>AllowableNumericValues</b>	Control, Memory (OperatingSpeedRangeMHz), Processor (OperatingSpeedRangeMHz)	array	The supported values for the set point.
<b>AllowablePattern</b>	ActionInfo (Parameters)	string	The allowable pattern for this parameter as applied to this action target.
	JobDocument (ParameterMetadata)	string	The allowable pattern for this parameter.
<b>AllowablePhysicalPortsPerAggregation</b>	NetworkAdapter (PortAggregation)	array	The allowable number of physical ports per aggregation.
<b>AllowableStaging</b>	UpdateServiceCapabilities	array	The allowable URIs that a client can specify in the <code>Targets</code> parameter for update requests when requesting to stage an image on target devices.
<b>AllowableTargets</b>	UpdateServiceCapabilities	array	The allowable URIs that a client can specify in the <code>Targets</code> parameter for update requests.
<b>AllowableValueDescriptions</b>	ActionInfo (Parameters), JobDocument (ParameterMetadata)	array	Descriptions of allowable values for this parameter.
<b>AllowableValues</b>	ActionInfo (Parameters)	array	The allowable values for this parameter as applied to this action target.
	JobDocument (ParameterMetadata)	array	The allowable values for this parameter.
<b>AllowDeny</b>	NetworkDeviceFunction	object	The link to the collection of allow and deny permissions for packets leaving and arriving to this network device function.
<b>AllowDuplicateASEnabled</b>	AddressPool (Ethernet > EBGp), AddressPool (Ethernet > MultiProtocolEBGP)	boolean	Allow duplicate Autonomous System (AS) path.
<b>Allowed</b>	SecurityPolicy (SPDM)	object	The SPDM policy settings that are allowed, such as the allowable SPDM versions and algorithms.

Property Name	Defined In Schema(s)	Type	Description
	SecurityPolicy (TLS > Client), SecurityPolicy (TLS > Server)	object	The TLS policy settings that are allowed, such as the allowable TLS versions and algorithms.
<b>AllowedClients</b>	ManagerNetworkProtocol (Modbus)	array	Indicates the list of allowed clients for this Modbus TCP server interface.
<b>AllowedSpeedsMHz</b>	Memory	array (MHz)	Speeds supported by this memory device.
<b>AllowExtendedAlgorithms</b>	SecurityPolicy (SPDM)	boolean	An indication of whether SPDM extended algorithms are allowed.
<b>AllowFIPVLANDiscovery</b>	NetworkDeviceFunction (FibreChannel)	boolean	An indication of whether the FCoE Initialization Protocol (FIP) populates the FCoE VLAN ID.
<b>AllowOverprovisioning</b>	CompositionService	boolean	An indication of whether this service is allowed to overprovision a composition relative to the composition request.
<b>AllowOverrideASEnabled</b>	AddressPool (Ethernet > EBGp), AddressPool (Ethernet > MultiProtocolEBGP)	boolean	Option to override an Autonomous System (AS) number with the AS number of the sending peer.
<b>AllowOwnASEnabled</b>	AddressPool (Ethernet > EBGp > BGPNeighbor), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor)	boolean	Allow own Autonomous System (AS) status.
<b>AllowsBlockProvisioning</b>	MemoryDomain	boolean	An indication of whether this memory domain supports the provisioning of blocks of memory.
<b>AllowsMemoryChunkCreation</b>	MemoryDomain	boolean	An indication of whether this memory domain supports the creation of memory chunks.
<b>AllowsMirroring</b>	MemoryDomain	boolean	An indication of whether this memory domain supports the creation of memory chunks with mirroring enabled.

Property Name	Defined In Schema(s)	Type	Description
<b>AllowsSparing</b>	MemoryDomain	boolean	An indication of whether this memory domain supports the creation of memory chunks with sparing enabled.
<b>AllowType</b>	AllowDeny	string (enum)	Indicates the type of permission.
<b>AllowZoneAffinity</b>	CompositionService	boolean	An indication of whether a client can request that a specific resource zone fulfill a composition request.
<b>AlternateRoleId</b>	Role	string	An equivalent role to use when this role is restricted.
<b>AlternativeNames</b>	CertificateEnrollment (CSRParameters), CertificateService (Actions > GenerateCSR (Action))	array	The additional host names of the component to secure.
	Certificate (Issuer), Certificate (Subject)	array	The additional host names of the entity.
<b>ALUA</b>	Volume	object	ALUA properties for this volume.
<b>AlwaysCompareMEDEnabled</b>	AddressPool (Ethernet > EBGP), AddressPool (Ethernet > MultiProtocolEBGP)	boolean	Compare Multi Exit Discriminator (MED) status.
<b>Ambient</b>	ThermalMetrics (TemperatureSummaryCelsius)	object	The ambient temperature (in degree Celsius units) of this subsystem.
<b>AmbientMetrics</b>	Facility	object	The link to the ambient environment metrics for this facility.
<b>AmbientTemperatureCelsius</b>	EnvironmentMetrics, PowerDistributionMetrics	object	Ambient temperature (Celsius).
<b>ANACCharacteristics</b>	StorageController (NVMeControllerProperties)	array	The ANA characteristics and volume information.
<b>ANAGroupId</b>	Volume (ALUA)	number	The ANA group id for this volume.
<b>AnycastGatewayIPAddress</b>	AddressPool (Ethernet > BGPEvpn), AddressPool (Ethernet > IPv4)	string	The anycast gateway IPv4 address.
<b>AnycastGatewayMACAddress</b>	AddressPool (Ethernet > BGPEvpn), AddressPool (Ethernet > IPv4)	string	The anycast gateway MAC address.

Property Name	Defined In Schema(s)	Type	Description
<b>ApparentkVAh</b>	<i>various</i> (Circuit (EnergykWh), Circuit (PolyPhaseEnergykWh > Line1ToLine2) ... )	number (kV.A.h)	Apparent energy (kVAh).
<b>ApparentVA</b>	<i>various</i> (Circuit (PolyPhasePowerWatts > Line1ToLine2), Circuit (PolyPhasePowerWatts > Line1ToNeutral) ... )	number (V.A)	The product of voltage and current for an AC circuit, in volt-ampere units.
<b>AppendLimit</b>	MetricReportDefinition	integer	The maximum number of entries that can be appended to a metric report. When the metric report reaches its limit, its behavior is dictated by the <code>ReportUpdates</code> property.
<b>Applications</b>	OperatingSystem	object	The link to the collection of applications running under this operating system.
<b>AppliedOperatingConfig</b>	Processor	object	The link to the operating configuration that is applied to this processor.
<b>ApplyTime</b>	UpdateService (HttpPushUriOptions > HttpPushUriApplyTime)	string (enum)	The time when to apply the <code>HttpPushUri</code> -provided software update.
<b>ArchitectureId</b>	ManagerNetworkProtocol (SNMP > EngineId)	string	The architecture identifier.
<b>ArchiveFile</b>	MessageRegistryFile (Location)	string	If the service hosts the registry in an archive file, the name of the file within the archive.
	JsonSchemaFile (Location)	string	The name of the file in the archive, if the schema is hosted on the service in an archive file.
<b>ArchiveUri</b>	MessageRegistryFile (Location)	string	If the registry is hosted on the service in an archive file, the link to the archive file.
	JsonSchemaFile (Location)	string	The link to an archive file, if the schema is hosted on the service in an archive file.

Property Name	Defined In Schema(s)	Type	Description
<b>ARIFunctionNumber</b>	PCleFunction	string	The ARI (Alternative Routing-ID Interpretation) function number of this PCIe function.
<b>ARIModeEnabled</b>	PCleFunction	boolean	An indication of whether PCIe ARI (Alternative Routing-ID Interpretation) is enabled for this PCIe function.
<b>ARPProxyEnabled</b>	AddressPool (Ethernet > BGPEvpn)	boolean	Address Resolution Protocol (ARP) proxy status.
<b>ARPSuppressionEnabled</b>	AddressPool (Ethernet > BGPEvpn)	boolean	Address Resolution Protocol (ARP) suppression status.
<b>ARPSuppressionEnabled</b>	AddressPool (Ethernet > BGPEvpn)	boolean	Address Resolution Protocol (ARP) suppression status.
<b>ArraySizeMaximum</b>	ActionInfo (Parameters)	integer	The maximum number of array elements allowed for this parameter.
<b>ArraySizeMinimum</b>	ActionInfo (Parameters)	integer	The minimum number of array elements required for this parameter.
<b>ASICManufacturer</b>	FabricAdapter	string	The manufacturer name for the ASIC of this fabric adapter.
<b>ASICPartNumber</b>	FabricAdapter	string	The part number for the ASIC on this fabric adapter.
<b>ASICRevisionIdentifier</b>	FabricAdapter	string	The revision identifier for the ASIC on this fabric adapter.
<b>ASNumberRange</b>	AddressPool (Ethernet > EBGp), AddressPool (Ethernet > MultiProtocolEBGP), AddressPool (Ethernet > MultiProtocolIBGP)	object	Autonomous System (AS) number range.
<b>Assemblies</b>	Assembly	array	The assembly records.
<b>Assembly</b>	Processor	object	The link to an assembly associated with this processor.
	Battery	object	The link to the assembly associated with this battery.
	Cable	object	The link to the assembly associated with this cable.

Property Name	Defined In Schema(s)	Type	Description
	Chassis	object	The link to the assembly associated with this chassis.
	CoolingUnit	object	The link to the assembly associated with this cooling unit.
	Drive	object	The link to the assembly associated with this drive.
	Fan, Thermal (Fans)	object	The link to the assembly associated with this fan.
	Filter	object	The link to the assembly associated with this filter.
	Heater	object	The link to the assembly associated with this heater.
	PCleDevice	object	The link to the assembly associated with this PCIe device.
	PowerSupply	object	The link to the assembly associated with this power supply.
	Pump	object	The link to the assembly associated with this pump.
	Reservoir	object	The link to the assembly associated with this reservoir.
	Storage (StorageControllers), StorageController	object	The link to the assembly associated with this storage controller.
	NetworkAdapter	object	The link to the assembly resource associated with this adapter.
	Memory	object	The link to the assembly resource associated with this memory device.
	Power (PowerSupplies)	object	The link to the assembly resource associated with this power supply.
<b>AssetTag</b>	Cable	string	The user-assigned asset tag for this cable.
	Drive	string	The user-assigned asset tag for this drive.
	CoolingUnit, PowerDistribution, Pump	string	The user-assigned asset tag for this equipment.

Property Name	Defined In Schema(s)	Type	Description
	GraphicsController	string	The user-assigned asset tag for this graphics controller.
	PCleDevice	string	The user-assigned asset tag for this PCIe device.
	Storage (StorageControllers), StorageController	string	The user-assigned asset tag for this storage controller.
	Switch	string	The user-assigned asset tag for this switch.
	Chassis	string	The user-assigned asset tag of this chassis.
	ComputerSystem	string	The user-definable tag that can track this computer system for inventory or other client purposes.
<b>AssignablePhysicalNetworkPorts</b>	NetworkDeviceFunction	array	An array of physical ports or logical aggregated ports to which this network device function can be assigned.
<b>AssignablePhysicalPorts</b>	NetworkDeviceFunction	array	An array of physical ports to which this network device function can be assigned.
<b>AssignedPrivileges</b>	Role	array	The Redfish privileges for this role.
<b>AssignReplicaTarget (Action)</b>	Volume (Actions)	object	This action is used to establish a replication relationship by assigning an existing volume to serve as a target replica for an existing source volume.
<b>AssociatedControls</b>	Sensor (Links)	array	An array of links to the controls that can affect this sensor.
<b>AssociatedEndpoints</b>	Port (Links)	array	An array of links to the endpoints at the other end of the link.
<b>AssociatedFeaturesRegistry</b>	Volume (Operations)	object	A reference to the task associated with the operation if any.

Property Name	Defined In Schema(s)	Type	Description
<b>AssociatedMACAddresses</b>	Port (Ethernet)	array	An array of all configured MAC addresses associated with this network port. For example, this would include the programmed addresses for network device functions and the address for hardware port teaming.
<b>AssociatedNetworkAddresses</b>	NetworkPort	array	An array of configured MAC or WWN network addresses that are associated with this network port, including the programmed address of the lowest-numbered network device function, the configured but not active address, if applicable, the address for hardware port teaming, or other network addresses.
<b>AssociatedNodeGUIDs</b>	Port (InfiniBand)	array	An array of configured node GUIDs that are associated with this network port, including the programmed address of the lowest-numbered network device function, the configured but not active address, if applicable, the address for hardware port teaming, or other network addresses.
<b>AssociatedPhysicalContext</b>	SoftwareInventory	string (enum)	The area or device to which the software applies. Used to distinguish when different parts of a device have different software components.
<b>AssociatedPhysicalPort</b>	Port	integer	The index of the physical port from which this subport has been split.
<b>AssociatedPhysicalPorts</b>	Port (Links)	array	An array of links to the physical ports associated with this aggregated logical port.
<b>AssociatedPortGUIDs</b>	Port (InfiniBand)	array	An array of configured port GUIDs that are associated with this network port, including the programmed address of the lowest-numbered network device function, the configured but not active address, if applicable, the address for hardware port teaming, or other network addresses.

Property Name	Defined In Schema(s)	Type	Description
<b>AssociatedSensors</b>	Control	array	An array of links to the sensors associated with this control.
<b>AssociatedSystemGUIDs</b>	Port (InfiniBand)	array	An array of configured system GUIDs that are associated with this network port, including the programmed address of the lowest-numbered network device function, the configured but not active address, if applicable, the address for hardware port teaming, or other network addresses.
<b>AssociatedTask</b>	Drive (Operations)	object	The link to the task associated with the operation, if any.
<b>AssociatedWorldWideNames</b>	Port (FibreChannel)	array	An array of configured World Wide Names (WWN) that are associated with this network port, including the programmed address of the lowest-numbered network device function, the configured but not active address, if applicable, the address for hardware port teaming, or other network addresses.
<b>AttachedVolumes</b>	StorageController (Links)	array	An array of links to volumes that are attached to this controller instance.
<b>AttachNamespaces (Action)</b>	StorageController (Actions)	object	This action attaches referenced namespaces or volumes to the storage controller. Attached namespaces and volumes are added to the <code>AttachedVolumes</code> property in <code>Links</code> . For NVMe, namespaces are modeled as <code>Volume</code> resources.
<b>AttributeName</b>	AttributeRegistry (RegistryEntries > Attributes)	string	The unique name for the attribute.
<b>AttributeRegistry</b>	Bios	string	The resource ID of the attribute registry that has the system-specific information about a BIOS resource.
<b>Attributes</b>	AttributeRegistry (RegistryEntries)	array	An array of attributes and their possible values in the attribute registry.

Property Name	Defined In Schema(s)	Type	Description
	Bios	object	The list of BIOS attributes specific to the manufacturer or provider.
<b>Audience</b>	AccountService (ActiveDirectory > OAuth2Service), AccountService (LDAP > OAuth2Service), AccountService (OAuth2 > OAuth2Service), AccountService (TACACSPplus > OAuth2Service), ExternalAccountProvider (OAuth2Service)	array	The allowable audience strings of the Redfish service.
<b>Authentication</b>	AccountService (ActiveDirectory), AccountService (LDAP), AccountService (OAuth2), AccountService (TACACSPplus), ExternalAccountProvider	object	The authentication information for the external account provider.
	OutboundConnection	string (enum)	The authentication mechanism for the WebSocket connection.
	EventService (SMTP)	string (enum)	The authentication method for the SMTP server.
<b>AuthenticationKey</b>	AggregationSource (SNMP), EventDestination (SNMP), ManagerAccount (SNMP)	string	The secret authentication key for SNMPv3.
<b>AuthenticationKeySet</b>	AggregationSource (SNMP), EventDestination (SNMP), ManagerAccount (SNMP)	boolean	Indicates if the <code>AuthenticationKey</code> property is set.
<b>AuthenticationMethod</b>	Drive (Actions > UnfreezePersonality (Action)), Storage (Actions > UnfreezePersonality (Action))	string (enum)	The authentication method for the unfreeze operation.
	NetworkDeviceFunction (iSCSIBoot)	string (enum)	The iSCSI boot authentication method for this network device function.
<b>AuthenticationModeEnabled</b>	Port (UALink)	boolean	An indication of whether authentication mode is enabled.
<b>AuthenticationModes</b>	HostInterface	array	The authentication modes available on this interface.
<b>AuthenticationProtocol</b>	AggregationSource (SNMP), EventDestination (SNMP), ManagerAccount (SNMP)	string (enum)	The authentication protocol for SNMPv3.

Property Name	Defined In Schema(s)	Type	Description
	ManagerNetworkProtocol (SNMP)	string (enum)	The authentication protocol used for SNMPv3 access to this manager.
<b>AuthenticationType</b>	AccountService (ActiveDirectory > Authentication), AccountService (LDAP > Authentication), AccountService (OAuth2 > Authentication), AccountService (TACACSPplus > Authentication), ExternalAccountProvider (Authentication)	string (enum)	The type of authentication used to connect to the external account provider.
<b>AuthFailureLoggingThreshold</b>	AccountService	integer	The number of authorization failures per account that are allowed before the failed attempt is logged to the manager log.
<b>AuthNoneRole</b>	HostInterface (Links)	object	The link to the Redfish role that contains the privileges on this host interface when no authentication is performed.
<b>AuthNoneRoleId</b>	HostInterface	string	The role when no authentication on this interface is used.
<b>AuthorizationScope</b>	License	string (enum)	The authorization scope of the license.
<b>AuthorizationService</b>	AccountService (ActiveDirectory > TACACSPplusService), AccountService (LDAP > TACACSPplusService), AccountService (OAuth2 > TACACSPplusService), AccountService (TACACSPplus > TACACSPplusService), ExternalAccountProvider (TACACSPplusService)	string	The TACACS+ service authorization argument.
<b>AuthorizedDevices</b>	License (Links)	array	An array of links to the devices authorized by the license.
	LicenseService (Actions > Install (Action))	array	An array of links to the devices to be authorized by the license.
<b>AutoClearResolvedEntries</b>	LogService	string (enum)	Indicates if this log service automatically clears the resolved log entries.

Property Name	Defined In Schema(s)	Type	Description
<b>AutoDSTEnabled</b>	LogService	boolean	An indication of whether the log service is configured for automatic Daylight Saving Time (DST) adjustment.
	Manager	boolean	An indication of whether the manager is configured for automatic Daylight Saving Time (DST) adjustment.
<b>AutomaticCertificateEnrollment</b>	CertificateService	object	The automatic certificate enrollment configuration.
<b>AutomaticRetryAttempts</b>	ComputerSystem (Boot)	integer	The number of attempts the system will automatically retry booting.
<b>AutomaticRetryConfig</b>	ComputerSystem (Boot)	string (enum)	The configuration of how the system retries booting automatically.
<b>AutomationNodeGroup</b>	AutomationNode (Links)	array	An array of links to the automation nodes that are included in an automation node group.
<b>AutomationNodes</b>	Chassis (Links)	array	An array of links to the automation nodes contained in this chassis.
	ServiceRoot	object	The link to a collection of automation nodes.
<b>AutoNeg</b>	EthernetInterface	boolean	An indication of whether the speed and duplex are automatically negotiated and configured on this interface.
<b>AutoSpeedNegotiation</b>	NetworkPort (SupportedLinkCapabilities)	boolean	An indication of whether the port is capable of autonegotiating speed.
<b>AutoSpeedNegotiationCapable</b>	Port (LinkConfiguration)	boolean	An indication of whether the port is capable of autonegotiating speed.
<b>AutoSpeedNegotiationEnabled</b>	Port (LinkConfiguration)	boolean	Controls whether this port is configured to enable autonegotiating speed.
<b>AutoTransferEnabled</b>	PowerDistribution (TransferConfiguration)	boolean	Indicates if the qualified alternate mains circuit is automatically switched on when the preferred mains circuit becomes unqualified and is automatically switched off.

Property Name	Defined In Schema(s)	Type	Description
<b>AutoVolumeCreate</b>	Storage	string (enum)	Indicates if this storage subsystem automatically creates new volumes for unassigned drives.
<b>AvailableBytes</b>	ManagerDiagnosticData (MemoryStatistics)	integer (bytes)	The amount of memory available in bytes for starting new processes without swapping.
<b>AvailableExtents</b>	CXLLogicalDevice	integer	The number of available extents on this logical device.
<b>AvailableSparePercent</b>	StorageControllerMetrics (NVMeSMART)	number (%)	The normalized percentage of the remaining spare capacity available.
<b>AvailableSpareThresholdPercent</b>	StorageControllerMetrics (NVMeSMART)	number (%)	The available spare threshold as a normalized percentage.
<b>AvailableTags</b>	CXLLogicalDevice	integer	The number of available tags on this logical device.
<b>AverageConsumedWatts</b>	Power (PowerControl > PowerMetrics)	number (watts)	The average power level over the measurement window over the last <code>IntervalInMin</code> minutes.
<b>AverageFrequencyMHz</b>	ProcessorMetrics	number (MHz)	The average frequency of the processor.
<b>AveragePowerBudgetMilliWatts</b>	Memory (PowerManagementPolicy)	integer (milliwatts)	Average power budget, in milliwatt units.
<b>AverageReading</b>	Sensor	number	The average sensor value.
<b>AveragingInterval</b>	Sensor	string	The interval over which the average sensor value is calculated.
<b>AveragingIntervalAchieved</b>	Sensor	boolean	Indicates that enough readings were collected to calculate the average sensor reading over the averaging interval time.
<b>BackpressureAveragePercentage</b>	PortMetrics (CXL)	integer (%)	The average congestion of the port as a percentage.
<b>BackpressureSampleInterval</b>	Port (CXL > Congestion)	integer	The interval for the CXL Specification-defined 'Egress Port Congestion' mechanism to take samples in nanoseconds.

Property Name	Defined In Schema(s)	Type	Description
<b>BackupDestinations</b>	EventDestination	array	The backup destination URIs for this event receiver. Events are sent to these URIs, in array order, when the destination URI is unreachable or returns an error.
<b>BadBlockCount</b>	DriveMetrics	integer	The total number of bad blocks reported by the drive.
<b>BandwidthPercent</b>	ProcessorMetrics	number (%)	The bandwidth usage of this processor as a percentage.
	MemoryMetrics	number (%)	The memory bandwidth utilization as a percentage.
<b>BaseAsym</b>	SecurityPolicy (SPDM > Allowed > Algorithms), SecurityPolicy (SPDM > Denied > Algorithms)	array	The asymmetric signature algorithms.
<b>BaseDistinguishedNames</b>	AccountService (ActiveDirectory > LDAPService > SearchSettings), AccountService (LDAP > LDAPService > SearchSettings), AccountService (OAuth2 > LDAPService > SearchSettings), AccountService (TACACSpplus > LDAPService > SearchSettings), ExternalAccountProvider (LDAPService > SearchSettings)	array	The base distinguished names to use to search an external LDAP service.
<b>BaseHash</b>	SecurityPolicy (SPDM > Allowed > Algorithms), SecurityPolicy (SPDM > Denied > Algorithms)	array	The hash algorithms.
<b>BaseModuleType</b>	Memory	string (enum)	The base module type of the memory device.
<b>BaseSpeedMHz</b>	OperatingConfig, Processor	integer (MHz)	The base (nominal) clock speed of the processor in MHz.
	OperatingConfig (BaseSpeedPrioritySettings)	integer (MHz)	The clock speed to configure the set of cores in MHz.
<b>BaseSpeedPrioritySettings</b>	OperatingConfig	array	The clock speed for sets of cores when the configuration is operational.

Property Name	Defined In Schema(s)	Type	Description
<b>BaseSpeedPriorityState</b>	Processor	string (enum)	The state of the base frequency settings of the operation configuration applied to this processor.
<b>BatchSize</b>	Aggregate (Actions > Reset (Action)), AggregationService (Actions > Reset (Action))	integer	The number of elements in each batch being reset.
<b>Batteries</b>	Memory (Links)	array	The batteries that provide power to this memory device during a power-loss event.
	StorageController (Links)	array	The batteries that provide power to this storage controller during a power-loss event.
	PowerSubsystem	object	The link to the collection of batteries within this subsystem.
<b>BatteryChemistryType</b>	Battery	string (enum)	The chemistry of the battery.
<b>BFDSingleHopOnly</b>	AddressPool (Ethernet)	object	Bidirectional Forwarding Detection (BFD) related properties for this Ethernet fabric.
<b>BGPVpn</b>	AddressPool (Ethernet)	object	BGP Ethernet Virtual Private Network (EVPN) related properties for this Ethernet fabric.
<b>BGPLocalPreference</b>	AddressPool (Ethernet > EBGp), AddressPool (Ethernet > MultiProtocolEBGP)	integer	Local preference value.
<b>BGPNeighbor</b>	AddressPool (Ethernet > EBGp), AddressPool (Ethernet > MultiProtocolEBGP), AddressPool (Ethernet > MultiProtocolIBGP)	object	Border Gateway Protocol (BGP) neighbor related properties.
<b>BGPRoute</b>	AddressPool (Ethernet > EBGp), AddressPool (Ethernet > MultiProtocolEBGP), AddressPool (Ethernet > MultiProtocolIBGP)	object	Border Gateway Protocol (BGP) route-related properties.
<b>BGPWeight</b>	AddressPool (Ethernet > EBGp), AddressPool (Ethernet > MultiProtocolEBGP)	integer	BGP weight attribute.

Property Name	Defined In Schema(s)	Type	Description
<b>BinaryDataURI</b>	Assembly (Assemblies)	string	The URI at which to access an image of the assembly information.
<b>BindingStatus</b>	VirtualPCI2PCIBridge	string (enum)	The binding status of the vPPB.
<b>Bios</b>	ComputerSystem	object	The link to the BIOS settings associated with this system.
<b>BiosVersion</b>	GraphicsController	string	The version of the graphics controller BIOS or primary graphics controller firmware.
	ComputerSystem	string	The version of the system BIOS or primary system firmware.
<b>BitRate</b>	SerialInterface	string (enum)	The receive and transmit rate of data flow, typically in bits per second (bit/s), over the serial connection.
<b>BlockSecurityIDEnabled</b>	Drive	boolean	Indicates if establishment of a TCG-defined security ID (SID) on the drive is blocked.
<b>BlockSecurityIDPolicy</b>	Storage	boolean	Indicates if the storage controller sends a command to block establishment of a TCG-defined security ID (SID) during each drive boot sequence for drives that support it.
<b>BlockSecurityIDUnsupportedDrives</b>	Storage (Links)	array	The set of drives in this storage subsystem that do not support blocking of TCG-defined security ID (SID).
<b>BlockSecurityIDUpdateUnsuccessfulDrives</b>	Storage (Links)	array	The set of drives in this storage subsystem for which the most recent attempt to block TCG-defined security ID (SID) failed.
<b>BlockSizeBytes</b>	MemoryMetrics	integer (bytes)	The block size, in bytes.
	Volume	integer (bytes)	The size of the smallest addressable unit (Block) of this volume in bytes.

Property Name	Defined In Schema(s)	Type	Description
	Drive	integer (bytes)	The size, in bytes, of the smallest addressable unit, or block.
<b>BlockSizeMiB</b>	PCIeDevice (CXLDevice > DynamicCapacity > MemoryBlockSizesSupported)	array (mebibytes)	Set of memory block sizes supported by this memory region defined in mebibytes (MiB).
	MemoryRegion	integer (mebibytes)	The memory region block size in mebibytes (MiB).
<b>BlocksRead</b>	MemoryMetrics (LifeTime)	integer	The number of blocks read for the lifetime of the memory.
	MemoryMetrics (CurrentPeriod)	integer	The number of blocks read since reset.
<b>BlocksWritten</b>	MemoryMetrics (LifeTime)	integer	The number of blocks written for the lifetime of the memory.
	MemoryMetrics (CurrentPeriod)	integer	The number of blocks written since reset.
<b>Boot</b>	Bios (Passwords)	object	Information about the password that allows the system to boot to an operating system.
	ComputerSystem	object	The boot settings for this system.
<b>BootImagePushURI</b>	ComputerSystem	string	The URI used to perform a Redfish Specification-defined multipart HTTP or HTTPS push upload, configuration, and immediate boot from a virtual media image.
<b>Bootloader</b>	SoftwareInventory (AdditionalVersions)	string	The bootloader version contained in this software, such as U-Boot or UEFI.
<b>BootMediaURI</b>	NetworkDeviceFunction (HTTPBoot)	string	The URI of the boot media loaded with this network device function.
<b>BootMode</b>	NetworkDeviceFunction	string (enum)	The boot mode configured for this network device function.
<b>BootNext</b>	ComputerSystem (Boot)	string	The <code>BootOptionReference</code> of the Boot Option to perform a one-time boot from when <code>BootSourceOverrideTarget</code> is <code>UefiBootNext</code> .

Property Name	Defined In Schema(s)	Type	Description
<b>BootOptionEnabled</b>	BootOption	boolean	An indication of whether the boot option is enabled. If <code>true</code> , it is enabled. If <code>false</code> , the boot option that the boot order array on the computer system contains is skipped. In the UEFI context, this property influences the load option active flag for the boot option.
<b>BootOptionReference</b>	BootOption	string	The unique boot option.
<b>BootOptions</b>	ComputerSystem (Boot)	object	The link to the collection of the UEFI boot options associated with this computer system.
<b>BootOrder</b>	ComputerSystem (Boot)	array	An array of <code>BootOptionReference</code> strings that represent the persistent boot order for with this computer system. Changes to the boot order typically require a system reset before they take effect. It is likely that a client finds the <code>@Redfish.Settings</code> term in this resource, and if it is found, the client makes requests to change boot order settings by modifying the resource identified by the <code>@Redfish.Settings</code> term.
<b>BootOrderPropertySelection</b>	ComputerSystem (Boot)	string (enum)	The name of the boot order property that the system uses for the persistent boot order.
<b>BootParameters</b>	SoftwareInventory (AdditionalVersions)	string	The version of the configuration file that contains the initial boot parameters of this software, such as parameters for U-Boot.
<b>BootPriority</b>	NetworkDeviceFunction (FibreChannel > BootTargets)	integer	The relative priority for this entry in the boot targets array.
<b>BootProgress</b>	ComputerSystem	object	This object describes the last boot progress state.
<b>BootSourceOverrideEnabled</b>	ComputerSystem (Boot)	string (enum)	The state of the boot source override feature.

Property Name	Defined In Schema(s)	Type	Description
<b>BootSourceOverrideMode</b>	ComputerSystem (Boot)	string (enum)	The BIOS boot mode to use when the system boots from the <code>BootSourceOverrideTarget</code> boot source.
<b>BootSourceOverrideTarget</b>	ComputerSystem (Boot)	string (enum)	The current boot source to use at the next boot instead of the normal boot device, if <code>BootSourceOverrideEnabled</code> does not contain <code>Disabled</code> .
<b>BootTargets</b>	NetworkDeviceFunction (FibreChannel)	array	An array of Fibre Channel boot targets configured for this network device function.
<b>BootTimeStatistics</b>	ManagerDiagnosticData	object	The boot-time statistics of the manager.
<b>BoundLdId</b>	VirtualPCI2PCIBridge	integer	The identifier of the bound local logical device.
<b>BoundPBRId</b>	VirtualPCI2PCIBridge	integer	The identifier of the bound PBR.
<b>BoundPortId</b>	VirtualPCI2PCIBridge	integer	The physical port number of the bound port.
<b>BranchCircuit</b>	Circuit (Links)	object	A reference to the branch circuit related to this circuit.
	Outlet (Links)	object	A reference to the branch circuit related to this outlet.
<b>Branches</b>	PowerDistribution	object	A link to the branch circuits for this equipment.
<b>BreakerControl (Action)</b>	Circuit (Actions)	object	This action attempts to reset the circuit breaker.
<b>BreakerState</b>	Circuit	string (enum)	The state of the overcurrent protection device.
<b>BuffersAndCacheBytes</b>	ManagerDiagnosticData (MemoryStatistics)	integer (bytes)	The amount of memory used in bytes by kernel buffers, page caches, and slabs.
<b>BurstBytesPerSecond</b>	NetworkDeviceFunction (Limits)	integer	The maximum number of bytes per second in a burst for this network device function.

Property Name	Defined In Schema(s)	Type	Description
<b>BurstPacketsPerSecond</b>	NetworkDeviceFunction (Limits)	integer	The maximum number of packets per second in a burst for this network device function.
<b>BusErrorCount</b>	ManagerDiagnosticData (I2CBuses)	integer	The number of bus errors on this I2C bus.
<b>BusNumber</b>	PCIeFunction	string	The bus number of this PCIe function.
<b>BusWidthBits</b>	Memory	integer	The bus width, in bits.
<b>ByLane</b>	PortMetrics (Transceivers)	array	The metrics for the lanes in this port that are part of this transceiver. Each member represents a single lane.
<b>BypassTypes</b>	AccountService (ActiveDirectory > RemoteRoleMapping > MFABypass), AccountService (LDAP > RemoteRoleMapping > MFABypass), AccountService (OAuth2 > RemoteRoleMapping > MFABypass), AccountService (TACACSplus > RemoteRoleMapping > MFABypass)	array	The types of multi-factor authentication this account or role mapping is allowed to bypass.
<b>CableClass</b>	Cable	string (enum)	The identifier for the downstream resource.
<b>Cables</b>	Chassis (Links)	array	An array of links to the cables connected to this chassis.
	Port (Links)	array	An array of links to the cables connected to this port.
	ServiceRoot	object	The link to a collection of cables.
<b>CableStatus</b>	Cable	string (enum)	The user-reported status of this resource.
<b>CableType</b>	Cable	string	The type of this cable.
<b>CACertificates</b>	CertificateEnrollment (Links)	array	The list of server certificates for the server referenced by the <code>ServerURI</code> property.
<b>Cache</b>	ProcessorMetrics	array	The processor cache metrics.

Property Name	Defined In Schema(s)	Type	Description
<b>CacheDataVolumes</b>	Volume (Links)	array	A pointer to the data volumes this volume serves as a cache volume.
<b>CacheDuration</b>	ComputerSystem (KeyManagement > KMIPServers)	string	The duration the system caches KMIP data.
<b>CacheLevel</b>	Memory	integer	The level of the cache memory.
<b>CacheMemory</b>	Processor	object	The link to the collection of cache memory associated with this processor.
<b>CacheMetricsTotal</b>	ProcessorMetrics	object	The total cache metrics for this processor.
<b>CacheMiss</b>	ProcessorMetrics (Cache), ProcessorMetrics (CoreMetrics > CoreCache)	number	The number of cache line misses in millions.
<b>CacheMissesPerInstruction</b>	ProcessorMetrics (Cache), ProcessorMetrics (CoreMetrics > CoreCache)	number	The number of cache misses per instruction.
<b>CachePolicy</b>	ComputerSystem (KeyManagement > KMIPServers)	string (enum)	The cache policy to control how KMIP data is cached.
<b>CacheSizeMiB</b>	Memory	integer (mebibytes)	Total size of the cache portion memory in MiB.
<b>CacheSummary</b>	Storage (StorageControllers), StorageController	object	The cache memory of the storage controller in general detail.
<b>CacheVolumeSource</b>	Volume (Links)	object	A pointer to the cache volume source for this volume.
<b>Calculable</b>	MetricDefinition	string (enum)	An indication of whether the metric can be used in a calculation.
<b>CalculationAlgorithm</b>	MetricDefinition	string (enum)	The calculation that is performed on a source metric to obtain the metric being defined.
<b>CalculationParameters</b>	MetricDefinition	array	The metric properties that are part of a calculation that this metric definition defines.
<b>CalculationTimeInterval</b>	MetricDefinition	string	The time interval over which the metric calculation is performed.

Property Name	Defined In Schema(s)	Type	Description
<b>Calibrate (Action)</b>	Battery (Actions)	object	This action performs a self-calibration, or learn cycle, of the battery.
<b>Calibration</b>	MetricDefinition	number	The calibration offset added to the metric reading.
	Sensor	number	The calibration offset applied to the Reading.
<b>CalibrationTime</b>	Sensor	string	The date and time that the sensor was last calibrated.
<b>Cancel (Action)</b>	Job (Actions)	object	Cancels the job.
	SoftwareInventory (Actions)	object	This action cancels the pending activation of this staged software inventory instance.
<b>CancelAllJobs (Action)</b>	JobService (Actions)	object	Cancels all jobs.
<b>CapabilitiesVendorID</b>	TrustedComponent (TPM)	string	The capabilities vendor ID for this trusted component.
<b>Capable</b>	NetworkAdapter (Controllers > ControllerCapabilities > DataCenterBridging)	boolean	An indication of whether this controller is capable of data center bridging (DCB).
<b>CapableLinkSpeedGbps</b>	Port (LinkConfiguration)	array (Gbit/s)	The set of link speed capabilities of this port.
<b>CapableLinkSpeedMbps</b>	NetworkPort (SupportedLinkCapabilities)	array	The set of link speed capabilities of this port.
<b>CapablePowerWatts</b>	Port (Ethernet > PoE)	number (watts)	The maximum power supported by this port.
<b>CapableProtocolVersions</b>	PCleDevice (CXLDevice)	array	An array of the CXL specification revisions supported by this device.
	Port	array	The protocol versions capable of being sent over this port.
<b>CapableSpeedGbs</b>	Drive	number (Gbit/s)	The speed, in gigabits per second (Gbit/s) units, at which this drive can communicate to a storage controller in ideal conditions.
<b>Capacity</b>	Volume	object	Capacity utilization.

Property Name	Defined In Schema(s)	Type	Description
<b>CapacityActualAmpHours</b>	Battery	number (A.h)	The actual maximum capacity of this battery in amp-hour units.
<b>CapacityActualWattHours</b>	Battery	number (W.h)	The actual maximum capacity of this battery in watt-hour units.
<b>CapacityBytes</b>	Volume	integer (bytes)	The size in bytes of this Volume.
	SimpleStorage (Devices)	integer (bytes)	The size, in bytes, of the storage device.
	Drive	integer (bytes)	The size, in bytes, of this drive.
<b>CapacityLiters</b>	Reservoir	number	The capacity of the reservoir (L).
<b>CapacityMiB</b>	Memory	integer (mebibytes)	Memory capacity in mebibytes (MiB).
	Processor (ProcessorMemory)	integer (mebibytes)	The memory capacity in MiB.
<b>CapacityRatedAmpHours</b>	Battery	number (A.h)	The rated maximum capacity of this battery in amp-hour units.
<b>CapacityRatedWattHours</b>	Battery	number (W.h)	The rated maximum capacity of this battery in watt-hour units.
<b>CapacitySources</b>	Volume	array	An array of space allocations to this volume.
<b>CapacityUtilizationPercent</b>	MemoryMetrics	number (%)	The memory capacity utilization as a percentage.
<b>CapacityWatts</b>	PowerSupply (InputRanges)	number (watts)	The maximum capacity of this power supply when operating in this input range.
	PowerSubsystem	number (watts)	The total amount of power that this subsystem can draw.
<b>CDUs</b>	Facility (Links)	array	An array of links to the coolant distribution units in this facility.
	ThermalEquipment	object	A link to a collection of coolant distribution units.
<b>CellVoltages</b>	BatteryMetrics	array	The cell voltages (V) for this battery.

Property Name	Defined In Schema(s)	Type	Description
<b>Certificate</b>	ComponentIntegrity (Actions > TPMGetSignedMeasurements (Action))	object	The URI for the certificate that represents the TPM attestation key.
<b>CertificateCollection</b>	CertificateService (Actions > GenerateCSR (Action))	object	The link to the certificate collection where the certificate is installed after the certificate authority (CA) signs the certificate.
<b>CertificateEnrollments</b>	CertificateService	object	The link to the collection of certificate enrollment configurations.
<b>CertificateLocations</b>	CertificateService	object	The information about the location of certificates.
<b>CertificateMappingAttribute</b>	AccountService (MultiFactorAuth > ClientCertificate)	string (enum)	The client certificate attribute to map to a user.
<b>Certificates</b>	CertificateLocations (Links)	array	An array of links to the certificates installed on this service.
	SecureBootDatabase	object	A link to the collection of certificates contained in this UEFI Secure Boot database.
	AccountService (MultiFactorAuth > ClientCertificate)	object	The link to a collection of CA certificates used to validate client certificates.
	<i>various</i> (Chassis, ComputerSystem ... )	object	The link to a collection of certificates for device identity and attestation.
	AccountService (ActiveDirectory), AccountService (LDAP), AccountService (OAuth2), AccountService (TACACSplus), ExternalAccountProvider	object	The link to a collection of certificates that the external account provider uses.
	ComputerSystem (Boot)	object	The link to a collection of certificates used for booting through HTTPS by this computer system.
	ManagerNetworkProtocol (HTTPS)	object	The link to a collection of certificates used for HTTPS by this manager.
	TrustedComponent	object	The link to a collection of device identity certificates of the trusted component.

Property Name	Defined In Schema(s)	Type	Description
	OutboundConnection	object	The link to a collection of server certificates for the remote client referenced by the <code>EndpointURI</code> property.
	AccountService (MultiFactorAuth > SecurID)	object	The link to a collection of server certificates for the RSA SecurID server referenced by the <code>ServerURI</code> property.
	EventDestination	object	The link to a collection of server certificates for the server referenced by the <code>Destination</code> property.
	VirtualMedia	object	The link to a collection of server certificates for the server referenced by the <code>Image</code> property.
	ManagerAccount	object	The link to a collection of user identity certificates for this account.
<b>CertificateService</b>	ServiceRoot	object	The link to the certificate service.
<b>CertificatesSupported</b>	CertificateService (AutomaticCertificateEnrollment)	array	The certificate usage types that support automatic enrollments for this service.
<b>CertificateString</b>	Certificate, CertificateService (Actions > ReplaceCertificate (Action))	string	The string for the certificate.
<b>CertificateType</b>	Certificate, CertificateService (Actions > ReplaceCertificate (Action))	string (enum)	The format of the certificate.
<b>CertificateUri</b>	CertificateService (Actions > ReplaceCertificate (Action))	object	The link to the certificate that is being replaced.
<b>CertificateUsageTypes</b>	Certificate	array	The types or purposes for this certificate.
<b>ChallengePassword</b>	CertificateEnrollment (SCEP)	string	The challenge password for SCEP enrollment.

Property Name	Defined In Schema(s)	Type	Description
	Certificate (Actions > Rekey (Action)), Certificate (Actions > Renew (Action)), CertificateEnrollment (CSRParameters), CertificateService (Actions > GenerateCSR (Action))	string	The challenge password to apply to the certificate for revocation requests.
<b>ChallengeType</b>	CertificateEnrollment (ACME)	string (enum)	The ACME challenge type used for domain validation.
<b>ChangeAffectsUserData</b>	Drive (NVMe > ActivePersonalities), Storage (NVMeSubsystemProperties > ActivePersonalities)	boolean	An indication of whether changing this personality affects user data.
<b>ChangePassword (Action)</b>	Bios (Actions)	object	This action changes a BIOS password.
	ManagerAccount (Actions)	object	This action changes the account password.
<b>ChangeRAIDLAYOUT (Action)</b>	Volume (Actions)	object	Request system change the RAID layout of the volume.
<b>Channel</b>	Memory (MemoryLocation)	integer	The channel number to which the memory device is connected.
<b>CHAP</b>	Connection (ConnectionKeys)	object	The CHAP-specific permission key information for this connection.
<b>CHAPPassword</b>	Connection (ConnectionKeys > CHAP)	string	The password for CHAP authentication. The value is <code>null</code> in responses.
<b>CHAPSecret</b>	NetworkDeviceFunction (iSCSIBoot)	string	The shared secret for CHAP authentication.
<b>CHAPUsername</b>	Connection (ConnectionKeys > CHAP), NetworkDeviceFunction (iSCSIBoot)	string	The username for CHAP authentication.
<b>ChargePercent</b>	BatteryMetrics	object	The amount of charge available (percent) in this battery.
<b>ChargeState</b>	Battery	string (enum)	The charge state of this battery.
<b>Chassis</b>	PCIeDevice (Links)	array	An array of links to the chassis in which the PCIe device is contained.

Property Name	Defined In Schema(s)	Type	Description
	ResourceBlock (Links)	array	An array of links to the chassis in which this resource block is contained.
	AutomationNode (Links), CoolingUnit (Links), JobExecutor (Links), PowerDistribution (Links)	array	An array of links to the chassis that contain this equipment.
	ComputerSystem (Links)	array	An array of links to the chassis that contains this system.
	Outlet (Links)	array	Any array of links to chassis connected to this outlet.
	CoolingLoop (Links)	object	A link to the chassis that contains this equipment.
	ServiceRoot	object	The link to a collection of chassis.
	Drive (Links)	object	The link to the chassis that contains this drive.
	EthernetInterface (Links)	object	The link to the chassis that contains this Ethernet interface.
	Memory (Links)	object	The link to the chassis that contains this memory device.
	Processor (Links)	object	The link to the chassis that contains this processor.
	SimpleStorage (Links)	object	The link to the chassis that contains this simple storage.
	Switch (Links)	object	The link to the chassis that contains this switch.
<b>ChassisId</b>	Port (Ethernet > LLDPReceive)	string	Link Layer Data Protocol (LLDP) chassis ID received from the remote partner across this link.
	Port (Ethernet > LLDPTransmit)	string	Link Layer Data Protocol (LLDP) chassis ID.
<b>ChassisIdSubtype</b>	Port (Ethernet > LLDPReceive)	string (enum)	The type of identifier used for the chassis ID received from the remote partner across this link.
	Port (Ethernet > LLDPTransmit)	string (enum)	The type of identifier used for the chassis ID.

Property Name	Defined In Schema(s)	Type	Description
<b>ChassisType</b>	Chassis	string (enum)	The type of physical form factor of the chassis.
<b>CheckConsistency (Action)</b>	Volume (Actions)	object	This action is used to force a check of the Volume's parity or redundant data to ensure it matches calculated values.
<b>ChunkLink</b>	MemoryRegion (MemoryChunks)	object	The link to the memory chunk providing capacity to the memory region.
	MemoryExtent (MemoryChunks)	object	The link to the memory chunk that provides capacity to the memory extent.
<b>ChunkOffsetMiB</b>	MemoryRegion (MemoryChunks)	integer (mebibytes)	Offset of the memory chunk within the memory region in mebibytes (MiB).
	MemoryExtent (MemoryChunks)	integer (mebibytes)	The offset of the memory chunk within the memory extent in mebibytes (MiB).
<b>CID</b>	Endpoint (ConnectedEntities > GenZ > GCID)	string	The component identifier portion of the GCID for the entity.
<b>CIDR</b>	AddressPool (Ethernet > EBGp > BGPNeighbor), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor)	integer	The Classless Inter-Domain Routing (CIDR) value used for neighbor communication. This is the number of ones before the first zero in the subnet mask.
<b>CipherSuiteAllowList</b>	KeyPolicy (NVMeoF)	array	The cipher suites that this key policy allows.
<b>CipherSuites</b>	SecurityPolicy (TLS > Client > Allowed > Algorithms), SecurityPolicy (TLS > Client > Denied > Algorithms), SecurityPolicy (TLS > Server > Allowed > Algorithms), SecurityPolicy (TLS > Server > Denied > Algorithms)	array	The TLS cipher suites.
<b>CircuitType</b>	Circuit	string (enum)	The type of circuit.

Property Name	Defined In Schema(s)	Type	Description
<b>City</b>	CertificateEnrollment (CSRParameters), CertificateService (Actions > GenerateCSR (Action))	string	The city or locality of the organization making the request.
	Certificate (Issuer), Certificate (Subject)	string	The city or locality of the organization of the entity.
<b>ClassCode</b>	PCleFunction	string	The Class Code of this PCIe function.
	Endpoint (ConnectedEntities > EntityPcild), Endpoint (Pcild)	string	The Class Code, Subclass, and Programming Interface code of this PCIe function.
<b>ClassOfService</b>	Volume (Links)	object	The ClassOfService that this storage volume conforms to.
<b>ClearCurrentPeriod (Action)</b>	MemoryMetrics (Actions), ProcessorMetrics (Actions), SwitchMetrics (Actions)	object	This action sets the <code>CurrentPeriod</code> property's values to 0.
<b>ClearLog (Action)</b>	LogService (Actions)	object	The action to clear the log for this log service.
<b>ClearMetricReports (Action)</b>	TelemetryService (Actions)	object	The action to clear the metric reports for this telemetry service.
<b>ClearSecretKey (Action)</b>	ManagerAccount (Actions)	object	This action clears the secret key for Time-based One-Time Password (TOTP) multi-factor authentication for this account.
<b>ClearTelemetryData (Action)</b>	TelemetryService (Actions)	object	The action to clear the telemetry data for this telemetry service.
<b>Client</b>	SecurityPolicy (TLS)	object	The TLS policy where the manager acts as a TLS client for communication with servers.
	CompositionReservation	string	The client that owns the reservation.
	ResourceBlock	string	The client to which this resource block is assigned.
<b>ClientCertificate</b>	AccountService (MultiFactorAuth)	object	The settings related to client certificate authentication schemes such as mTLS or CAC/PIV.

Property Name	Defined In Schema(s)	Type	Description
<b>ClientCertificates</b>	OutboundConnection	object	The link to a collection of client identity certificates provided to the remote client referenced by the <code>EndpointURI</code> property.
	EventDestination	object	The link to a collection of client identity certificates provided to the server referenced by the <code>Destination</code> property.
	VirtualMedia	object	The link to a collection of client identity certificates provided to the server referenced by the <code>Image</code> property.
	UpdateService	object	The link to a collection of client identity certificates provided to the server referenced by the <code>ImageURI</code> parameter in <code>SimpleUpdate</code> .
<b>ClientContextQuery</b>	ServiceRoot (ProtocolFeaturesSupported)	boolean	An indication of whether the service supports the <code>clientcontext</code> query parameter for incremental retrieval from resource collections.
<b>ClientEndpoints</b>	Volume (Links)	array	An array of references to the client Endpoints associated with this volume.
<b>ClientId</b>	AccountService (MultiFactorAuth > SecurID)	string	The client ID to use when communicating with the RSA SecurID server.
<b>ClientOriginIPAddress</b>	Session	string	The IP address of the client that created the session.
<b>ClientSecret</b>	AccountService (MultiFactorAuth > SecurID)	string	The client secret to use when communicating with the RSA SecurID server. This property is <code>null</code> in responses.
<b>ClientSecretSet</b>	AccountService (MultiFactorAuth > SecurID)	boolean	Indicates if the <code>ClientSecret</code> property is set.
<b>ClientType</b>	RegisteredClient	string (enum)	The type of registered client.
<b>ClientURI</b>	RegisteredClient	string	The URI of the registered client.

Property Name	Defined In Schema(s)	Type	Description
<b>ClosedTransitionAllowed</b>	PowerDistribution (TransferConfiguration)	boolean	Indicates if a make-before-break switching sequence of the mains circuits is permitted when they are both qualified and in synchronization.
<b>ClosedTransitionTimeoutSeconds</b>	PowerDistribution (TransferConfiguration)	integer	The time in seconds to wait for a closed transition to occur.
<b>CoefficientUpdateTime</b>	Control (ControlLoop)	string	The date and time that the control loop coefficients were changed.
<b>CollectDiagnosticData (Action)</b>	LogService (Actions)	object	The action to collect the diagnostic data for the given type. When the diagnostic data is collected, a new log entry will be created and the additional data referenced by the new log entry will contain the diagnostic data.
<b>CollectionDuration</b>	MetricReportDefinition (Metrics)	string	The duration over which the function is computed.
<b>CollectionFunction</b>	TelemetryService (SupportedCollectionFunctions)	string (enum)	An operation to perform over the sample.
	MetricReportDefinition (Metrics)	string (enum)	Specifies the function to perform on each of the metric properties listed in the <code>MetricProperties</code> property or the metric properties specified in the <code>MetricDefinition</code> referenced by the <code>MetricId</code> property. If not specified, calculations are not performed on the metric properties.
<b>CollectionTimeScope</b>	MetricReportDefinition (Metrics)	string (enum)	The scope of time over which the function is applied.
<b>CollectTelemetryData (Action)</b>	TelemetryService (Actions)	object	The action to collect the telemetry data from a device or service. When the telemetry data is collected, a new telemetry data resource will be created.
<b>CommandLine</b>	ManagerDiagnosticData (TopProcesses)	string	The command line of this process.
<b>CommandShell</b>	Manager	object	The manager's command line user interface or command shell service.

Property Name	Defined In Schema(s)	Type	Description
<b>Comment</b>	Key (SSH)	string	The user-specified comment associated with this key, which typically contains the client's username and host name.
<b>CommonName</b>	Certificate (Issuer), Certificate (Subject)	string	The common name of the entity.
	CertificateEnrollment (CSRParameters), CertificateService (Actions > GenerateCSR (Action))	string	The name of the component to secure.
<b>CommunityAccessMode</b>	ManagerNetworkProtocol (SNMP)	string (enum)	The access level of the SNMP community.
<b>CommunityString</b>	AggregationSource (SNMP), ManagerNetworkProtocol (SNMP > CommunityStrings)	string	The SNMP community string.
<b>CommunityStrings</b>	ManagerNetworkProtocol (SNMP)	array	The SNMP community strings.
<b>CompletedTaskOverWritePolicy</b>	TaskService	string (enum)	The overwrite policy for completed tasks. This property indicates if the task service overwrites completed task information.
<b>CompletionCollectionInterval</b>	Port (CXL > Congestion)	integer	The interval for the CXL Specification-defined 'Completion Counting' mechanism to collect the number of transmitted responses in a single counter in nanoseconds.
<b>ComponentCertificate</b>	ComponentIntegrity (SPDM > IdentityAuthentication > ResponderAuthentication), ComponentIntegrity (TPM > IdentityAuthentication)	object	A link to the certificate that represents the identity of the component.
<b>ComponentCommunication</b>	ComponentIntegrity (SPDM)	object	Information about communication between the SPDM Requester and SPDM Responder.
	ComponentIntegrity (TPM)	object	Information about communication with the TPM.
<b>ComponentIntegrity</b>	TrustedComponent (Links)	array	An array of links to ComponentIntegrity resources for which the trusted component is responsible.

Property Name	Defined In Schema(s)	Type	Description
	ServiceRoot	object	The link to a collection of component integrity information.
<b>ComponentIntegrityEnabled</b>	ComponentIntegrity	boolean	An indication of whether security protocols are enabled for the component.
<b>ComponentIntegrityType</b>	ComponentIntegrity	string (enum)	The type of security technology for the component.
<b>ComponentIntegrityTypeVersion</b>	ComponentIntegrity	string	The version of the security technology.
<b>Components</b>	CoolingUnit (Actions > ExportConfiguration (Action)), PowerDistribution (Actions > ExportConfiguration (Action))	array	The components of the equipment for which to export configuration data.
	ComputerSystem (Actions > ExportConfiguration (Action))	array	The components of the system for which to export configuration data.
<b>ComponentsProtected</b>	ComponentIntegrity (Links), TrustedComponent (Links)	array	An array of links to resources that the target component protects.
<b>Compose (Action)</b>	CompositionService (Actions)	object	This action performs a set of operations specified by a manifest.
<b>CompositeTemperatureCelsius</b>	StorageControllerMetrics (NVMeSMART)	number (Celsius)	The composite temperature (C).
<b>Composition</b>	ComputerSystem	object	Information about the composition capabilities and state of the computer system.
<b>CompositionReservations</b>	CompositionService	object	The link to the collection of reservations with the composition reservation collection.
<b>CompositionService</b>	ServiceRoot	object	The link to the composition service.
<b>CompositionState</b>	ResourceBlock (CompositionStatus)	string (enum)	The current state of the resource block from a composition perspective.
<b>CompositionStatus</b>	ResourceBlock	object	The composition status details for this resource block.
<b>Compressed</b>	Volume	boolean	Indicator of whether or not the Volume has compression enabled.

Property Name	Defined In Schema(s)	Type	Description
<b>CompressionSavingsBytes</b>	StorageMetrics	integer (bytes)	Current compression savings on the storage system in bytes.
<b>ComputerSystem</b>	JobExecutor (Links)	object	The system that is performing the work of this job executor.
<b>ComputerSystemETag</b>	ComputerSystem (Actions > AddResourceBlock (Action)), ComputerSystem (Actions > Decommission (Action)), ComputerSystem (Actions > RemoveResourceBlock (Action))	string	The current ETag of the system.
<b>ComputerSystems</b>	ResourceBlock	array	An array of links to the computer systems available in this resource block.
	HostInterface (Links)	array	An array of links to the computer systems connected to this host interface.
	ResourceBlock (Links)	array	An array of links to the computer systems that are composed from this resource block.
	Chassis (Links)	array	An array of links to the computer systems that this chassis directly and wholly contains.
<b>Condition</b>	ServiceConditions (Conditions)	object	A condition that requires attention.
<b>ConditionalRequirement</b>	ActionInfo (Parameters)	string	Information about conditional parameter requirements.
<b>Conditions</b>	ServiceConditions	array	Conditions reported by this service that require attention.
<b>ConfigurationLock</b>	Drive	string (enum)	Indicates whether in-band configuration requests to the drive are locked. Other properties, such as <code>ConfigurationLockState</code> , contain additional information regarding the status of the configuration lock.

Property Name	Defined In Schema(s)	Type	Description
	Storage	string (enum)	Indicates whether in-band configuration requests to the storage subsystem are locked. Other properties, such as <code>ConfigurationLockState</code> , contain additional information regarding the status of the configuration lock.
<b>ConfigurationLockCapable</b>	Memory (SecurityCapabilities)	boolean	An indication of whether this memory device supports the locking, or freezing, of the configuration.
<b>ConfigurationLocked</b>	Memory	boolean	An indication of whether the configuration of this memory device is locked and cannot be altered.
	Circuit, Outlet, OutletGroup	boolean	Indicates whether the configuration is locked.
<b>ConfigurationLockState</b>	Drive (NVMe), Storage (NVMeSubsystemProperties)	object	The configurable features that are able to be locked from in-band usage on an NVMe subsystem and their current lock state.
<b>ConfiguredAggregatedPorts</b>	NetworkAdapter (PortAggregation)	integer	The configured number number of aggregated ports.
<b>ConfiguredLinkSpeedGbps</b>	Port (LinkConfiguration > ConfiguredNetworkLinks)	number (Gbit/s)	The link speed per lane this port is configured to use for autonegotiation.
<b>ConfiguredNetworkLinks</b>	Port (LinkConfiguration)	array	The set of link speed and width pairs this port is configured to use for autonegotiation.
<b>ConfiguredPhysicalFunctions</b>	Storage (MPF)	integer	The current number of physical functions configured for the storage controller in this storage subsystem.
<b>ConfiguredPhysicalPortsPerAggregation</b>	NetworkAdapter (PortAggregation)	integer	The configured number of physical ports per aggregation.
<b>ConfiguredPowerWatts</b>	Port (Ethernet > PoE)	number (watts)	The configured maximum power this port is allowed to negotiate.
<b>ConfiguredSpeedGbps</b>	Port	number (Gbit/s)	The speed to which this port is configured to train when autonegotiation is disabled.

Property Name	Defined In Schema(s)	Type	Description
<b>ConfiguredWidth</b>	Port (LinkConfiguration > ConfiguredNetworkLinks)	integer	The link width this port is configured to use for autonegotiation in conjunction with the link speed.
	Port	integer	The number of lanes, phys, or other physical transport links to which this port is configured to train when autonegotiation is disabled.
<b>Congestion</b>	Port (CXL)	object	The congestion properties for this CXL port.
<b>CongestionTelemetryEnabled</b>	Port (CXL > Congestion)	boolean	Indicates whether congestion telemetry collection is enabled for this port.
<b>ConnectedChassis</b>	CoolantConnector (Links)	array	Any array of links to chassis at the other end of the connection.
<b>ConnectedCoolingLoop</b>	CoolantConnector (Links)	object	A link to the cooling loop at the other end of the connection.
<b>ConnectedCoolingLoops</b>	Chassis (Links)	array	An array of links to cooling loops connected to this chassis.
<b>ConnectedCoolingUnit</b>	CoolantConnector (Links)	object	A link to the cooling unit at the other end of the connection.
<b>ConnectedDeviceMode</b>	Port (CXL)	string (enum)	The connected device mode.
<b>ConnectedDeviceType</b>	Port (CXL)	string (enum)	The connected device type.
<b>ConnectedEntities</b>	Endpoint	array	All the entities connected to this endpoint.
<b>ConnectedPClePorts</b>	PCleDevice (Links)	array	An array of links to the remote PCIe ports to which this device is connected.
<b>ConnectedPorts</b>	Port (Links)	array	An array of links to the remote device ports at the other end of the link.
	Endpoint (Links)	array	An array of links to the switch ports or remote device ports at the other end of the link.
<b>ConnectedProcessors</b>	Processor (Links)	array	An array of links to the processors directly connected to this processor.

Property Name	Defined In Schema(s)	Type	Description
<b>ConnectedSwitches</b>	Port (Links)	array	An array of links to the switches at the other end of the link.
<b>ConnectedSwitchPorts</b>	Port (Links)	array	An array of links to the switch ports at the other end of the link.
<b>ConnectedVia</b>	VirtualMedia	string (enum)	The current virtual media connection method.
<b>ConnectionEnabled</b>	OutboundConnection	boolean	Indicates if the outbound connection is enabled.
<b>ConnectionKeys</b>	Connection	object	The permission keys required to access the specified resources for this connection.
<b>ConnectionMethod</b>	AggregationSource (Links)	object	A link to the connection method used to contact this aggregation source.
<b>ConnectionMethods</b>	AggregationService	object	The link to the collection of connection methods associated with this service.
<b>ConnectionMethodType</b>	ConnectionMethod	string (enum)	The type of connection method.
<b>ConnectionMethodVariant</b>	ConnectionMethod	string	The variant of connection method.
<b>ConnectionProtocol</b>	EventService (SMTP)	string (enum)	The connection type to the outgoing SMTP server.
<b>ConnectionRetryPolicy</b>	OutboundConnection (RetryPolicy)	string (enum)	The type of retry policy for this outbound connection.
<b>Connections</b>	Volume	array	An array of references to Connections that includes this volume.
	Endpoint (Links)	array	The connections to which this endpoint belongs.
	EndpointGroup (Links)	array	The connections to which this endpoint group belongs.
	Fabric	object	The collection of links to the connections that this fabric contains.

Property Name	Defined In Schema(s)	Type	Description
	Storage	object	The collection of links to the connections that this storage subsystem contains.
<b>ConnectionType</b>	Connection	string (enum)	The type of resources this connection specifies.
<b>ConnectorGroup</b>	CoolantConnector	object	The group of coolant connectors represented by this resource.
<b>ConnectorType</b>	SerialInterface	string (enum)	The type of connector used for this interface.
<b>ConnectRetrySeconds</b>	AddressPool (Ethernet > EBGp > BGPNeighbor), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor)	integer	Border Gateway Protocol (BGP) retry timer in seconds.
<b>ConnectTypesSupported</b>	Manager (CommandShell)	array	This property enumerates the command shell connection types that the implementation allows.
	ComputerSystem (GraphicalConsole), Manager (GraphicalConsole)	array	This property enumerates the graphical console connection types that the implementation allows.
	Manager (SerialConsole)	array	This property enumerates the serial console connection types that the implementation allows.
<b>ConsistencyCheckRatePercent</b>	Storage (StorageControllers > ControllerRates)	integer	The percentage of controller resources used for performing a data consistency check on volumes.
	StorageController (ControllerRates)	integer (%)	The percentage of controller resources used for performing a data consistency check on volumes.
<b>ConsistencyGroups</b>	Volume (Links)	array	An array of references to the ConsistencyGroups associated with this volume.
	Storage	object	The consistency groups, each of which contains a set of volumes that are treated by an application or set of applications as a single resource, that are managed by this storage subsystem.

Property Name	Defined In Schema(s)	Type	Description
<b>ConsoleEntryCommand</b>	ComputerSystem (SerialConsole > IPMI), ComputerSystem (SerialConsole > SSH), ComputerSystem (SerialConsole > Telnet)	string	The command string passed to the service to select or enter the system's serial console.
<b>ConsoleURI</b>	ComputerSystem (SerialConsole > WebSocket)	string	The URI at which to access the WebSocket serial console.
<b>ConsumedPowerWatt</b>	ProcessorMetrics	number (watts)	The power, in watt units, that the processor has consumed.
<b>ConsumingComputerSystems</b>	ComputerSystem (Links)	array	An array of links to computer systems that are realized, in whole or in part, from this computer system.
<b>ConsumingEquipmentNames</b>	CoolingLoop	array	An array of names of downstream devices that receive coolant from this cooling loop.
<b>ConsumingResourceBlocks</b>	ResourceBlock (Links)	array	An array of links to resource blocks that depend on this resource block.
<b>Contact</b>	License	object	The contact of the license.
<b>ContactName</b>	License (Contact)	string	Name of this contact.
<b>ContactPerson</b>	CertificateEnrollment (CSRParameters), CertificateService (Actions > GenerateCSR (Action))	string	The name of the user making the request.
<b>ContainedBy</b>	Chassis (Links)	object	The link to the chassis that contains this chassis.
<b>ContainedByFacility</b>	Facility (Links)	object	The link to the facility that contains this facility.
<b>ContainedByZones</b>	Zone (Links)	array	An array of links to the zone that contain this zone.
<b>ContainerEngines</b>	OperatingSystem	array	The container engines running in this operating system.
<b>ContainerImage</b>	Container (Links)	object	The link to the container image for this container.

Property Name	Defined In Schema(s)	Type	Description
<b>ContainerImages</b>	OperatingSystem	object	The link to the collection of container images available to container engines on this operating system.
<b>Containers</b>	ContainerImage (Links)	array	The array of links to the containers running from this container image.
	OperatingSystem	object	The link to the collection of containers running under this operating system.
<b>Contains</b>	Chassis (Links)	array	An array of links to any other chassis that this chassis has in it.
<b>ContainsChassis</b>	Facility (Links)	array	An array of links to the outermost chassis contained within this facility.
<b>ContainsFacilities</b>	Facility (Links)	array	An array of links to other facilities contained within this facility.
<b>ContainsZones</b>	Zone (Links)	array	An array of links to the zones that are contained by this zone.
<b>Context</b>	RegisteredClient	string	A client-supplied data for providing context for its own use.
	EventDestination	string	A client-supplied string that is stored with the event destination subscription.
	Session	string	A client-supplied string that is stored with the session.
	Event, Event (Events), MetricReport	string	A context can be supplied at subscription time. This property is the context value supplied by the subscriber.
<b>ControlDelaySeconds</b>	Control	number	The time delay in seconds before the control will activate once the value has deviated from the set point.
<b>ControllerBusyTimeMinutes</b>	StorageControllerMetrics (NVMeSMART)	integer	The total time the controller is busy with I/O commands in minutes.
<b>ControllerCapabilities</b>	NetworkAdapter (Controllers)	object	The capabilities of this controller.

Property Name	Defined In Schema(s)	Type	Description
<b>ControllerPassword</b>	Storage (Actions > ImportForeignDrives (Action))	string	The current controller password. This parameter is not required if the controller does not currently have a password.
<b>ControllerRates</b>	Storage (StorageControllers), StorageController	object	This property describes the various controller rates used for processes such as volume rebuild or consistency checks.
<b>Controllers</b>	Volume (Links)	array	An array of the Controllers associated with this volume.
	NetworkAdapter	array	The set of network controllers ASICs that make up this NetworkAdapter.
	Storage	object	The set of controllers instantiated by this storage subsystem.
<b>ControllerType</b>	StorageController (NVMeControllerProperties)	string (enum)	The type of NVMe controller.
<b>ControlLoop</b>	AutomationInstrumentation (PID), Control, CoolantConnector (DeltaPressureControlkPa), CoolantConnector (DeltaTemperatureControlCelsius), CoolantConnector (FlowControlLitersPerMinute), CoolantConnector (ReturnTemperatureControlCelsius), CoolantConnector (SupplyTemperatureControlCelsius), CoolantConnector (ValvePositionControlPercent), Pump (SpeedControlPercent)	object	The control loop details.
<b>ControlMode</b>	<i>various</i> (AutomationInstrumentation (NodeControl), AutomationInstrumentation (PID) ... )	string (enum)	The current operating mode of the control.
<b>Controls</b>	Chassis	object	The link to the collection of controls located in this chassis.
<b>ControlType</b>	Control	string (enum)	The type of control.

Property Name	Defined In Schema(s)	Type	Description
<b>Coolant</b>	CoolantConnector, CoolingUnit, Reservoir	object	Details about the coolant used in this unit.
	CoolingLoop	object	The coolant details for this cooling loop.
<b>CoolantConnectorRedundancy</b>	CoolingUnit	array	The redundancy information for the coolant connectors in this cooling unit.
	ThermalSubsystem	array	The redundancy information for the coolant connectors in this subsystem.
<b>CoolantConnectors</b>	ThermalSubsystem	object	A link to the coolant connectors for this equipment.
<b>CoolantConnectorType</b>	CoolantConnector	string (enum)	The type of coolant connector.
<b>CoolantLevelPercent</b>	CoolingLoop	object	The coolant capacity filled (percent).
<b>CoolantLevelStatus</b>	CoolingLoop	string (enum)	The status of the coolant level in this cooling loop.
<b>CoolantQuality</b>	CoolingLoop	string (enum)	The quality of the coolant.
<b>CoolantType</b>	CoolingLoop (Coolant)	string (enum)	The type of coolant.
<b>CooledBy</b>	Chassis (Links)	array	An array of links to resources or objects that cool this chassis. Normally, the link is for either a chassis or a specific set of fans.
	ComputerSystem (Links)	array	An array of links to resources or objects that cool this computer system. Normally, the link is for either a chassis or a specific set of fans.
<b>CoolingCapacityWatts</b>	CoolingUnit	integer	The cooling capacity (W) of this equipment.
<b>CoolingChassis</b>	Fan (Links)	array	An array of links to the chassis that are directly cooled by this fan.
<b>CoolingLoopName</b>	CoolantConnector	string	The name of the cooling loop attached to this interface.

Property Name	Defined In Schema(s)	Type	Description
<b>CoolingLoopRedundancy</b>	ThermalEquipment	array	The redundancy information for cooling loops attached to this equipment.
<b>CoolingLoops</b>	Facility (Links)	array	An array of links to the cooling loops in this facility.
	ThermalEquipment	object	A link to a collection of cooling loops.
<b>CoolingLoopType</b>	CoolingLoop	string (enum)	The type of cooling loop.
<b>CoolingManagerURI</b>	CoolantConnector, CoolingLoop	string	The link to the application that manages the cooling loop.
<b>CoolingUnitRedundancy</b>	CoolingUnit	array	The redundancy information for the groups of cooling units.
<b>CoolingUnits</b>	Chassis (Links)	array	An array of links to cooling unit functionality contained in this chassis.
<b>CoreCache</b>	ProcessorMetrics (CoreMetrics)	array	The cache metrics of this core in the processor.
<b>CoreCount</b>	OperatingConfig (BaseSpeedPrioritySettings)	integer	The number of cores to configure with a specified speed.
	ComputerSystem (ProcessorSummary)	integer	The number of processor cores in the system.
<b>CoreId</b>	ProcessorMetrics (CoreMetrics)	string	The processor core identifier.
<b>CoreIDs</b>	OperatingConfig (BaseSpeedPrioritySettings)	array	The identifier of the cores to configure with the specified speed.
<b>CoreMetrics</b>	ProcessorMetrics	array	The processor core metrics.
<b>CoreVoltage</b>	ProcessorMetrics	object	The core voltage (V) of this processor.
<b>CorrectableCoreErrorCount</b>	ProcessorMetrics (CoreMetrics), ProcessorMetrics	integer	The number of correctable core errors.
<b>CorrectableECCErrors</b>	MemoryMetrics (HealthData > AlarmTrips)	boolean	An indication of whether the correctable error threshold crossing alarm trip was detected.

Property Name	Defined In Schema(s)	Type	Description
	MemoryMetrics (CXL > AlertCapabilities)	boolean	Indicates whether correctable ECC errors generate an alert to the CXL Fabric Manager or host.
<b>CorrectableECCErrorCount</b>	ProcessorMetrics (CacheMetricsTotal > LifeTime)	integer	The number of correctable errors for the lifetime of the cache memory.
	StorageControllerMetrics	integer	The number of correctable errors for the lifetime of the memory of the storage controller.
	MemoryMetrics (LifeTime), SwitchMetrics (InternalMemoryMetrics > LifeTime)	integer	The number of correctable errors for the lifetime of the memory.
	ProcessorMetrics (CacheMetricsTotal > CurrentPeriod)	integer	The number of correctable errors of cache memory since reset or <code>ClearCurrentPeriod</code> action for this processor.
	SwitchMetrics (InternalMemoryMetrics > CurrentPeriod)	integer	The number of correctable errors of memory since reset.
	ManagerDiagnosticData (MemoryECCStatistics), MemoryMetrics (CurrentPeriod)	integer	The number of correctable errors since reset.
<b>CorrectableFECErrors</b>	PortMetrics (FibreChannel)	integer	The total number of correctable forward error correction (FEC) errors.
<b>CorrectableIOReadErrorCount</b>	DriveMetrics	integer	The number of correctable read errors for the lifetime of the drive.
<b>CorrectableIOWriteErrorCount</b>	DriveMetrics	integer	The number of correctable write errors for the lifetime of the drive.
<b>CorrectableOtherErrorCount</b>	ProcessorMetrics (CoreMetrics), ProcessorMetrics	integer	The number of correctable errors of all other components.
<b>CorrectableParityErrorCount</b>	StorageControllerMetrics	integer	The number of correctable parity errors for the lifetime of the memory of the storage controller.
<b>CorrectedPersistentErrorCount</b>	MemoryMetrics	integer	The number of corrected errors in persistent memory.
<b>CorrectedVolatileErrorCount</b>	MemoryMetrics	integer	The number of corrected errors in volatile memory.

Property Name	Defined In Schema(s)	Type	Description
<b>CorrectionInMs</b>	Power (PowerControl > PowerLimit)	integer (ms)	The time required for the limiting process to reduce power consumption to below the limit.
<b>Count</b>	ComputerSystem (ProcessorSummary)	integer	The number of physical processors in the system.
<b>Country</b>	Certificate (Issuer), Certificate (Subject)	string	The country of the organization of the entity.
	CertificateEnrollment (CSRParameters), CertificateService (Actions > GenerateCSR (Action))	string	The two-letter country code of the organization making the request.
<b>CPER</b>	Event (Events)	object	Details for a CPER section or record associated with this event.
	LogEntry	object	Details for a CPER section or record associated with this log entry.
<b>CPUCorePercent</b>	NetworkAdapterMetrics	number (%)	The device CPU core utilization as a percentage.
<b>CPUCount</b>	Container (Limits)	number	The number of processors available to this container.
<b>CPUOffload</b>	ComputerSystem (Virtualization)	boolean	An indication of whether the CPUs of the system is providing offload for virtualization. Examples of this are AMD-V, Intel VT-x, Intel VT-i, or ARM EL2.
<b>CRate</b>	BatteryMetrics	number	The rate at which the battery is charging or discharging, based on current in ampere units, relative to its rated maximum capacity in ampere-hour units. For example, 0.5 indicates it takes two hours to charge or discharge the battery based upon the current charge rate and capacity.
<b>Created</b>	LogEntry	string	The date and time when the log entry was created.
<b>CreatedBy</b>	OutletGroup	string	The creator of this outlet group.

Property Name	Defined In Schema(s)	Type	Description
	Job	string	The person or program that created this job entry.
<b>CreatedDate</b>	RegisteredClient	string	The date and time when the client entry was created.
<b>CreatedResources</b>	Task (Links)	array	An array of URIs referencing the resources created as the result of the operation that produced this task.
	Job (Links)	array	An array of URIs referencing the resources created as the result of this job.
<b>CreatedTime</b>	Session	string	The date and time when the session was created.
<b>CreateReplicaTarget (Action)</b>	Volume (Actions)	object	This action is used to create a new volume resource to provide expanded data protection through a replica relationship with the specified source volume.
<b>CreateTime</b>	ContainerImage	string	The date and time when the container image was created.
<b>CreationTime</b>	Job	string	The date and time when the job was created.
	JobDocument	string	The date and time when this job document resource was created.
<b>CredentialBootstrapping</b>	HostInterface	object	The credential bootstrapping settings for this interface.
<b>CredentialBootstrappingRole</b>	HostInterface (Links)	object	The link to the role that contains the privileges for the bootstrap account created for this interface.
<b>CrestFactor</b>	<i>various</i> (AutomationInstrumentation (CurrentAmps), AutomationInstrumentation (Voltage) ... )	number	The crest factor for this sensor.
<b>CriticalCircuit</b>	Circuit	boolean	Designates if this is a critical circuit.

Property Name	Defined In Schema(s)	Type	Description
<b>CriticalCompositeTempTimeMinutes</b>	StorageControllerMetrics (NVMeSMART)	integer	The amount of time in minutes that the controller has been operational and that the composite temperature has been greater than or equal to the critical composite temperature threshold.
<b>CriticalReactionType</b>	LeakDetector	string (enum)	The reaction to perform when a critical leak is detected.
<b>CriticalWarnings</b>	StorageControllerMetrics (NVMeSMART)	object	The NVMe SMART critical warnings.
<b>CSRParameters</b>	CertificateEnrollment	object	The certificate signing request parameters.
<b>CStateResidency</b>	ProcessorMetrics (CoreMetrics)	array	The C-state residency of this core in the processor.
<b>CurrentAmps</b>	PortMetrics (PoE)	number (A)	The current being delivered or consumed on this port.
	Circuit	object	The current (A) for this circuit.
	EnvironmentMetrics	object	The current (A) for this device.
	AutomationInstrumentation	object	The current (A) for this node.
	Outlet	object	The current (A) for this outlet.
	LeakDetector	object	The current (A) measurement for this leak detector.
<b>CurrentBandwidthGbps</b>	Switch	number (Gbit/s)	The current internal bandwidth of this switch.
<b>CurrentConfiguration</b>	NetworkAdapter (PortSplitting)	array	The current port splitting configuration for this controller.
<b>CurrentEncryptionKey</b>	Storage (Actions > SetEncryptionKey (Action))	string	The current local encryption key on the storage subsystem. This parameter is not needed if the controller does not currently have an encryption key.
<b>CurrentLinkSpeedMbps</b>	NetworkPort	integer (Mbit/s)	Network port current link speed.

Property Name	Defined In Schema(s)	Type	Description
<b>CurrentPassword</b>	Storage (Actions > SetControllerPassword (Action))	string	The current controller password. This parameter is not needed if the controller does not currently have a password.
<b>CurrentPeriod</b>	ProcessorMetrics (CacheMetricsTotal)	object	The cache metrics since the last reset or <code>ClearCurrentPeriod</code> action for this processor.
	SwitchMetrics (InternalMemoryMetrics)	object	The memory metrics since the last reset for this switch.
	MemoryMetrics	object	The memory metrics since the last reset or <code>ClearCurrentPeriod</code> action.
<b>CurrentPortConfigurationState</b>	Port (CXL)	string (enum)	The current port configuration state.
<b>CurrentProtocolVersion</b>	Port	string	The protocol version being sent over this port.
	PCIeDevice (CXLDevice)	string (enum)	The revision of the CXL specification in use by this device.
<b>CurrentSpeedGbps</b>	Port	number (Gbit/s)	The current speed of this port.
<b>CurrentValue</b>	AttributeRegistry (RegistryEntries > Attributes)	boolean, number, string	The placeholder of the current value for the attribute.
<b>Curve</b>	UpdateService (Actions > GenerateSSHIdentityKeyPair (Action))	string (enum)	The curve to use with the SSH key if the <code>KeyType</code> parameter contains <code>ECDSA</code> .
	AggregationSource (Actions > GenerateSSHIdentityKeyPair (Action))	string (enum)	The curve to use with the SSH key if the <code>KeyType</code> parameter contains <code>ECDSA</code> .
<b>CXL</b>	Memory	object	CXL properties for this memory device.
	Port	object	CXL properties for this port.
	Switch	object	CXL properties for this switch.
	MemoryMetrics	object	The memory metrics specific to CXL devices.
	PortMetrics	object	The port metrics specific to CXL ports.

Property Name	Defined In Schema(s)	Type	Description
<b>CXLDevice</b>	PCIeDevice	object	The CXL-specific properties of this PCIe device.
<b>CXLEntryType</b>	LogEntry	string (enum)	The specific CXL entry type.
<b>CXLLogicalDevice</b>	PCIeFunction (Links)	object	The link to the CXL logical device to which this function is assigned.
<b>CXLLogicalDevices</b>	MemoryChunks (Links)	array	An array of links to the CXL logical devices associated with this memory chunk.
	MemoryDomain (Links)	array	An array of links to the CXL logical devices associated with this memory domain.
	PCIeDevice	object	The link to the collection of CXL logical devices within this PCIe device.
<b>CXLReferenceDCMemory (Action)</b>	PCIeDevice (Actions)	object	Updates a reference to CXL dynamic capacity memory.
<b>Data</b>	StorageController (Actions > SecuritySend (Action))	string	The data to transfer.
	Drive (NVMe > ActivePersonalities), Storage (NVMeSubsystemProperties > ActivePersonalities)	string	The personality data.
<b>Databaseld</b>	SecureBootDatabase	string	This property contains the name of the UEFI Secure Boot database.
<b>DataBits</b>	SerialInterface	string (enum)	The number of data bits that follow the start bit over the serial connection.
<b>DataCenterBridging</b>	NetworkAdapter (Controllers > ControllerCapabilities)	object	Data center bridging (DCB) for this controller.
<b>DataLockCapable</b>	Memory (SecurityCapabilities)	boolean	An indication of whether this memory device supports data locking.
<b>DataLossDetected</b>	MemoryMetrics (HealthData)	boolean	An indication of whether data loss was detected.

Property Name	Defined In Schema(s)	Type	Description
<b>DataSourceUri</b>	<i>various</i> (AutomationInstrumentation (NodeControl), AutomationInstrumentation (PID) ... )	string	The link to the resource that provides the data for this control.
	LeakDetection (LeakDetectorGroups > Detectors)	string	The link to the resource that provides the data for this leak detector.
	<i>various</i> (AutomationInstrumentation (CurrentAmps), AutomationInstrumentation (TemperatureCelsius) ... )	string	The link to the resource that provides the data for this sensor.
<b>DataType</b>	ActionInfo (Parameters), JobDocument (ParameterMetadata)	string (enum)	The JSON property type for this parameter.
<b>DataUnitsRead</b>	StorageControllerMetrics (NVMeSMART)	integer	The number of 512 byte data units the host has read from the controller as part of processing a SMART Data Units Read Command in units of one thousand.
<b>DataUnitsWritten</b>	StorageControllerMetrics (NVMeSMART)	integer	The number of 512 byte data units the host has written to the controller as part of processing a User Data Out Command in units of one thousand.
<b>DataWidthBits</b>	Memory	integer	Data width in bits.
<b>DateCode</b>	Port (SFP)	string	The manufacturing date code for this SFP.
<b>DateTime</b>	JobService	string	The current date and time setting for the job service.
	LogService	string	The current date and time with UTC offset of the log service.
	Manager	string	The current date and time with UTC offset of the manager.
	TaskService	string	The current date and time, with UTC offset, setting that the task service uses.
<b>DateTimeLocalOffset</b>	LogService, Manager	string	The time offset from UTC that the <code>DateTime</code> property is in <code>+HH:MM</code> format.

Property Name	Defined In Schema(s)	Type	Description
<b>DateTimeSource</b>	Manager	string (enum)	The source of the date and time of this manager, such as NTP, RTC, or firmware.
<b>DaylightSavingTime</b>	Manager	object	The daylight saving time settings for this manager.
<b>DeadBand</b>	Control	number	The maximum deviation from the set point allowed before the control will activate.
<b>Decommission (Action)</b>	ComputerSystem (Actions)	object	This action decommissions a system.
<b>DecommissionTypes</b>	ComputerSystem (Actions > Decommission (Action))	array	The types of data to remove from the system.
<b>DedicatedNetworkPorts</b>	Manager	object	The dedicated network ports of the manager.
<b>DedicatedSpareDrives</b>	Volume (Links)	array	An array of references to the drives which are dedicated spares for this volume.
<b>Deduplicated</b>	Volume	boolean	Indicator of whether or not the Volume has deduplication enabled.
<b>DeduplicationSavingsBytes</b>	StorageMetrics	integer (bytes)	Current deduplication savings on the storage system in bytes.
<b>DeepOperations</b>	ServiceRoot (ProtocolFeaturesSupported)	object	The information about deep operations that the service supports.
<b>DeepPATCH</b>	ServiceRoot (ProtocolFeaturesSupported > DeepOperations)	boolean	An indication of whether the service supports the deep <code>PATCH</code> operation.
<b>DeepPOST</b>	ServiceRoot (ProtocolFeaturesSupported > DeepOperations)	boolean	An indication of whether the service supports the deep <code>POST</code> operation.
<b>Default</b>	Drive (NVMe > ActivePersonalities), Storage (NVMeSubsystemProperties > ActivePersonalities)	boolean	An indication of whether this personality is set to the manufacturing default values.
<b>DefaultRoutingEnabled</b>	Zone	boolean	This property indicates whether routing within this zone is enabled.

Property Name	Defined In Schema(s)	Type	Description
<b>DefaultSetPoint</b>	Control, EnvironmentMetrics (PowerLimitWatts)	number	The default set point of the control.
<b>DefaultValue</b>	AttributeRegistry (RegistryEntries > Attributes)	boolean, number, string	The default value for the attribute.
	ActionInfo (Parameters)	string	The default value for this parameter.
<b>DelayBetweenBatchesInSeconds</b>	Aggregate (Actions > Reset (Action)), AggregationService (Actions > Reset (Action))	integer (seconds)	The delay of the batches of elements being reset in seconds.
<b>DELETE</b>	PrivilegeRegistry (Mappings > OperationMap), PrivilegeRegistry (Mappings > PropertyOverrides > OperationMap), PrivilegeRegistry (Mappings > ResourceURIOverrides > OperationMap), PrivilegeRegistry (Mappings > SubordinateOverrides > OperationMap)	array	The privilege required to complete an HTTP <code>DELETE</code> operation.
<b>DeleteAllCompletedTasks (Action)</b>	TaskService (Actions)	object	Deletes all completed tasks.
<b>DeleteTargetVolume</b>	Volume (Actions > RemoveReplicaRelationship (Action))	boolean	Indicate whether or not to delete the target volume as part of the operation.
<b>DeliverBufferedEventDuration</b>	EventDestination (Actions > ResumeSubscription (Action))	string	The maximum age of buffered events that should be delivered when resuming the subscription.
<b>DeliveryRetryAttempts</b>	EventService	integer	The number of times that the <code>POST</code> of an event is retried before the subscription terminates or is suspended. This retry occurs at the service level, which means that the HTTP <code>POST</code> to the event destination fails with an HTTP <code>4XX</code> or <code>5XX</code> status code or an HTTP timeout occurs this many times before the event destination subscription terminates or is suspended.
<b>DeliveryRetryIntervalSeconds</b>	EventService	integer (seconds)	The interval, in seconds, between retry attempts for sending any event.

Property Name	Defined In Schema(s)	Type	Description
<b>DeliveryRetryPolicy</b>	EventDestination	string (enum)	The subscription delivery retry policy for events, where the subscription type is <code>RedfishEvent</code> .
<b>DeltaLiquidPressurekPa</b>	Filter	object	The differential pressure (kPa) across the liquid filter.
<b>DeltaPhysicalContext</b>	Thermal (Temperatures)	string (enum)	The area or device to which the <code>DeltaReadingCelsius</code> temperature measurement applies, relative to <code>PhysicalContext</code> .
<b>DeltaPressureControlkPa</b>	CoolantConnector	object	The desired differential pressure (kPa).
<b>DeltaPressurekPa</b>	CoolantConnector, ThermalMetrics	object	The differential pressure (kPa).
<b>DeltaReadingCelsius</b>	Thermal (Temperatures)	number (Celsius)	The delta temperature reading.
<b>DeltaTemperatureCelsius</b>	CoolantConnector	object	The differential temperature (C).
<b>DeltaTemperatureControlCelsius</b>	CoolantConnector	object	The desired differential temperature (C).
<b>DemandModeEnabled</b>	AddressPool (Ethernet > BFDSingleHopOnly)	boolean	Bidirectional Forwarding Detection (BFD) Demand Mode status.
<b>Denied</b>	SecurityPolicy (SPDM)	object	The SPDM policy settings that are prohibited, such as the prohibited SPDM versions and algorithms.
	SecurityPolicy (TLS > Client), SecurityPolicy (TLS > Server)	object	The TLS policy settings that are prohibited, such as the prohibited TLS versions and algorithms.
<b>DensityKgPerCubicMeter</b>	CoolingLoop (Coolant)	number (kg/m3)	The density (kg/m <sup>3</sup> ) of the coolant.
<b>Dependencies</b>	AttributeRegistry (RegistryEntries)	array	An array of dependencies of attributes on this component.
<b>Dependency</b>	AttributeRegistry (RegistryEntries > Dependencies)	object	The dependency expression for one or more attributes in this attribute registry.
<b>DependencyFor</b>	AttributeRegistry (RegistryEntries > Dependencies)	string	The <code>AttributeName</code> of the attribute whose change triggers the evaluation of this dependency expression.

Property Name	Defined In Schema(s)	Type	Description
<b>DepthMm</b>	Chassis	number (mm)	The depth of the chassis.
<b>DesiredMinTxIntervalMilliseconds</b>	AddressPool (Ethernet > BFDSingleHopOnly)	integer	Desired Bidirectional Forwarding Detection (BFD) minimal transmit interval.
<b>Destination</b>	Container (MountPoints)	string	The file system path in the container that is provided as the mount point to access the files and folders contained in the source path.
	EventDestination	string	The URI of the destination event receiver.
<b>DestinationPortLower</b>	AllowDeny	integer	The TCP, UDP, or other destination port to which this rule begins application, inclusive.
<b>DestinationPortUpper</b>	AllowDeny	integer	The TCP, UDP, or other destination port to which this rule ends application, inclusive.
<b>DestinationURIs</b>	Application	array	The URIs to which this application pushes data.
<b>DetachNamespaces (Action)</b>	StorageController (Actions)	object	This action detaches referenced namespaces or volumes from the storage controller. Detached namespaces and volumes are removed from the <code>AttachedVolumes</code> property in <code>Links</code> . For NVMe, namespaces are modeled as <code>Volume</code> resources.
<b>DetectionStatus</b>	Port (Ethernet > PoE)	string (enum)	The detection and delivery status of PoE on this port.
<b>Detectors</b>	LeakDetection (LeakDetectorGroups)	array	The leak detection states from all related leak detection devices in this group.
<b>DetectorState</b>	LeakDetection (LeakDetectorGroups > Detectors), LeakDetector	string (enum)	The state of the leak detector.
<b>DeviceClass</b>	PCIeFunction	string (enum)	The class for this PCIe function.

Property Name	Defined In Schema(s)	Type	Description
<b>DeviceEnabled</b>	NetworkDeviceFunction	boolean	An indication of whether the network device function is enabled.
<b>DeviceId</b>	Endpoint (ConnectedEntities > EntityPcId), Endpoint (PcId), PCIeFunction	string	The Device ID of this PCIe function.
<b>DeviceID</b>	Memory	string	Device ID.
<b>DeviceIsolation</b>	ComputerSystem (Virtualization)	boolean	An indication of whether the system is providing hardware support to isolate device I/O and DMA access. Examples of this are AMD-vi and Intel VT-d.
<b>DeviceLocator</b>	Memory	string	Location of the memory device in the platform.
<b>DeviceMaxCount</b>	NetworkAdapter (Controllers > ControllerCapabilities > VirtualizationOffload > VirtualFunction)	integer	The maximum number of virtual functions supported by this controller.
<b>DeviceName</b>	EnvironmentMetrics (FanSpeedsPercent), HeaterMetrics (TemperatureReadingsCelsius), LeakDetection (LeakDetectorGroups > Detectors), PowerSupplyMetrics (FanSpeedsPercent), ThermalMetrics (TemperatureReadingsCelsius)	string	The name of the device.
<b>DeviceNumber</b>	PCIeFunction	string	The device number of this PCIe function.
<b>Devices</b>	SimpleStorage	array	The storage devices.
<b>DeviceType</b>	PCIeDevice (CXLDevice)	string (enum)	The CXL device type.
	PCIeDevice	string (enum)	The device type for this PCIe device.
<b>DewPointCelsius</b>	EnvironmentMetrics	object	The dew point temperature (C).
<b>DewPointProximityCelsius</b>	CoolantConnector	object	The proximity of the coolant temperature to the dew point.
	EnvironmentMetrics	object	The proximity of the temperature to the dew point.

Property Name	Defined In Schema(s)	Type	Description
<b>DHCHAP</b>	Connection (ConnectionKeys)	object	The DHCHAP-specific permission key information for this connection.
<b>DHCP</b>	AddressPool (Ethernet > IPv4)	object	The Dynamic Host Configuration Protocol (DHCP) related addressing for this Ethernet fabric.
	ManagerNetworkProtocol	object	The settings for this manager's DHCPv4 protocol support.
<b>DHCPEnabled</b>	EthernetInterface (DHCPv4)	boolean	An indication of whether DHCP v4 is enabled on this Ethernet interface.
<b>DHCPInterfaceMTUBytes</b>	AddressPool (Ethernet > IPv4 > DHCP)	integer	Dynamic Host Configuration Protocol (DHCP) interface Maximum Transmission Unit (MTU).
<b>DHCPRelayEnabled</b>	AddressPool (Ethernet > IPv4 > DHCP)	boolean	Dynamic Host Configuration Protocol (DHCP) relay status.
<b>DHCPsServer</b>	AddressPool (Ethernet > IPv4 > DHCP)	array	The Dynamic Host Configuration Protocol (DHCP) IPv4 addresses for this Ethernet fabric.
<b>DHCPv4</b>	EthernetInterface	object	DHCPv4 configuration for this interface.
<b>DHCPv6</b>	EthernetInterface	object	DHCPv6 configuration for this interface.
	ManagerNetworkProtocol	object	The settings for this manager's DHCPv6 protocol support.
<b>DHGroupAllowList</b>	KeyPolicy (NVMeoF)	array	The Diffie-Hellman (DH) groups that this key policy allows.
<b>DiagnosticData</b>	Event (Events)	string	A Base64-encoded set of diagnostic data associated with this event.
	LogEntry	string	A Base64-encoded set of diagnostic data associated with this log entry.
<b>DiagnosticDataDetails</b>	LogService	array	The detailed information for the data collected with the <code>CollectDiagnosticData</code> action.
<b>DiagnosticDataType</b>	Event (Events), LogEntry	string (enum)	The type of data available in the <code>DiagnosticData</code> property or retrieved from the URI specified by the <code>AdditionalDataURI</code> property.

Property Name	Defined In Schema(s)	Type	Description
	LogService (DiagnosticDataDetails)	string (enum)	The type of diagnostic data to collect with the <code>CollectDiagnosticData</code> action.
	LogService (Actions > CollectDiagnosticData (Action))	string (enum)	The type of diagnostic data to collect.
<b>Differential</b>	AutomationInstrumentation (PID > ControlLoop), Control (ControlLoop), CoolantConnector (DeltaPressureControlkPa > ControlLoop), CoolantConnector (DeltaTemperatureControlCelsius > ControlLoop), CoolantConnector (FlowControlLitersPerMinute > ControlLoop), CoolantConnector (ReturnTemperatureControlCelsius > ControlLoop), CoolantConnector (SupplyTemperatureControlCelsius > ControlLoop), CoolantConnector (ValvePositionControlPercent > ControlLoop), Pump (SpeedControlPercent > ControlLoop)	number	The differential coefficient.
<b>Direction</b>	NetworkDeviceFunction (Limits)	string (enum)	Indicates the direction of the data to which this limit applies.
	AllowDeny	string (enum)	Indicates the direction of the data to which this permission applies.
<b>DirtyShutdownCount</b>	MemoryMetrics	integer	The number of shutdowns while outstanding writes have not completed to persistent memory.
<b>DisableMasterPassphrase (Action)</b>	Memory (Actions)	object	Disables the master passphrase for the given region.
<b>DisablePassphrase (Action)</b>	Memory (Actions)	object	Disable passphrase for the given region.
	CXLLogicalDevice (Actions)	object	Disables the passphrase for the CXL logical device.
<b>DischargeCycles</b>	BatteryMetrics	number	The number of discharges this battery has sustained.
<b>DiscoveryTransportServiceId</b>	StorageController (NVMeControllerProperties)	integer	The NVMe discovery transport service identifier for the discovery controller.

Property Name	Defined In Schema(s)	Type	Description
<b>DiscreteTriggerCondition</b>	Triggers	string (enum)	The conditions for a discrete metric trigger.
<b>DiscreteTriggers</b>	Triggers	array	The list of discrete triggers.
<b>DiscreteValues</b>	MetricDefinition	array	This array property specifies possible values of a discrete metric.
<b>DisplayName</b>	MemoryChunks	string	A user-configurable string to name the memory chunk.
	Volume	string	A user-configurable string to name the volume.
	BootOption	string	The user-readable display name of the boot option that appears in the boot order list in the user interface.
	AttributeRegistry (RegistryEntries > Attributes)	string	The user-readable display string for the attribute in the defined language.
	AttributeRegistry (RegistryEntries > Menus)	string	The user-readable display string of this menu in the defined language.
<b>DisplayOrder</b>	AttributeRegistry (RegistryEntries > Attributes)	integer	The ascending order, as a number, in which this attribute appears relative to other attributes.
	AttributeRegistry (RegistryEntries > Menus)	integer	The ascending order, as a number, in which this menu appears relative to other menus.
<b>DisplayString</b>	Certificate (Issuer), Certificate (Subject)	string	A human-readable string for this identifier.
<b>DistanceExternal</b>	AddressPool (Ethernet > EBGp > BGpRoute), AddressPool (Ethernet > MultiProtocolEBGp > BGpRoute), AddressPool (Ethernet > MultiProtocolIBGp > BGpRoute)	integer	Route distance for external routes.
<b>DistanceInternal</b>	AddressPool (Ethernet > EBGp > BGpRoute), AddressPool (Ethernet > MultiProtocolEBGp > BGpRoute), AddressPool (Ethernet > MultiProtocolIBGp > BGpRoute)	integer	Route distance for internal routes.

Property Name	Defined In Schema(s)	Type	Description
<b>DistanceLocal</b>	AddressPool (Ethernet > EBGp > BGPRoute), AddressPool (Ethernet > MultiProtocolEBGP > BGPRoute), AddressPool (Ethernet > MultiProtocolIBGP > BGPRoute)	integer	Route distance for local routes.
<b>DistributeIntoUnderlayEnabled</b>	AddressPool (Ethernet > IPv4)	boolean	Indicates if host subnets should be distributed into the fabric underlay.
<b>DistributionCircuits</b>	Outlet (Links)	array	An array of links to mains or input circuits powered by this outlet.
	Circuit (Links)	array	An array of links to the circuits powered by this circuit.
<b>DNSDomainName</b>	AddressPool (Ethernet > IPv4)	string	The Domain Name Service (DNS) domain name for this Ethernet fabric.
<b>DNSServer</b>	AddressPool (Ethernet > IPv4)	array	The Domain Name Service (DNS) servers for this Ethernet fabric.
<b>DocumentBasedJobs</b>	JobService (ServiceCapabilities)	boolean	An indication of whether document-based jobs are supported.
<b>DocumentData</b>	JobDocument	string	The job document data as a Base64-encoded string.
<b>DocumentDataHash</b>	JobDocument	string	The hash of the job document data.
<b>DocumentDataURI</b>	JobDocument	string	The URI at which to access the job document data.
<b>DocumentType</b>	JobDocument	string	The type of job document data associated with this job document.
<b>DomainComponents</b>	Certificate (Issuer), Certificate (Subject)	array	The domain components of the entity.
<b>DomainID</b>	Switch	integer	The domain ID for this switch.
<b>Doors</b>	Chassis	object	The doors or access panels of the chassis.
<b>DoorState</b>	Chassis (Doors > Front), Chassis (Doors > Rear)	string (enum)	The state of the door.
<b>DownloadRawLog (Action)</b>	LogService (Actions)	object	The action to download a raw log for this log service.

Property Name	Defined In Schema(s)	Type	Description
<b>DownloadURI</b>	License	string	The URI from which to download the license file.
<b>DownstreamChassis</b>	Cable (Links)	array	An array of links to the downstream chassis connected to this cable.
<b>DownstreamConnectorTypes</b>	Cable	array	The connector types this cable supports.
<b>DownstreamName</b>	Cable	string	The identifier for the downstream resource.
<b>DownstreamPorts</b>	Cable (Links)	array	An array of links to the downstream ports connected to this cable.
<b>DownstreamResources</b>	Cable (Links)	array	An array of links to the downstream resources connected to this cable.
<b>DriveEncryptionKey</b>	Storage (Actions > ImportForeignDrives (Action))	string	The encryption key to unlock the drives.
<b>DriveEncryptionKeyIdentifier</b>	Storage (Actions > ImportForeignDrives (Action))	string	An encryption key identifier to filter the drives that are imported. If not provided, the controller attempts to import all foreign drives.
<b>DriveFormFactor</b>	Drive	string (enum)	The form factor of the drive inserted in this slot.
<b>DriverVersion</b>	GraphicsController	string	The version of the graphics controller driver loaded in the operating system.
<b>Drives</b>	ResourceBlock	array	An array of links to the drives available in this resource block.
	Chassis (Links)	array	An array of links to the drives located in this chassis.
	PCleFunction (Links)	array	An array of links to the drives that this PCIe function produces.
	Volume (Links)	array	An array of references to the drives which contain this volume. This will reference Drives that either wholly or only partly contain this volume.
	Volume (Actions > ChangeRAIDLAYOUT (Action))	array	An array of the drives to be used by the volume.

Property Name	Defined In Schema(s)	Type	Description
	Storage	array	The set of drives attached to the storage controllers that this resource represents.
	Chassis	object	The link to the collection of drives within this chassis.
<b>DwellTime</b>	Triggers (DiscreteTriggers)	string	The amount of time that a trigger event persists before the metric action is performed.
	Triggers (NumericThresholds > LowerCritical), Triggers (NumericThresholds > LowerWarning), Triggers (NumericThresholds > UpperCritical), Triggers (NumericThresholds > UpperWarning)	string	The duration the metric value must violate the threshold before the threshold is activated.
	Sensor (Thresholds > LowerCaution), Sensor (Thresholds > LowerCautionUser), Sensor (Thresholds > LowerCritical), Sensor (Thresholds > LowerCriticalUser), Sensor (Thresholds > LowerFatal), Sensor (Thresholds > UpperCaution), Sensor (Thresholds > UpperCautionUser), Sensor (Thresholds > UpperCritical), Sensor (Thresholds > UpperCriticalUser), Sensor (Thresholds > UpperFatal)	string	The duration the sensor value must violate the threshold before the threshold is activated.
<b>DynamicCapacity</b>	PCleDevice (CXLDevice)	object	The CXL dynamic capacity device (DCD) information for this CXL device.
<b>DynamicCapacityAdd (Action)</b>	CXLLogicalDevice (Actions)	object	Adds dynamic capacity to this CXL logical device.
<b>DynamicCapacityRelease (Action)</b>	CXLLogicalDevice (Actions)	object	Releases dynamic capacity from this CXL logical device.
<b>EABKey</b>	CertificateEnrollment (ACME)	string	The external account binding (EAB) key value.
<b>EABKeyId</b>	CertificateEnrollment (ACME)	string	The external account binding (EAB) key identifier.

Property Name	Defined In Schema(s)	Type	Description
<b>EBGP</b>	AddressPool (Ethernet)	object	External BGP (eBGP) related properties for this Ethernet fabric.
<b>EBGPAddressRange</b>	AddressPool (Ethernet > IPv4)	object	External BGP (eBGP) related addressing for this Ethernet fabric.
<b>ECCModeEnabled</b>	Processor (MemorySummary)	boolean	An indication of whether memory ECC mode is enabled for this processor.
<b>EEEEnabled</b>	NetworkPort	boolean	An indication of whether IEEE 802.3az Energy-Efficient Ethernet (EEE) is enabled for this network port.
	Port (Ethernet)	boolean	Indicates whether IEEE 802.3az Energy-Efficient Ethernet (EEE) is enabled on this port.
<b>EffectiveFamily</b>	Processor (ProcessorId)	string	The effective family for this processor.
<b>EffectiveModel</b>	Processor (ProcessorId)	string	The effective model for this processor.
<b>EfficiencyPercent</b>	Power (PowerSupplies)	number (%)	The measured efficiency of this power supply as a percentage.
	PowerSupply (EfficiencyRatings)	number (%)	The rated efficiency of this power supply at the specified load.
<b>EfficiencyRatings</b>	PowerSupply	array	The efficiency ratings of this power supply.
<b>EGCriticalWarningSummary</b>	StorageControllerMetrics (NVMeSMART)	object	The Endurance Group critical warnings summary.
<b>EgressIdentifier</b>	RouteSetEntry	integer	The egress interface identifier.
<b>EgressModeratePercentage</b>	Port (CXL > Congestion)	integer (%)	The threshold for moderate egress port congestion as a percentage.
<b>EgressPortBackpressureSupported</b>	CXLLogicalDevice (QoSTelemetryCapabilities)	boolean	Indicates whether the device supports the CXL Specification-defined 'Egress Port Backpressure' mechanism.
	Port (CXL > QoSTelemetryCapabilities)	boolean	Indicates whether the port supports the CXL Specification-defined 'Egress Port Backpressure' mechanism.

Property Name	Defined In Schema(s)	Type	Description
<b>EgressPortCongestionSupport</b>	PCIeDevice (CXLDevice)	boolean	Indicates whether the CXL device supports egress port congestion management.
<b>EgressSeverePercentage</b>	Port (CXL > Congestion)	integer (%)	The threshold for severe egress port congestion as a percentage.
<b>EjectMedia (Action)</b>	VirtualMedia (Actions)	object	This action detaches remote media from virtual media.
<b>EjectPolicy</b>	VirtualMedia	string (enum)	The ejection policy for the virtual media.
<b>EjectTimeout</b>	VirtualMedia	string	Timeout value before the virtual media is automatically ejected.
<b>ElectricalBuses</b>	Facility (Links)	array	An array of links to the electrical buses in this facility.
	PowerDomain (Links)	array	An array of links to the electrical buses in this power domain.
	PowerEquipment	object	The link to a collection of electrical buses.
<b>ElectricalConsumerNames</b>	Circuit	array	An array of names of downstream devices that are powered by this circuit.
	Outlet	array	An array of names of downstream devices that are powered by this outlet.
<b>ElectricalContext</b>	Circuit, Outlet, Sensor	string (enum)	The combination of current-carrying conductors.
<b>ElectricalSourceManagerURI</b>	Circuit	string	The URI of the management interface for the upstream electrical source connection for this circuit.
<b>ElectricalSourceManagerURIs</b>	Chassis	array	The URIs of the management interfaces for the external electrical source connections for this chassis.
	PowerSupply	array	The URIs of the management interfaces for the upstream electrical source connections for this power supply.

Property Name	Defined In Schema(s)	Type	Description
<b>ElectricalSourceName</b>	Circuit	string	The name of the upstream electrical source, such as a circuit or outlet, connected to this circuit.
<b>ElectricalSourceNames</b>	Chassis	array	The names of the external electrical sources, such as circuits or outlets, connected to this chassis.
	PowerSupply	array	The names of the upstream electrical sources, such as circuits or outlets, connected to this power supply.
<b>Elements</b>	Aggregate (Actions > AddElements (Action))	array	An array of resource links to add to the <code>Elements</code> array.
	Aggregate (Actions > RemoveElements (Action))	array	An array of resource links to remove from the <code>Elements</code> array.
	Aggregate	array	The elements of this aggregate.
<b>ElementsCount</b>	Aggregate	integer	The number of entries in the <code>Elements</code> array.
<b>Email</b>	CertificateEnrollment (ACME)	string	The email address for ACME account registration.
	CertificateEnrollment (CSRParameters), CertificateService (Actions > GenerateCSR (Action))	string	The email address of the contact within the organization making the request.
	Certificate (Issuer), Certificate (Subject)	string	The email address of the contact within the organization of the entity.
<b>EmailAddress</b>	License (Contact)	string	Email address for this contact.
	ManagerAccount	string	The email address associated with this account.
<b>EmailAttribute</b>	AccountService (ActiveDirectory > LDAPService > SearchSettings), AccountService (LDAP > LDAPService > SearchSettings), AccountService (OAuth2 > LDAPService > SearchSettings), AccountService (TACACSplus > LDAPService > SearchSettings), ExternalAccountProvider (LDAPService > SearchSettings)	string	The attribute name that contains the LDAP user's email address.

Property Name	Defined In Schema(s)	Type	Description
<b>EnableAfterReset</b>	HostInterface (CredentialBootstrapping)	boolean	An indication of whether credential bootstrapping is enabled after a reset for this interface.
<b>Enabled</b>	ManagerAccount	boolean	An indication of whether an account is enabled. An administrator can disable it without deleting the user information. If <code>true</code> , the account is enabled and the user can log in. If <code>false</code> , the account is disabled and, in the future, the user cannot log in.
	AddressPool (Ethernet > EBGp > BGPNeighbor), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor)	boolean	An indication of whether BGP neighbor communication is enabled.
	AccountService (MultiFactorAuth > ClientCertificate)	boolean	An indication of whether client certificate authentication is enabled.
	HostInterface (CredentialBootstrapping)	boolean	An indication of whether credential bootstrapping is enabled for this interface.
	ComputerSystem (IdlePowerSaver)	boolean	An indication of whether idle power saver is enabled.
	AccountService (MultiFactorAuth > OneTimePasscode)	boolean	An indication of whether multi-factor authentication using a one-time passcode is enabled.
	AccountService (MultiFactorAuth > TimeBasedOneTimePassword)	boolean	An indication of whether multi-factor authentication with a Time-based One-Time Password (TOTP) is enabled.
	AccountService (MultiFactorAuth > GoogleAuthenticator)	boolean	An indication of whether multi-factor authentication with Google Authenticator is enabled.
	AccountService (MultiFactorAuth > MicrosoftAuthenticator)	boolean	An indication of whether multi-factor authentication with Microsoft Authenticator is enabled.
	AccountService (MultiFactorAuth > SecurID)	boolean	An indication of whether multi-factor authentication with RSA SecurID is enabled.

Property Name	Defined In Schema(s)	Type	Description
	SecurityPolicy (SPDM)	boolean	An indication of whether SPDM communication with devices is enabled.
	CertificateEnrollment	boolean	An indication of whether this automatic certificate enrollment is enabled.
	Memory	boolean	An indication of whether this memory is enabled.
	PCIeFunction	boolean	An indication of whether this PCIe device function is enabled.
	Port	boolean	An indication of whether this port is enabled.
	Processor	boolean	An indication of whether this processor is enabled.
	Switch	boolean	An indication of whether this switch is enabled.
	ManagerNetworkProtocol (Proxy)	boolean	Indicates if the manager uses the proxy server.
	Port (Ethernet > PoE)	boolean	Indicates whether PoE is enabled on this port.
	LeakDetector	boolean	Indicates whether the leak detector is enabled and provides a status.
	Sensor	boolean	Indicates whether the sensor is enabled and provides a reading.
<b>EnableSNMPv1</b>	ManagerNetworkProtocol (SNMP)	boolean	Indicates if access via SNMPv1 is enabled.
<b>EnableSNMPv2c</b>	ManagerNetworkProtocol (SNMP)	boolean	Indicates if access via SNMPv2c is enabled.
<b>EnableSNMPv3</b>	ManagerNetworkProtocol (SNMP)	boolean	Indicates if access via SNMPv3 is enabled.
<b>Enclosures</b>	Storage (Links)	array	An array of links to the chassis to which this storage subsystem is attached.
<b>Encrypted</b>	Volume	boolean	Is this Volume encrypted.

Property Name	Defined In Schema(s)	Type	Description
<b>EncryptionAbility</b>	Drive	string (enum)	The encryption ability of this drive.
<b>EncryptionKey</b>	AccountService (ActiveDirectory > Authentication), AccountService (LDAP > Authentication), AccountService (OAuth2 > Authentication), AccountService (TACACSPplus > Authentication), ExternalAccountProvider (Authentication)	string	Specifies the encryption key.
	Storage (Actions > SetEncryptionKey (Action))	string	The local encryption key to set on the storage subsystem.
	AggregationSource (SNMP), EventDestination (SNMP)	string	The secret authentication key for SNMPv3.
	ManagerAccount (SNMP)	string	The secret encryption key used in SNMPv3.
<b>EncryptionKeyIdentifier</b>	Storage (Actions > SetEncryptionKey (Action))	string	The local encryption key identifier used by the storage subsystem.
<b>EncryptionKeySet</b>	AccountService (ActiveDirectory > Authentication), AccountService (LDAP > Authentication), AccountService (OAuth2 > Authentication), AccountService (TACACSPplus > Authentication), AggregationSource (SNMP), EventDestination (SNMP), ExternalAccountProvider (Authentication), ManagerAccount (SNMP)	boolean	Indicates if the <code>EncryptionKey</code> property is set.
<b>EncryptionMode</b>	Storage	string (enum)	The encryption mode of this storage subsystem.
<b>EncryptionPassphrase</b>	ComputerSystem (Actions > ExportConfiguration (Action)), CoolingUnit (Actions > ExportConfiguration (Action)), PowerDistribution (Actions > ExportConfiguration (Action))	string	The encryption passphrase for the exported file.
<b>EncryptionProtocol</b>	AggregationSource (SNMP), EventDestination (SNMP), ManagerAccount (SNMP)	string (enum)	The encryption protocol for SNMPv3.

Property Name	Defined In Schema(s)	Type	Description
	ManagerNetworkProtocol (SNMP)	string (enum)	The encryption protocol used for SNMPv3 access to this manager.
<b>EncryptionStatus</b>	Drive	string (enum)	The status of the encryption of this drive.
<b>EncryptionTypes</b>	Volume	array	The types of encryption used by this Volume.
<b>EndDateTime</b>	Manager (DaylightSavingTime)	string	The end date and time with UTC offset of daylight saving time.
<b>EndingPhysicalPort</b>	NetworkAdapter (PortSplitting > CurrentConfiguration), NetworkAdapter (PortSplitting > SupportedConfigurations > Subconfigurations)	integer	The last physical port to which this subconfiguration applies.
<b>Endpoint</b>	Zone (Actions > AddEndpoint (Action))	object	The endpoint to add to the zone.
	Zone (Actions > RemoveEndpoint (Action))	object	The endpoint to remove from the zone.
<b>EndpointETag</b>	Zone (Actions > AddEndpoint (Action))	string	The current ETag of the endpoint to add to the zone.
	Zone (Actions > RemoveEndpoint (Action))	string	The current ETag of the endpoint to remove from the system.
<b>EndpointGroups</b>	Storage	object	All of the endpoint groups, each of which contains a set of endpoints that are used for a common purpose such as an ACL or logical identification, that belong to this storage subsystem.
	Fabric	object	The collection of links to the endpoint groups that this fabric contains.
<b>EndpointProtocol</b>	Endpoint	string (enum)	The protocol supported by this endpoint.
<b>Endpoints</b>	NetworkDeviceFunction (Links)	array	An array of links to endpoints associated with this network device function.
	CXLLogicalDevice (Links)	array	An array of links to the endpoints associated with this CXL logical device.

Property Name	Defined In Schema(s)	Type	Description
	Memory (Links)	array	An array of links to the endpoints associated with this memory.
	AccelerationFunction (Links)	array	An array of links to the endpoints that connect to this acceleration function.
	Storage (StorageControllers > Links), StorageController (Links)	array	An array of links to the endpoints that connect to this controller.
	Drive (Links)	array	An array of links to the endpoints that connect to this drive.
	EthernetInterface (Links)	array	An array of links to the endpoints that connect to this Ethernet interface.
	MediaController (Links)	array	An array of links to the endpoints that connect to this media controller.
	MemoryChunks (Links)	array	An array of links to the endpoints that connect to this memory chunk.
	Processor (Links)	array	An array of links to the endpoints that connect to this processor.
	Switch (Links)	array	An array of links to the endpoints that connect to this switch.
	ComputerSystem (Links)	array	An array of links to the endpoints that connect to this system.
	FabricAdapter (Links)	array	An array of links to the endpoints that represent the logical fabric connection to this fabric adapter.
	AddressPool (Links)	array	An array of links to the endpoints that this address pool contains.
	EndpointGroup, EndpointGroup (Links)	array	The endpoints in this endpoint group.
	VirtualPCI2PCIBridge (Links)	array	The links to the endpoints associated with this vPPB.
	VirtualCXLSwitch (Links)	array	The links to the endpoints designated for this Virtual CXL Switch.
	Zone (Links)	array	The links to the endpoints that this zone contains.

Property Name	Defined In Schema(s)	Type	Description
	Fabric	object	The collection of links to the endpoints that this fabric contains.
<b>EndpointURI</b>	OutboundConnection	string	The URI of the WebSocket connection to the remote client.
<b>EndTime</b>	Job	string	The date and time when the job was completed.
	Task	string	The date and time when the task was completed. This property will only appear when the task is complete.
<b>EndToEndCRCERrors</b>	PortMetrics (GenZ)	integer	The total number of ECRC transient errors detected.
<b>EnergyJoules</b>	EnvironmentMetrics	object	Energy consumption (J).
<b>EnergykWh</b>	ThermalMetrics	object	Energy consumption (kWh) of the thermal management subsystem.
	EnvironmentMetrics, PowerDistributionMetrics	object	Energy consumption (kWh).
	Circuit	object	The energy (kWh) for this circuit.
	OutletGroup	object	The energy (kWh) for this outlet group.
	Outlet	object	The energy (kWh) for this outlet.
	PowerSupplyMetrics	object	The energy consumption (kWh) of this unit.
<b>EnergyStorageType</b>	Battery	string (enum)	The type of energy storage technology used in the battery.
<b>EnforcePasswordHistoryCount</b>	AccountService	integer	The number of unique new passwords that need to be associated with a user account before a previous password is accepted when modifying the password. If 0, a user does not need to provide a unique new password.
<b>EngineeringChangeLevel</b>	Assembly (Assemblies)	string	The engineering change level of the assembly.
<b>Engineld</b>	ManagerNetworkProtocol (SNMP)	object	The engine ID.

Property Name	Defined In Schema(s)	Type	Description
<b>EnrolledCertificate</b>	CertificateEnrollment (Links)	object	The link to the enrolled certificate.
<b>EnrolledCertificateLocation</b>	CertificateEnrollment (Links)	object	The link to the certificate collection where the enrolled certificate will be installed.
<b>EnrollmentCACertificates</b>	CertificateService	object	The link to a collection of server certificates for the automatic certificate enrollment servers.
<b>EnrollmentState</b>	CertificateEnrollment	object	The status information for this enrollment.
<b>EnrollmentType</b>	CertificateEnrollment	string (enum)	The configured automatic certificate enrollment protocol.
<b>EnrollmentTypes</b>	CertificateService (AutomaticCertificateEnrollment)	array	The automatic enrollment protocols supported by this service.
<b>EnterDwellTimeSeconds</b>	ComputerSystem (IdlePowerSaver)	integer (seconds)	The duration in seconds the computer system is below the <code>EnterUtilizationPercent</code> value before the idle power save is activated.
<b>EnterpriseSpecificMethod</b>	ManagerNetworkProtocol (SNMP > EngineId)	string	The enterprise-specific method.
<b>EnterUtilizationPercent</b>	ComputerSystem (IdlePowerSaver)	number (%)	The percentage of utilization when the computer system enters idle power save. If the computer system's utilization goes below this value, it enters idle power save.
<b>EntitlementId</b>	License	string	The entitlement identifier for this license.
<b>Entity</b>	PrivilegeRegistry (Mappings)	string	The resource name, such as <code>Manager</code> .
<b>EntityLink</b>	Endpoint (ConnectedEntities)	object	The link to the associated entity.
<b>EntityPcId</b>	Endpoint (ConnectedEntities)	object	The PCI ID of the connected entity.
<b>EntityRole</b>	Endpoint (ConnectedEntities)	string (enum)	The role of the connected entity.
<b>EntityType</b>	Endpoint (ConnectedEntities)	string (enum)	The type of the connected entity.
<b>Entries</b>	LogService	object	The link to the log entry collection.

Property Name	Defined In Schema(s)	Type	Description
<b>EntryCode</b>	LogEntry	string (enum)	The entry code for the log entry if the entry type is <code>SEL</code> .
<b>EntryType</b>	LogEntry	string (enum)	The type of log entry.
<b>EnvironmentalClass</b>	Chassis	string (enum)	The ASHRAE Environmental Class for this chassis.
<b>EnvironmentMetrics</b>	Chassis	object	The link to the environment metrics for this chassis.
	Drive	object	The link to the environment metrics for this drive.
	CoolingUnit	object	The link to the environment metrics for this equipment.
	Facility	object	The link to the environment metrics for this facility.
	MediaController	object	The link to the environment metrics for this media controller.
	Memory	object	The link to the environment metrics for this memory.
	NetworkAdapter	object	The link to the environment metrics for this network adapter.
	PCIeDevice	object	The link to the environment metrics for this PCIe device.
	Port	object	The link to the environment metrics for this port or any attached small form-factor pluggable (SFP) device.
	Processor	object	The link to the environment metrics for this processor.
	StorageController	object	The link to the environment metrics for this storage controller.
	Switch	object	The link to the environment metrics for this switch.
<b>EquipmentType</b>	CoolingUnit, PowerDistribution	string (enum)	The type of equipment this resource represents.

Property Name	Defined In Schema(s)	Type	Description
<b>ERate</b>	BatteryMetrics	number	The rate at which the battery is charging or discharging, based on power in watt units, relative to its rated maximum capacity in watt-hour units. For example, <code>0.5</code> indicates it takes two hours to charge or discharge the battery based upon the current charge rate and capacity.
<b>ErrorCorrection</b>	Memory	string (enum)	Error correction scheme supported for this memory device.
<b>ESINumberRange</b>	AddressPool (Ethernet > BGPEvpn)	object	The Ethernet Segment Identifier (ESI) number range for the fabric.
<b>EstimatedCompletionTime</b>	Job	string	The date and time when the job is expected to complete.
<b>EstimatedDuration</b>	Job	string	The estimated total time required to complete the job.
	Task	string	The estimated total time required to complete the task.
	LogService (DiagnosticDataDetails)	string	The estimated total time required to generate the data with the <code>CollectDiagnosticData</code> action.
<b>EstimatedSizeBytes</b>	LogService (DiagnosticDataDetails)	integer	The estimated size of the data collected by <code>CollectDiagnosticData</code> action.
<b>Ethernet</b>	Port	object	Ethernet properties for this port.
	NetworkDeviceFunction	object	The Ethernet capabilities, status, and configuration values for this network device function.
	Processor (FPGA > ExternalInterfaces), Processor (FPGA > HostInterface), Processor (SystemInterface)	object	The Ethernet-related information for this interface.
	AddressPool	object	The Ethernet-related properties for this address pool.
	NetworkDeviceFunctionMetrics	object	The network function metrics specific to Ethernet adapters.

Property Name	Defined In Schema(s)	Type	Description
<b>EthernetInterface</b>	NetworkDeviceFunction (Links)	object	The link to a virtual Ethernet interface that was created when one of the network device function VLANs is represented as a virtual NIC for the purpose of showing the IP address associated with that VLAN.
<b>EthernetInterfaces</b>	ResourceBlock	array	An array of links to the Ethernet interfaces available in this resource block.
	PCleFunction (Links)	array	An array of links to the Ethernet interfaces that this PCIe function produces.
	Port (Links)	array	The links to the Ethernet interfaces this port provides.
	NetworkDeviceFunction (Links)	array	The system Ethernet interfaces that use this network device function. This includes physical Ethernet interfaces or VLANs. Each member of this property is subordinate a <code>ComputerSystem</code> resource.
	NetworkDeviceFunction (Ethernet)	object	The Ethernet interface collection that contains the interfaces on this network device function.
	Manager	object	The link to a collection of NICs that this manager uses for network communication.
	Container	object	The link to the collection of Ethernet interfaces associated with this container.
	ComputerSystem	object	The link to the collection of Ethernet interfaces associated with this system.
<b>EthernetInterfaceType</b>	EthernetInterface	string (enum)	The type of interface.
<b>EventFormatType</b>	EventService (SSEFilterPropertiesSupported)	boolean	An indication of whether the service supports filtering by the <code>EventFormatType</code> property.

Property Name	Defined In Schema(s)	Type	Description
	EventDestination	string (enum)	The content types of the message that are sent to the <code>EventDestination</code> .
<b>EventFormatTypes</b>	EventService	array	The content types of the message that this service can send to the event destination.
<b>EventGroupId</b>	LogEntry	integer	An identifier that correlates events with the same cause.
	EventService (Actions > SubmitTestEvent (Action))	integer	The group identifier for the event.
	Event (Events)	integer	The identifier that correlates events with the same root cause. If <code>0</code> , no other event is related to this event.
<b>EventId</b>	EventService (Actions > SubmitTestEvent (Action))	string	The ID for the event to add.
	LogEntry	string	The unique instance identifier for an event.
	Event (Events)	string	The unique instance identifier of an event.
<b>Events</b>	Event	array	Each event in this array has a set of properties that describe the event. Because this is an array, more than one event can be sent simultaneously.
<b>EventService</b>	ServiceRoot	object	The link to the event service.
<b>EventTimestamp</b>	EventService (Actions > SubmitTestEvent (Action))	string	The date and time for the event to add.
	LogEntry	string	The date and time when the event occurred.
	Event (Events)	string	The time the event occurred.
<b>EventTriggers</b>	Triggers	array	The array of <code>MessageId</code> values that specify when a trigger condition is met based on an event.
<b>EventType</b>	EventService (SSEFilterPropertiesSupported)	boolean	An indication of whether the service supports filtering by the <code>EventTypes</code> property.

Property Name	Defined In Schema(s)	Type	Description
	EventService (Actions > SubmitTestEvent (Action))	string (enum)	The type for the event to add.
	LogEntry	string (enum)	The type of event recorded in this log.
	Event (Events)	string (enum)	The type of event.
<b>EventTypes</b>	EventDestination	array	The types of events that are sent to the destination.
<b>EventTypesForSubscription</b>	EventService	array	The types of events to which a client can subscribe.
<b>EVINumberRange</b>	AddressPool (Ethernet > BGPEvpn)	object	The Ethernet Virtual Private Network (EVPN) Instance number (EVI) number range for the fabric.
<b>Example</b>	MessageRegistry	string	An example of the message including values for all message arguments.
<b>ExcerptQuery</b>	ServiceRoot (ProtocolFeaturesSupported)	boolean	An indication of whether the service supports the <code>excerpt</code> query parameter.
<b>ExcludeAddresses</b>	ManagerNetworkProtocol (Proxy)	array	Addresses that do not require the proxy server to access.
<b>ExcludeMessageId</b>	EventService	boolean	An indication of whether the service supports filtering by the <code>ExcludeMessageIds</code> property.
<b>ExcludeMessageIds</b>	EventDestination	array	The list of <code>MessageId</code> values that are not sent to this event destination.
<b>ExcludeRegistryPrefix</b>	EventService	boolean	An indication of whether the service supports filtering by the <code>ExcludeRegistryPrefixes</code> property.
<b>ExcludeRegistryPrefixes</b>	EventDestination	array	The list of prefixes for the message registries that contain the <code>MessageId</code> values that are not sent to this event destination.
<b>ExcludeTargets</b>	UpdateService (Actions > SimpleUpdate (Action))	array	An array of URIs that indicate where not to apply the update image.

Property Name	Defined In Schema(s)	Type	Description
<b>ExecutingJobs</b>	JobExecutor (Links)	array	Links to jobs this executor is running.
<b>Executor</b>	Job (Links)	object	A link to the executor that is running this job.
<b>ExecutorType</b>	JobExecutor	string	The primary type of job this executor processes.
<b>Exhaust</b>	ThermalMetrics (TemperatureSummaryCelsius)	object	The exhaust temperature (in degree Celsius units) of this subsystem.
<b>ExitDwellTimeSeconds</b>	ComputerSystem (IdlePowerSaver)	integer (seconds)	The duration in seconds the computer system is above the <code>ExitUtilizationPercent</code> value before the idle power save is stopped.
<b>ExitUtilizationPercent</b>	ComputerSystem (IdlePowerSaver)	number (%)	The percentage of utilization when the computer system exits idle power save. If the computer system's utilization goes above this value, it exits idle power save.
<b>ExpandAll</b>	ServiceRoot (ProtocolFeaturesSupported > ExpandQuery)	boolean	An indication of whether the service supports the asterisk ( * ) option of the <code>\$expand</code> query parameter.
<b>ExpandQuery</b>	ServiceRoot (ProtocolFeaturesSupported)	object	The information about the use of <code>\$expand</code> in the service.
<b>ExpirationDate</b>	RegisteredClient	string	The date and time when the client entry will expire.
	License	string	The date and time when the license expires.
<b>ExpirationTime</b>	Session	string	The date and time when the session expires regardless of session activity.
<b>ExportConfiguration (Action)</b>	ComputerSystem (Actions)	object	This action exports the configuration of a system in a vendor-specific format.
	CoolingUnit (Actions), PowerDistribution (Actions)	object	This action exports the configuration of the equipment in a vendor-specific format.

Property Name	Defined In Schema(s)	Type	Description
<b>ExportType</b>	ComputerSystem (Actions > ExportConfiguration (Action)), CoolingUnit (Actions > ExportConfiguration (Action)), PowerDistribution (Actions > ExportConfiguration (Action))	string (enum)	The types of export to perform.
<b>ExtentLink</b>	MemoryRegion (MemoryExtents)	object	The link to the memory extent.
<b>ExtentList</b>	CXLLogicalDevice (Actions > DynamicCapacityAdd (Action))	array	The array of links to memory extents to add.
	CXLLogicalDevice (Actions > DynamicCapacityRelease (Action))	array	The array of links to memory extents to release.
<b>ExtentOffsetMiB</b>	MemoryRegion (MemoryExtents)	integer (mebibytes)	Offset of the memory extent within the memory region in mebibytes (MiB).
	MemoryExtent	integer (mebibytes)	The offset of the memory extent in the device address range in mebibytes (MiB).
<b>ExtentsCount</b>	MemoryRegion	integer	The number of extents defined for this memory region.
<b>ExtentSizeMiB</b>	MemoryRegion (MemoryExtents)	integer (mebibytes)	Size of the memory extent in mebibytes (MiB).
	MemoryExtent	integer (mebibytes)	The size of the memory extent in mebibytes (MiB).
<b>ExternalAccessibility</b>	Zone	string (enum)	Indicates accessibility of endpoints in this zone to endpoints outside of this zone.
<b>ExternalCompareRouterIdEnabled</b>	AddressPool (Ethernet > EBGp > BGpRoute), AddressPool (Ethernet > MultiProtocolEBGp > BGpRoute), AddressPool (Ethernet > MultiProtocolIBGp > BGpRoute)	boolean	Compare router identifier status.
<b>ExternalInterfaces</b>	Processor (FPGA)	array	An array of the FPGA external interfaces.

Property Name	Defined In Schema(s)	Type	Description
<b>ExternallyAccessible</b>	HostInterface	boolean	An indication of whether external entities can access this interface. External entities are non-host entities. For example, if the host and manager are connected through a switch and the switch also exposes an external port on the system, external clients can also use the interface, and this property value is <code>true</code> .
<b>FabricAdapters</b>	MemoryDomain (Links)	array	An array of links to the fabric adapters that present this memory domain to a fabric.
	Processor (Links)	array	An array of links to the fabric adapters that present this processor to a fabric.
	ComputerSystem	object	The link to the collection of fabric adapters associated with this system.
	Chassis	object	The link to the collection of fabric adapters located in this chassis that provide access to fabric-related resource pools.
<b>FabricLinkAddressRange</b>	AddressPool (Ethernet > IPv4)	object	Link-related IPv4 addressing for this Ethernet fabric typically applied to connections between spine and leaf Ethernet switches.
<b>FabricName</b>	Port (FibreChannel)	string	The Fibre Channel Fabric Name provided by the switch.
<b>Fabrics</b>	ServiceRoot	object	The link to a collection of fabrics.
<b>FabricType</b>	FabricAdapter	string (enum)	The configured fabric type of this fabric adapter.
	Fabric	string (enum)	The protocol being sent over this fabric.
<b>FabricTypeCapabilities</b>	FabricAdapter	array	An array of fabric types supported by this fabric adapter.
<b>Facilities</b>	ServiceRoot	object	The link to a collection of facilities.

Property Name	Defined In Schema(s)	Type	Description
<b>Facility</b>	CoolingLoop (Links), CoolingUnit (Links), PowerDistribution (Links)	object	A link to the facility that contains this equipment.
	Chassis (Links)	object	The link to the facility that contains this chassis.
<b>FacilityType</b>	Facility	string (enum)	The type of location this resource represents.
<b>FactoryConfiguration</b>	SoftwareInventory (AdditionalVersions)	string	The version of the configuration that contains the factory default runtime configuration parameters of this software.
<b>FailurePredicted</b>	Drive	boolean	An indication of whether this drive currently predicts a failure in the near future.
<b>FallbackAddress</b>	EthernetInterface (DHCPv4)	string (enum)	DHCPv4 fallback address method for this interface.
<b>Family</b>	Processor	string	The processor family.
<b>FanDiameterMm</b>	Fan	integer (mm)	The diameter of the fan assembly in millimeter units.
<b>FanName</b>	Thermal (Fans)	string	The name of the fan.
<b>FanRedundancy</b>	ThermalSubsystem	array	The redundancy information for the groups of fans in this subsystem.
<b>Fans</b>	Chassis (Links)	array	An array of links to the fans that cool this chassis.
	Thermal	array	The set of fans for this chassis.
	ThermalSubsystem	object	The link to the collection of fans within this subsystem.
<b>FansFullSpeedOverrideEnable</b>	ThermalSubsystem	boolean	An indication of whether the fans in this equipment are overridden to operate at full speed.
<b>FanSpeedPercent</b>	PowerSupplyMetrics	object	The fan speed (percent) for this power supply.
<b>FanSpeedsPercent</b>	EnvironmentMetrics, PowerSupplyMetrics	array	Fan speeds (percent).
<b>FCFabricName</b>	NetworkPort	string	The FC Fabric Name provided by the switch.

Property Name	Defined In Schema(s)	Type	Description
<b>FCoEActiveVLANId</b>	NetworkDeviceFunction (FibreChannel)	integer	The active FCoE VLAN ID.
<b>FCoELocalVLANId</b>	NetworkDeviceFunction (FibreChannel)	integer	The locally configured FCoE VLAN ID.
<b>FCPortConnectionType</b>	NetworkPort	string (enum)	The connection type of this port.
<b>Feeders</b>	PowerDistribution	object	A link to the feeder circuits for this equipment.
<b>FiberConnectionType</b>	Port (SFP)	string (enum)	The type of fiber connection currently used by this transceiver.
<b>FibreChannel</b>	Port	object	Fibre Channel properties for this port.
	NetworkDeviceFunction	object	The Fibre Channel capabilities, status, and configuration values for this network device function.
	PortMetrics	object	The Fibre Channel-specific port metrics for network ports.
	NetworkDeviceFunctionMetrics	object	The network function metrics specific to Fibre Channel adapters.
<b>FibreChannelId</b>	NetworkDeviceFunction (FibreChannel)	string	The Fibre Channel ID that the switch assigns for this interface.
<b>FileSystems</b>	Storage	object	All file systems that are allocated by this storage subsystem.
<b>FilterQuery</b>	ServiceRoot (ProtocolFeaturesSupported)	boolean	An indication of whether the service supports the <code>\$filter</code> query parameter.
<b>FilterQueryComparisonOperations</b>	ServiceRoot (ProtocolFeaturesSupported)	boolean	An indication of whether the service supports the <code>eq</code> , <code>ge</code> , <code>gt</code> , <code>le</code> , <code>lt</code> , and <code>ne</code> options for the <code>\$filter</code> query parameter.
<b>FilterQueryCompoundOperations</b>	ServiceRoot (ProtocolFeaturesSupported)	boolean	An indication of whether the service supports the <code>()</code> , <code>and</code> , <code>not</code> , and <code>or</code> options for the <code>\$filter</code> query parameter.
<b>FilterRedundancy</b>	CoolingUnit	array	The redundancy information for the groups of filters in this unit.

Property Name	Defined In Schema(s)	Type	Description
<b>Filters</b>	Pump, Reservoir	object	A link to a collection of filters.
	CoolingUnit, ThermalSubsystem	object	A link to the filters for this equipment.
<b>Fingerprint</b>	Key (SSH)	string	A fingerprint of the key.
	Certificate	string	The fingerprint of the certificate.
<b>FingerprintHashAlgorithm</b>	Certificate	string	The hash algorithm for the fingerprint of the certificate.
<b>FirmwareApiVersion</b>	Memory	string	Version of API supported by the firmware.
<b>FirmwareAuthEnabled</b>	HostInterface	boolean	An indication of whether this firmware authentication is enabled for this interface.
<b>FirmwareAuthRole</b>	HostInterface (Links)	object	The link to the Redfish role that has firmware authentication privileges on this host interface.
<b>FirmwareAuthRoleId</b>	HostInterface	string	The Redfish role used for firmware authentication on this interface.
<b>FirmwareCommit</b>	Drive (NVMe > ConfigurationLockState), Storage (NVMeSubsystemProperties > ConfigurationLockState)	string (enum)	The lock state of the NVMe-defined Firmware Commit command.
<b>FirmwareId</b>	Processor (FPGA)	string	The FPGA firmware identifier.
<b>FirmwareImageDownload</b>	Drive (NVMe > ConfigurationLockState), Storage (NVMeSubsystemProperties > ConfigurationLockState)	string (enum)	The lock state of the NVMe-defined Firmware Image Download command.
<b>FirmwareInventory</b>	UpdateService	object	An inventory of firmware.
<b>FirmwareManufacturer</b>	Processor (FPGA)	string	The FPGA firmware manufacturer.
<b>FirmwarePackageVersion</b>	NetworkAdapter (Controllers)	string	The version of the user-facing firmware package.
<b>FirmwareRevision</b>	Memory	string	Revision of firmware on the memory controller.
<b>FirmwareTimeSeconds</b>	ManagerDiagnosticData (BootTimeStatistics)	number	The number of seconds the manager spent in the firmware stage.

Property Name	Defined In Schema(s)	Type	Description
<b>FirmwareVersion</b>	AttributeRegistry (SupportedSystems)	string	Firmware version.
	Battery	string	The firmware version for this battery.
	Drive	string	The firmware version for this drive.
	Power (PowerSupplies), PowerSupply	string	The firmware version for this power supply.
	Processor	string	The firmware version of the processor.
	CoolingUnit, PowerDistribution, Pump	string	The firmware version of this equipment.
	FabricAdapter	string	The firmware version of this fabric adapter.
	Manager	string	The firmware version of this manager.
	Storage (StorageControllers), StorageController	string	The firmware version of this storage controller.
	Switch	string	The firmware version of this switch.
	ComputerSystem (TrustedModules)	string	The firmware version of this Trusted Module.
	Processor (FPGA)	string	The FPGA firmware version.
	TrustedComponent	string	The software version of the active software image on the trusted component.
	PCleDevice	string	The version of firmware for this PCIe device.
<b>FirmwareVersion2</b>	ComputerSystem (TrustedModules)	string	The second firmware version of this Trusted Module, if applicable.
<b>FirstLane</b>	Port	integer	The first lane that this port is configured to use.
<b>FirstOverflowTimestamp</b>	LogEntry	string	The timestamp of the first overflow captured after this log entry.

Property Name	Defined In Schema(s)	Type	Description
<b>FirstSubportId</b>	NetworkAdapter (PortSplitting > CurrentConfiguration), NetworkAdapter (PortSplitting > SupportedConfigurations > Subconfigurations)	integer	The first identifier to assign to subports in this subconfiguration. Subport identifiers are assigned sequentially to the subports starting with those for <code>StartPort</code> and working through to those for <code>EndPort</code> .
<b>FlapDampingEnabled</b>	AddressPool (Ethernet > EBGp > BGpRoute), AddressPool (Ethernet > MultiProtocolEBGp > BGpRoute), AddressPool (Ethernet > MultiProtocolIBGp > BGpRoute)	boolean	Route flap dampening status.
<b>FloorPDUs</b>	Facility (Links)	array	An array of links to the floor power distribution units in this facility.
	PowerDomain (Links)	array	An array of links to the floor power distribution units in this power domain.
	PowerEquipment	object	A link to a collection of floor power distribution units.
<b>FlowControl</b>	SerialInterface	string (enum)	The type of flow control, if any, that is imposed on the serial connection.
<b>FlowControlConfiguration</b>	NetworkPort	string (enum)	The locally configured 802.3x flow control setting for this network port.
	Port (Ethernet)	string (enum)	The locally configured 802.3x flow control setting for this port.
<b>FlowControlLitersPerMinute</b>	CoolantConnector	object	The desired liquid flow rate (L/min).
<b>FlowControlStatus</b>	NetworkPort	string (enum)	The 802.3x flow control behavior negotiated with the link partner for this network port (Ethernet-only).
	Port (Ethernet)	string (enum)	The 802.3x flow control behavior negotiated with the link partner for this port.
<b>FlowLitersPerMinute</b>	CoolantConnector	object	The liquid flow (L/min).
<b>FluidLevelPercent</b>	Reservoir	object	The fluid capacity filled (percent).
<b>FluidLevelStatus</b>	Reservoir	string (enum)	The status of the fluid level in this reservoir.

Property Name	Defined In Schema(s)	Type	Description
<b>FMReference</b>	PCIeDevice (Actions > CXLReferenceDCMemory (Action))	boolean	Indicates whether a CXL Fabric Manager is referencing the memory extents with the specified tag.
<b>FMReferencedExtent</b>	MemoryExtent	boolean	An indication of whether this memory extent is referenced by the CXL Fabric Manager.
<b>ForceAutomaticRenew (Action)</b>	Certificate (Actions)	object	This action forces an automatic renewal of the certificate, if this certificate is configured for automatic certificate enrollment.
<b>ForcedRemoval</b>	CXLLogicalDevice (Actions > DynamicCapacityRelease (Action))	boolean	Indicates whether to perform a forced removal of the dynamic capacity.
<b>ForceEnable (Action)</b>	Volume (Actions)	object	Request system force the volume to an enabled state regardless of data loss.
<b>ForceFailover (Action)</b>	Manager (Actions)	object	The <code>ForceFailover</code> action forces a failover of this manager to the manager used in the parameter.
<b>ForceStart (Action)</b>	Job (Actions)	object	Forces the job to start.
<b>ForceUpdate</b>	UpdateService (HttpPushUriOptions)	boolean	An indication of whether the service should bypass update policies when applying the <code>HttpPushUri</code> -provided image.
	UpdateService (Actions > SimpleUpdate (Action))	boolean	An indication of whether the service should bypass update policies when applying the provided image. The default is <code>false</code> .
<b>FormattedLBASize</b>	Volume (NVMeNamespaceProperties)	string	The LBA data size and metadata size combination that the namespace has been formatted with.
<b>FPGA</b>	Processor	object	The properties for processors of the FPGA type.
<b>FpgaReconfigurationSlots</b>	AccelerationFunction	array	An array of the reconfiguration slot identifiers of the FPGA that this acceleration function occupies.

Property Name	Defined In Schema(s)	Type	Description
<b>FpgaType</b>	Processor (FPGA)	string (enum)	The FPGA type.
<b>FQDN</b>	EthernetInterface	string	The complete, fully qualified domain name that DNS obtains for this interface.
	ManagerNetworkProtocol	string	The fully qualified domain name for the manager obtained by DNS including the host name and top-level domain name.
<b>FreeBytes</b>	ManagerDiagnosticData (MemoryStatistics)	integer (bytes)	The amount of free memory in bytes.
<b>FreePool</b>	CompositionService	object	The link to the collection of resource blocks within the free pool. Resource blocks in the free pool are not contributing to any composed resources.
<b>FreeStorageSpaceKiB</b>	ManagerDiagnosticData	integer (KiBy)	The available storage space on this manager in kibibytes (KiB).
<b>FreezePersonality (Action)</b>	Drive (Actions), Storage (Actions)	object	This action freezes a personality for the NVMe subsystem.
<b>FreezeSecurityState (Action)</b>	CXLLogicalDevice (Actions)	object	Freezes the security state of the CXL logical device.
	Memory (Actions)	object	Freezes the security state of the memory device.
<b>FrequencyHz</b>	Circuit	object	The frequency (Hz) for this circuit.
	Outlet	object	The frequency (Hz) for this outlet.
	PowerSupplyMetrics	object	The frequency (Hz) for this power supply.
<b>FrequencyRatio</b>	ProcessorMetrics	number	The frequency relative to the nominal processor frequency ratio.
<b>FromAddress</b>	EventService (SMTP)	string	The 'from' email address of the outgoing email.
<b>Front</b>	Chassis (Doors)	object	The front door of the chassis.

Property Name	Defined In Schema(s)	Type	Description
<b>Frozen</b>	Drive (NVMe > ActivePersonalities), Storage (NVMeSubsystemProperties > ActivePersonalities)	boolean	An indication of whether this personality is frozen.
<b>FTP</b>	ManagerNetworkProtocol	object	The settings for this manager's FTP protocol support.
<b>FTPS</b>	ManagerNetworkProtocol	object	The settings for this manager's FTP over SSL (FTPS) protocol support that apply to all system instances controlled by this manager.
<b>FullDuplex</b>	EthernetInterface	boolean	An indication of whether full-duplex mode is enabled on the Ethernet connection for this interface.
<b>FunctionClasses</b>	Memory	array	Function classes by the memory device.
<b>FunctionEnabled</b>	ComputerSystem (HostWatchdogTimer)	boolean	An indication of whether a user has enabled the host watchdog timer functionality. This property indicates only that a user has enabled the timer. To activate the timer, installation of additional host-based software is necessary; an update to this property does not initiate the timer.
<b>FunctionId</b>	PCleFunction	integer	The PCIe function number.
<b>FunctionMaxBandwidth</b>	Port	array	An array of maximum bandwidth allocation percentages for the functions associated with this port.
<b>FunctionMinBandwidth</b>	Port	array	An array of minimum bandwidth allocation percentages for the functions associated with this port.
<b>FunctionNumber</b>	Endpoint (ConnectedEntities > EntityPcild), Endpoint (Pcild)	integer	The PCI ID of the connected entity.
	PCleFunction	string	The function number of this PCIe function.
<b>FunctionProtocol</b>	PCleFunction	string (enum)	The PCIe function protocol.

Property Name	Defined In Schema(s)	Type	Description
<b>FunctionType</b>	PCleFunction	string (enum)	The type of the PCIe function.
<b>GatewayIPAddress</b>	AddressPool (Ethernet > BGPEvpn), AddressPool (Ethernet > IPv4)	string	The gateway IPv4 address.
<b>GatewayIPAddressRange</b>	AddressPool (Ethernet > BGPEvpn)	object	The IPv4 address range for gateways.
<b>GCID</b>	Endpoint (ConnectedEntities > GenZ)	object	The Global Component ID (GCID) for the entity.
<b>GCXLID</b>	VirtualPCI2PCIBridge	string	The GCXLID for the CXL logical device bound to this vPPB.
<b>GenerateCSR (Action)</b>	CertificateService (Actions)	object	This action makes a certificate signing request.
<b>GeneratedMetricReportValues</b>	TelemetryService (Actions > SubmitTestMetricReport (Action))	array	The contents of the <code>MetricReportValues</code> in the generated metric report.
<b>GenerateSecretKey (Action)</b>	ManagerAccount (Actions)	object	This action randomly generates a new secret key for Time-based One-Time Password (TOTP) multi-factor authentication for this account.
<b>GenerateSSHIdentityKeyPair (Action)</b>	UpdateService (Actions)	object	This action generates a new SSH identity key-pair to be used with the <code>UpdateService</code> resource. The generated public key is stored in the <code>key</code> resource referenced by the <code>PublicIdentitySSHKey</code> property. Any existing key-pair is deleted and replaced by the new key-pair.
	AggregationSource (Actions)	object	This action generates a new SSH identity key-pair to be used with this aggregation source. The generated public key is stored in the <code>key</code> resource referenced by the <code>PublicIdentityKey</code> property in <code>SSHSettings</code> . Any existing key-pair is deleted and replaced by the new key-pair.
<b>Generation</b>	Port (UALink)	string (enum)	The UALink Data Link Layer/ Physical Layer generation of this port.

Property Name	Defined In Schema(s)	Type	Description
<b>GeneratorId</b>	LogEntry	string	An identifier of the device that has generated the IPMI SEL Event Record.
<b>GenZ</b>	Port	object	Gen-Z specific properties.
	Endpoint (ConnectedEntities)	object	The Gen-Z related properties for the entity.
	AddressPool	object	The Gen-Z related properties for this address pool.
	FabricAdapter	object	The Gen-Z specific properties for this fabric adapter.
	Connection (ConnectionKeys)	object	The Gen-Z-specific permission key information for this connection.
	PortMetrics	object	The port metrics specific to Gen-Z ports.
<b>GET</b>	PrivilegeRegistry (Mappings > OperationMap), PrivilegeRegistry (Mappings > PropertyOverrides > OperationMap), PrivilegeRegistry (Mappings > ResourceURIOverrides > OperationMap), PrivilegeRegistry (Mappings > SubordinateOverrides > OperationMap)	array	The privilege required to complete an HTTP <code>GET</code> operation.
<b>GetPersonalityNonce (Action)</b>	Drive (Actions), Storage (Actions)	object	This action obtains a nonce required to unfreeze personalities with a programmed key.
<b>GivenName</b>	CertificateEnrollment (CSRParameters), CertificateService (Actions > GenerateCSR (Action))	string	The given name of the user making the request.
<b>GoogleAuthenticator</b>	AccountService (MultiFactorAuth)	object	The settings related to Google Authenticator multi-factor authentication. For generic Time-Based One-Time Password (TOTP) multi-factor authentication, use the <code>TimeBasedOneTimePassword</code> property.

Property Name	Defined In Schema(s)	Type	Description
<b>GracefulRestart</b>	AddressPool (Ethernet > EBGp), AddressPool (Ethernet > MultiProtocolEBGP), AddressPool (Ethernet > MultiProtocolIBGP)	object	Graceful restart related properties.
<b>GracefulRestartEnabled</b>	AddressPool (Ethernet > EBGp > GracefulRestart), AddressPool (Ethernet > MultiProtocolEBGP > GracefulRestart), AddressPool (Ethernet > MultiProtocolIBGP > GracefulRestart)	boolean	Border Gateway Protocol (BGP) graceful restart status.
<b>GracePeriodDays</b>	License	integer	The grace days of this license.
<b>GraphicalConsole</b>	ComputerSystem	object	The information about the graphical console (KVM-IP) service of this system.
	Manager	object	The manager's graphical console service.
<b>GraphicsController</b>	Processor (Links)	object	A link to the graphics controller associated with this processor.
<b>GraphicsControllers</b>	ComputerSystem	object	The link to a collection of graphics controllers that can output video for this system.
<b>GrayOut</b>	AttributeRegistry (RegistryEntries > Attributes)	boolean	An indication of whether this attribute is grayed out. A grayed-out attribute is not active and is grayed out in user interfaces but the attribute value can be modified.
	AttributeRegistry (RegistryEntries > Menus)	boolean	An indication of whether this menu is grayed out. A grayed-only menu is not accessible in user interfaces.
<b>GroupName</b>	LeakDetection (LeakDetectorGroups)	string	The name of this leak detector group.

Property Name	Defined In Schema(s)	Type	Description
<b>GroupNameAttribute</b>	AccountService (ActiveDirectory > LDAPService > SearchSettings), AccountService (LDAP > LDAPService > SearchSettings), AccountService (OAuth2 > LDAPService > SearchSettings), AccountService (TACACsplus > LDAPService > SearchSettings), ExternalAccountProvider (LDAPService > SearchSettings)	string	The attribute name that contains the LDAP group name entry.
<b>GroupsAttribute</b>	AccountService (ActiveDirectory > LDAPService > SearchSettings), AccountService (LDAP > LDAPService > SearchSettings), AccountService (OAuth2 > LDAPService > SearchSettings), AccountService (TACACsplus > LDAPService > SearchSettings), ExternalAccountProvider (LDAPService > SearchSettings)	string	The attribute name that contains the groups for a user on the LDAP user entry.
<b>GroupType</b>	EndpointGroup	string (enum)	The endpoint group type.
<b>HardwareInterfaceVendorID</b>	TrustedComponent (TPM)	string	The hardware interface vendor ID for this trusted component.
<b>HardwareManagedCoherencyRegion</b>	MemoryRegion	boolean	An indication of whether the device manages the cache coherency across hosts for this memory region.
<b>HardwareVersion</b>	Drive	string	The hardware version of this drive.
<b>HDMDecoders</b>	VirtualCXLSwitch	integer	The number of HDM (Host Device Memory) decoders present in this Virtual CXL Switch.
	Switch (CXL > VCS)	integer	The number of Host Device Memory (HDM) Decoders supported by this switch.

Property Name	Defined In Schema(s)	Type	Description
<b>HEAD</b>	PrivilegeRegistry (Mappings > OperationMap), PrivilegeRegistry (Mappings > PropertyOverrides > OperationMap), PrivilegeRegistry (Mappings > ResourceURIOverrides > OperationMap), PrivilegeRegistry (Mappings > SubordinateOverrides > OperationMap)	array	The privilege required to complete an HTTP HEAD operation.
<b>HealthData</b>	Memory	object	The health data of this memory device.
	MemoryMetrics	object	The health information of the memory.
<b>HealthRollup</b>	ServiceConditions	string (enum)	The health roll-up for all resources.
<b>HeartbeatIntervalMinutes</b>	EventDestination	integer	Interval for sending heartbeat events to the destination in minutes.
<b>Heaters</b>	ThermalSubsystem	object	The link to the collection of heaters within this subsystem.
<b>HeaterSummary</b>	ThermalMetrics	object	The summary of heater metrics for this chassis.
<b>HeatExchangers</b>	ThermalEquipment	object	A link to a collection of heat exchanger units.
<b>HeatingCoolingEquipmentNames</b>	Chassis	array	The names of the external heating or cooling equipment, such as coolant distribution units, connected to this chassis.
<b>HeatingCoolingManagerURIs</b>	Chassis	array	The URIs of the management interfaces for the external heating or cooling equipment for this chassis.
<b>HeatRemovedkW</b>	CoolantConnector	object	The heat removed (kW) through this connector.
<b>HeightMm</b>	Chassis	number (mm)	The height of the chassis.
<b>HeightRackUnits</b>	Chassis	number	The height of the rack-mountable chassis in rack units.

Property Name	Defined In Schema(s)	Type	Description
<b>HelperModeEnabled</b>	AddressPool (Ethernet > EBGp > GracefulRestart), AddressPool (Ethernet > MultiProtocolEBGP > GracefulRestart), AddressPool (Ethernet > MultiProtocolIBGP > GracefulRestart)	boolean	Graceful restart helper mode status.
<b>HelpText</b>	AttributeRegistry (RegistryEntries > Attributes)	string	The help text for the attribute.
<b>Hidden</b>	AttributeRegistry (RegistryEntries > Attributes)	boolean	An indication of whether this attribute is hidden in user interfaces.
	AttributeRegistry (RegistryEntries > Menus)	boolean	An indication of whether this menu is hidden in user interfaces.
<b>HideCommunityStrings</b>	ManagerNetworkProtocol (SNMP)	boolean	Indicates if the community strings should be hidden.
	EventDestination (SNMP)	boolean	Indicates whether the SNMP trap community string is hidden in responses.
<b>HidePayload</b>	JobDocument (Actions > SubmitJob (Action))	boolean	An indication of whether the contents of the parameters should be hidden from view after the job has been created. If <code>true</code> , responses do not return the parameters. If <code>false</code> , responses return the parameters. If this parameter is not present when the job is created, the default is <code>false</code> .
	Task	boolean	An indication of whether the contents of the payload are hidden from view after the task has been created. If <code>true</code> , responses do not return the payload. If <code>false</code> , responses return the payload. If this property is not present when the task is created, the default is <code>false</code> .

Property Name	Defined In Schema(s)	Type	Description
	Job	boolean	An indication of whether the contents of the payload or parameters should be hidden from view after the job has been created. If <code>true</code> , responses do not return the payload or parameters. If <code>false</code> , responses return the payload or parameters. If this property is not present when the job is created, the default is <code>false</code> .
<b>HighSpeedCoreIDs</b>	Processor	array	The list of core identifiers corresponding to the cores that have been configured with the higher clock speed from the operating configuration applied to this processor.
<b>HitRatio</b>	ProcessorMetrics (Cache), ProcessorMetrics (CoreMetrics > CoreCache)	number	The cache line hit ratio.
<b>HoldTimeSeconds</b>	AddressPool (Ethernet > EBGp > BGPNeighbor), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor)	integer	Border Gateway Protocol (BGP) hold timer in seconds.
<b>HopCount</b>	RouteSetEntry	integer	The number of hops.
<b>HostAddressRange</b>	AddressPool (Ethernet > IPv4)	object	IPv4-related host subnet addressing for physical device endpoints that connect to this Ethernet fabric.
<b>HostBootstrapAccount</b>	ManagerAccount	boolean	An indication of whether this account is a bootstrap account for the host interface.
<b>HostBusRXPercent</b>	NetworkAdapterMetrics	number (%)	The host bus, such as PCIe, RX utilization as a percentage.
<b>HostBusTXPercent</b>	NetworkAdapterMetrics	number (%)	The host bus, such as PCIe, TX utilization as a percentage.
<b>HostDevice</b>	Port	string (enum)	The current host device for this port.
<b>HostedServices</b>	ComputerSystem	object	The services that this computer system supports.

Property Name	Defined In Schema(s)	Type	Description
<b>HostEthernetInterfaces</b>	HostInterface	object	A link to the collection of network interface controllers or cards (NICs) that a computer system uses to communicate with this host interface.
<b>HostingComputerSystem</b>	ComputerSystem (Links)	object	The link to the system that is hosting this virtual machine.
<b>HostingRole</b>	ComputerSystem (HostingRoles)	string (enum)	The enumerations of <code>HostingRole</code> specify different features that the hosting computer system supports.
<b>HostingRoles</b>	ComputerSystem	array	The hosting roles that this computer system supports.
<b>HostingStorageSystems</b>	Storage (Links)	array	The storage systems that host this storage subsystem.
<b>HostInterface</b>	Processor (FPGA)	object	The FPGA interface to the host.
	EthernetInterface (Links)	object	The link to a Host Interface that is associated with this Ethernet interface.
<b>HostInterfaces</b>	Manager	object	The link to a collection of host interfaces that this manager uses for local host communication. Clients can find host interface configuration options and settings in this navigation property.
<b>HostInterfaceType</b>	HostInterface	string (enum)	The host interface type for this interface.
<b>HostKeyld</b>	Key (NVMeoF)	string	The identifier of the host key paired with this target key.
<b>HostName</b>	ManagerNetworkProtocol	string	The DNS host name of this manager, without any domain information.
	ComputerSystem, EthernetInterface	string	The DNS host name, without any domain information.
	AggregationSource	string	The URI of the system to be accessed.

Property Name	Defined In Schema(s)	Type	Description
<b>HostReadCommands</b>	StorageControllerMetrics (NVMeSMART)	integer	The number of SMART Host Read Commands completed by the controller.
<b>HostReservationMemoryBytes</b>	Endpoint	integer (bytes)	The amount of memory in bytes that the host should allocate to connect to this endpoint.
<b>HostWatchdogTimer</b>	ComputerSystem	object	The host watchdog timer functionality for this system.
<b>HostWriteCommands</b>	StorageControllerMetrics (NVMeSMART)	integer	The number of User Data Out Commands completed by the controller.
<b>HotKeySequenceDisplay</b>	ComputerSystem (SerialConsole > IPMI), ComputerSystem (SerialConsole > SSH), ComputerSystem (SerialConsole > Telnet)	string	The hotkey sequence available for the user to exit the serial console session.
<b>HotPluggable</b>	Chassis	boolean	An indication of whether this component can be inserted or removed while the equipment is in operation.
	Battery, Fan, Filter, Heater, Power (PowerSupplies), PowerSupply, Thermal (Fans)	boolean	An indication of whether this device can be inserted or removed while the equipment is in operation.
	PCIeDevice (Slot), PCIeSlots (Slots)	boolean	An indication of whether this PCIe slot supports hotplug.
<b>HotspareActivationPolicy</b>	Storage	string (enum)	The policy under which hot spare drives in this storage domain will activate.
<b>HotspareReplacementMode</b>	Drive	string (enum)	The replacement mode for the hot spare drive.
<b>HotspareType</b>	Drive	string (enum)	The type of hot spare that this drive serves as.
<b>HTTP</b>	ManagerNetworkProtocol	object	The settings for this manager's HTTP protocol support.
<b>HTTPBasicAuth</b>	AccountService	string (enum)	Indicates if HTTP Basic authentication is enabled for this service.

Property Name	Defined In Schema(s)	Type	Description
<b>HTTPBoot</b>	NetworkDeviceFunction	object	The HTTP and HTTPS boot capabilities, status, and configuration values for this network device function.
<b>HttpBootUri</b>	ComputerSystem (Boot)	string	The URI to boot from when <code>BootSourceOverrideTarget</code> is set to <code>UefiHttp</code> .
<b>HttpHeaders</b>	Job (Payload)	array	An array of HTTP headers in this job.
	Task (Payload)	array	An array of HTTP headers that this task includes.
	EventDestination	array	An array of settings for HTTP headers, such as authorization information. This array is <code>null</code> or an empty array in responses. An empty array is the preferred return value on read operations.
<b>HttpOperation</b>	Job (Payload)	string	The HTTP operation that executes this job.
	Task (Payload)	string	The HTTP operation to perform to execute this task.
<b>HttpPushUri</b>	UpdateService	string	The URI used to perform an HTTP or HTTPS push update to the update service. The format of the message is vendor-specific.
<b>HttpPushUriApplyTime</b>	UpdateService (HttpPushUriOptions)	object	The settings for when to apply <code>HttpPushUri</code> -provided firmware.
<b>HttpPushUriOptions</b>	UpdateService	object	The options for <code>HttpPushUri</code> -provided software updates.
<b>HttpPushUriOptionsBusy</b>	UpdateService	boolean	An indication of whether a client has reserved the <code>HttpPushUriOptions</code> properties for software updates.
<b>HttpPushUriTargets</b>	UpdateService	array	An array of URIs that indicate where to apply the update image.
<b>HttpPushUriTargetsBusy</b>	UpdateService	boolean	An indication of whether any client has reserved the <code>HttpPushUriTargets</code> property.

Property Name	Defined In Schema(s)	Type	Description
<b>HTTPS</b>	ManagerNetworkProtocol	object	The settings for this manager's HTTPS protocol support.
<b>HumidityPercent</b>	EnvironmentMetrics, LeakDetection (LeakDetectorGroups), PowerDistributionMetrics	object	Humidity (percent).
<b>HysteresisDuration</b>	Triggers	string	The duration the metric value must not violate the threshold before the threshold is deactivated.
	Sensor (Thresholds > LowerCaution), Sensor (Thresholds > LowerCautionUser), Sensor (Thresholds > LowerCritical), Sensor (Thresholds > LowerCriticalUser), Sensor (Thresholds > LowerFatal), Sensor (Thresholds > UpperCaution), Sensor (Thresholds > UpperCautionUser), Sensor (Thresholds > UpperCritical), Sensor (Thresholds > UpperCriticalUser), Sensor (Thresholds > UpperFatal)	string	The duration the sensor value must not violate the threshold before the threshold is deactivated.
<b>HysteresisReading</b>	<i>various</i> (Sensor (Thresholds > LowerCaution), Sensor (Thresholds > LowerCautionUser) ... )	number	The reading offset from the threshold value required to clear the threshold.
<b>I2CBuses</b>	ManagerDiagnosticData	array	The statistics of the I2C buses.
<b>I2CBusName</b>	ManagerDiagnosticData (I2CBuses)	string	The name of the I2C bus.
<b>IANAProtocolNumber</b>	AllowDeny	integer	The IANA protocol number to which this permission applies. For TCP, this is <code>6</code> . For UDP, this is <code>17</code> .
<b>IBGPAddressRange</b>	AddressPool (Ethernet > IPv4)	object	Internal BGP (iBGP) related addressing for this Ethernet fabric.
<b>IdentificationRegisters</b>	Processor (ProcessorId)	string	The raw manufacturer-provided processor identification registers for this processor.
<b>Identifier</b>	Drive (NVMe > ActivePersonalities), Storage (NVMeSubsystemProperties > ActivePersonalities)	integer	The personality identifier.

Property Name	Defined In Schema(s)	Type	Description
	<i>various</i> (CXLLogicalDevice (Identifiers), Drive (Identifiers) ... )	object	Any additional identifiers for a resource.
	EndpointGroup	object	The durable name for the endpoint group.
<b>Identifiers</b>	Endpoint (ConnectedEntities)	array	Identifiers for the remote entity.
	Endpoint	array	Identifiers for this endpoint.
	CXLLogicalDevice	array	The durable names for the CXL logical device.
	Drive	array	The durable names for the drive.
	NetworkAdapter (Controllers)	array	The durable names for the network adapter controller.
	NetworkAdapter	array	The durable names for the network adapter.
	Storage (StorageControllers), StorageController	array	The durable names for the storage controller.
	Storage	array	The durable names for the storage subsystem.
	Volume	array	The Durable names for the volume.
	Zone	array	The durable names for the zone.
<b>IdentityAuthentication</b>	ComponentIntegrity (SPDM)	object	Identity authentication information about the SPDM Requester and SPDM Responder.
	ComponentIntegrity (TPM)	object	Identity authentication information about the TPM.
<b>IdlePowerSaver</b>	ComputerSystem	object	The idle power saver settings of the computer system.
<b>Image</b>	VirtualMedia	string	The URI of the location of the selected image.
	VirtualMedia (Actions > InsertMedia (Action))	string	The URI of the media to attach to the virtual media.
<b>ImageDataURI</b>	SoftwareInventory	string	The URI at which to access the software inventory image.
<b>ImageName</b>	VirtualMedia	string	The current image name.

Property Name	Defined In Schema(s)	Type	Description
<b>ImageURI</b>	UpdateService (Actions > SimpleUpdate (Action))	string	The URI of the software image to install.
<b>ImmersionUnits</b>	Facility (Links)	array	An array of links to the immersion cooling units in this facility.
	ThermalEquipment	object	A link to a collection of immersion cooling units.
<b>Immutable</b>	AttributeRegistry (RegistryEntries > Attributes)	boolean	An indication of whether this attribute is immutable. Immutable attributes cannot be modified and typically reflect a hardware state.
<b>Implementation</b>	Control	string (enum)	The implementation of the control.
	MetricDefinition	string (enum)	The implementation of the metric.
	Sensor	string (enum)	The implementation of the sensor.
<b>ImportForeignDrives (Action)</b>	Storage (Actions)	object	This action imports encrypted foreign drives to a host-based storage controller by supplying encryption access credentials.
<b>IncludeOriginOfCondition</b>	EventDestination	boolean	An indication of whether the events subscribed to will also include the entire resource or object referenced by the <code>OriginOfCondition</code> property in the event payload.
<b>IncludeOriginOfConditionQuery</b>	ServiceRoot (ProtocolFeaturesSupported)	boolean	An indication of whether the service supports the <code>includeoriginofcondition</code> query parameter.
<b>IncludeOriginOfConditionSupported</b>	EventService	boolean	An indication of whether the service supports including the resource payload of the origin of condition in the event payload.
<b>IncludesSubordinates</b>	RegisteredClient (ManagedResources)	boolean	Indicates whether the subordinate resources of the managed resource are also managed by the registered client.

Property Name	Defined In Schema(s)	Type	Description
<b>Increment</b>	Control	number	The smallest increment supported for the set point.
<b>IndeterminateCorrectableErrorCount</b>	MemoryMetrics (LifeTime)	integer	The number of indeterminate correctable errors for the lifetime of the memory.
	MemoryMetrics (CurrentPeriod)	integer	The number of indeterminate correctable errors since reset.
<b>IndeterminatePersonalityStatus</b>	StorageController (NVMeControllerProperties > NVMeSMARTCriticalWarnings)	boolean	A request to change the settings of a personality did not complete successfully and the NVM subsystem was not able to revert to the previous personality.
<b>IndeterminateUncorrectableErrorCount</b>	MemoryMetrics (LifeTime)	integer	The number of indeterminate uncorrectable errors for the lifetime of the memory.
	MemoryMetrics (CurrentPeriod)	integer	The number of indeterminate uncorrectable errors since reset.
<b>IndicatorLED</b>	Drive	string (enum)	The state of the indicator LED, that identifies the drive.
	Chassis	string (enum)	The state of the indicator LED, which identifies the chassis.
	Circuit	string (enum)	The state of the indicator LED, which identifies the circuit.
	Outlet	string (enum)	The state of the indicator LED, which identifies the outlet.
	Power (PowerSupplies)	string (enum)	The state of the indicator LED, which identifies the power supply.
	Switch	string (enum)	The state of the indicator LED, which identifies the switch.
	ComputerSystem	string (enum)	The state of the indicator LED, which identifies the system.
	Thermal (Fans)	string (enum)	The state of the indicator LED, which identifies this fan.
<b>InfiniBand</b>	Port	object	InfiniBand properties for this port.

Property Name	Defined In Schema(s)	Type	Description
	NetworkDeviceFunction	object	The InfiniBand capabilities, status, and configuration values for this network device function.
<b>Initialize (Action)</b>	Volume (Actions)	object	This action is used to prepare the contents of the volume for use by the system. If InitializeMethod is not specified in the request body, but the property InitializeMethod is specified, the property InitializeMethod value should be used. If neither is specified, the InitializeMethod should be Foreground.
<b>InitializeMethod</b>	Volume	string (enum)	Indicates the Initialization Method used for this volume. If InitializeMethod is not specified, the InitializeMethod should be Foreground.
	Volume (Actions > Initialize (Action))	string (enum)	The type of initialization to be performed.
<b>InitializeType</b>	Volume (Actions > Initialize (Action))	string (enum)	The type of initialization to be performed.
<b>Initials</b>	CertificateEnrollment (CSRParameters), CertificateService (Actions > GenerateCSR (Action))	string	The initials of the user making the request.
<b>InitiatorCHAPPassword</b>	Connection (ConnectionKeys > CHAP)	string	The initiator shared secret for mutual (2-way) CHAP authentication. The value is <code>null</code> in responses.
<b>InitiatorCHAPUsername</b>	Connection (ConnectionKeys > CHAP)	string	The initiator username for mutual (2-way) CHAP authentication.
<b>InitiatorDefaultGateway</b>	NetworkDeviceFunction (iSCSIBoot)	string	The IPv6 or IPv4 iSCSI boot default gateway.
<b>InitiatorEndpointGroups</b>	Connection (Links)	array	An array of links to the initiator endpoint groups that are associated with this connection.
<b>InitiatorEndpoints</b>	Connection (Links)	array	An array of links to the initiator endpoints that are associated with this connection.

Property Name	Defined In Schema(s)	Type	Description
<b>InitiatorIPAddress</b>	NetworkDeviceFunction (iSCSIBoot)	string	The IPv6 or IPv4 address of the iSCSI initiator.
<b>InitiatorName</b>	NetworkDeviceFunction (iSCSIBoot)	string	The iSCSI initiator name.
<b>InitiatorNetmask</b>	NetworkDeviceFunction (iSCSIBoot)	string	The IPv6 or IPv4 netmask of the iSCSI boot initiator.
<b>InitrTimeSeconds</b>	ManagerDiagnosticData (BootTimeStatistics)	number	The number of seconds the manager spent in the initrd boot stage.
<b>InjectPersistentPoison (Action)</b>	Memory (Actions)	object	Injects poison to a specific persistent memory address in the memory device.
<b>InletPressurekPa</b>	Pump	object	The inlet pressure (kPa).
<b>InputCurrentAmps</b>	BatteryMetrics	object	The input current (A) for this battery.
	PowerSupplyMetrics	object	The input current (A) for this power supply.
<b>InputNominalVoltageType</b>	PowerSupply	string (enum)	The nominal voltage type that is detected on the line input to this power supply.
<b>InputPowerWatts</b>	PowerSupplyMetrics	object	The input power (W) for this power supply.
<b>InputRanges</b>	Power (PowerSupplies), PowerSupply	array	The input ranges that the power supply can use.
<b>InputType</b>	Power (PowerSupplies > InputRanges)	string (enum)	The Input type (AC or DC).
<b>InputVoltage</b>	BatteryMetrics	object	The input voltage (V) for this battery.
	PowerSupplyMetrics	object	The input voltage (V) for this power supply.
<b>Inserted</b>	VirtualMedia (Actions > InsertMedia (Action))	boolean	An indication of whether the image is treated as mounted and visible to the host system upon completion of the action. The default is <code>true</code> .
	VirtualMedia	boolean	An indication of whether the media is mounted and visible to the host system.

Property Name	Defined In Schema(s)	Type	Description
<b>InsertMedia (Action)</b>	VirtualMedia (Actions)	object	This action attaches remote media to virtual media.
<b>Install (Action)</b>	LicenseService (Actions)	object	This action installs one or more licenses from a remote file.
<b>InstallDate</b>	License	string	The date and time when the license was installed.
<b>InstanceID</b>	Switch (CXL > PIDTargetList)	integer	The index of the PID for targets that support multiple PIDs.
<b>InstructionSet</b>	Processor	string (enum)	The instruction set of the processor.
<b>InstructionsPerCycle</b>	ProcessorMetrics (CoreMetrics)	number	The number of instructions per clock cycle of this core.
<b>Instrumentation</b>	AutomationNode	object	A link to the instrumentation for this node.
<b>Intake</b>	ThermalMetrics (TemperatureSummaryCelsius)	object	The intake temperature (in degree Celsius units) of this subsystem.
<b>Integral</b>	AutomationInstrumentation (PID > ControlLoop), Control (ControlLoop), CoolantConnector (DeltaPressureControlkPa > ControlLoop), CoolantConnector (DeltaTemperatureControlCelsius > ControlLoop), CoolantConnector (FlowControlLitersPerMinute > ControlLoop), CoolantConnector (ReturnTemperatureControlCelsius > ControlLoop), CoolantConnector (SupplyTemperatureControlCelsius > ControlLoop), CoolantConnector (ValvePositionControlPercent > ControlLoop), Pump (SpeedControlPercent > ControlLoop)	number	The integral coefficient.
<b>IntegratedInto</b>	TrustedComponent (Links)	object	A link to a resource to which this trusted component is integrated.
<b>IntegratedMemory</b>	Processor (ProcessorMemory)	boolean	An indication of whether this memory is integrated within the processor.

Property Name	Defined In Schema(s)	Type	Description
<b>Interactive</b>	ComputerSystem (SerialConsole > WebSocket)	boolean	Indicates if the WebSocket serial console allows interactive input.
<b>InterconnectSpecificDCManagement</b>	MemoryRegion	boolean	An indication of whether the device supports changing the amount of host-visible memory capacity in a memory region at runtime.
<b>InterfaceEnabled</b>	Port	boolean	An indication of whether the port is enabled.
	EthernetInterface, HostInterface, SerialInterface	boolean	An indication of whether this interface is enabled.
<b>InterfaceType</b>	ComputerSystem (TrustedModules)	string (enum)	The interface type of the Trusted Module.
	Processor (FPGA > ExternalInterfaces), Processor (FPGA > HostInterface), Processor (SystemInterface)	string (enum)	The interface type.
<b>InterfaceTypeSelection</b>	ComputerSystem (TrustedModules)	string (enum)	The interface type selection supported by this Trusted Module.
<b>InterleavableMemorySets</b>	MemoryDomain	array	The interleave sets for the memory chunk.
<b>InterleaveSets</b>	MemoryChunks	array	The interleave sets for the memory chunk.
<b>Internal</b>	ThermalMetrics (TemperatureSummaryCelsius)	object	The internal temperature (in degree Celsius units) of this subsystem.
<b>InternalMemoryMetrics</b>	SwitchMetrics	object	The memory metrics for a switch.
<b>InternalPressurekPa</b>	Reservoir	object	The internal pressure (kPa) reading.
<b>IntervalInMin</b>	Power (PowerControl > PowerMetrics)	integer (min)	The time interval, or window, over which the power metrics are measured.
<b>IntrusionSensor</b>	Chassis (PhysicalSecurity)	string (enum)	The physical security state of the chassis, such as if hardware intrusion is detected.
<b>IntrusionSensorNumber</b>	Chassis (PhysicalSecurity)	integer	A numerical identifier to represent the physical security sensor.

Property Name	Defined In Schema(s)	Type	Description
<b>IntrusionSensorReArm</b>	Chassis (PhysicalSecurity)	string (enum)	The policy that describes how the physical security state of the chassis returns to a normal state.
<b>Invalidate (Action)</b>	Job (Actions)	object	Invalidates the job.
<b>InvalidCRCs</b>	PortMetrics (FibreChannel)	integer	The total number of invalid cyclic redundancy checks (CRCs).
<b>InvalidDwordCount</b>	PortMetrics (SAS)	integer	The number of invalid dwords that have been received by the phy outside of phy reset sequences.
<b>InvalidTXWords</b>	PortMetrics (FibreChannel)	integer	The total number of invalid transmission words.
<b>InvolvedSwitches</b>	Zone (Links)	array	The links to the collection of switches in this zone.
<b>IOPerfModeEnabled</b>	Volume	boolean	Indicates the IO performance mode setting for the volume.
<b>IOStallCount</b>	ProcessorMetrics (CoreMetrics)	number	The number of stalled cycles due to I/O operations.
<b>IOStatistics</b>	StorageMetrics	object	Statistics for this storage system.
	Volume	object	Statistics for this volume.
<b>IPAddressLower</b>	AllowDeny	string	The lower IP address to which this permission applies.
<b>IPAddressType</b>	NetworkDeviceFunction (iSCSIBoot)	string (enum)	The type of IP address being populated in the iSCSIBoot IP address fields.
	AllowDeny	string (enum)	The type of IP address populated in the <code>IPAddressLower</code> and <code>IPAddressUpper</code> properties.
<b>IPAddressUpper</b>	AllowDeny	string	The upper IP address to which this permission applies.
<b>IPMaskDNSViaDHCP</b>	NetworkDeviceFunction (iSCSIBoot)	boolean	An indication of whether the iSCSI boot initiator uses DHCP to obtain the initiator name, IP address, and netmask.
<b>IPMI</b>	ComputerSystem (SerialConsole)	object	The connection details for an IPMI Serial-over-LAN service.

Property Name	Defined In Schema(s)	Type	Description
	ManagerNetworkProtocol	object	The settings for this manager's IPMI-over-LAN protocol support.
<b>IPMIHostInterface</b>	ComputerSystem	object	The information about the in-band IPMI service of this system.
<b>IPTransportDetails</b>	Endpoint	array	An array of details for each IP transport supported by this endpoint. The array structure can model multiple IP addresses for this endpoint.
<b>IPv4</b>	AddressPool (Ethernet)	object	IPv4 and Virtual LAN (VLAN) related addressing for this Ethernet fabric.
<b>IPv4Address</b>	Endpoint (IPTransportDetails)	object	The IPv4 addresses assigned to the endpoint.
	EthernetInterface (IPv4Addresses), EthernetInterface (IPv4StaticAddresses)	object	This type describes an IPv4 address.
<b>IPv4Addresses</b>	EthernetInterface	array	The IPv4 addresses currently in use by this interface.
<b>IPv4AddressRangeLower</b>	ManagerNetworkProtocol (SNMP > CommunityStrings)	string	The lowest IPv4 address in the range allowed to access the service.
<b>IPv4AddressRangeUpper</b>	ManagerNetworkProtocol (SNMP > CommunityStrings)	string	The highest IPv4 address in the range allowed to access the service.
<b>IPv4AutoConfigEnabled</b>	EthernetInterface (StatelessAddressAutoConfig)	boolean	An indication of whether IPv4 stateless address autoconfiguration (SLAAC) is enabled for this interface.
<b>IPv4StaticAddresses</b>	EthernetInterface	array	The IPv4 static addresses assigned to this interface. See <a href="#">IPv4Addresses</a> for the addresses in use by this interface.
<b>IPv6Address</b>	Endpoint (IPTransportDetails)	object	The IPv6 addresses assigned to the endpoint.
	EthernetInterface (IPv6Addresses)	object	This type describes an IPv6 address.

Property Name	Defined In Schema(s)	Type	Description
<b>IPv6Addresses</b>	EthernetInterface	array	The IPv6 addresses currently in use by this interface.
<b>IPv6AddressGenerationMode</b>	ManagerNetworkProtocol	string (enum)	The IPv6 address generation mode. This affects all Ethernet interfaces on this manager.
<b>IPv6AddressPolicyTable</b>	EthernetInterface	array	An array that represents the RFC6724-defined address selection policy table.
<b>IPv6AutoConfigEnabled</b>	EthernetInterface (StatelessAddressAutoConfig)	boolean	An indication of whether IPv6 stateless address autoconfiguration (SLAAC) is enabled for this interface.
<b>IPv6DefaultGateway</b>	EthernetInterface	string	The IPv6 default gateway address in use on this interface.
<b>IPv6Enabled</b>	EthernetInterface	boolean	An indication of whether IPv6 is enabled on this interface.
<b>IPv6GatewayStaticAddress</b>	EthernetInterface (IPv6StaticDefaultGateways)	object	This type represents a single IPv6 static address to be assigned on a network interface.
<b>IPv6StaticAddress</b>	EthernetInterface (IPv6StaticAddresses)	object	This type represents a single IPv6 static address to be assigned on a network interface.
<b>IPv6StaticAddresses</b>	EthernetInterface	array	The IPv6 static addresses assigned to this interface. See <a href="#">IPv6Addresses</a> for the addresses in use by this interface.
<b>IPv6StaticDefaultGateways</b>	EthernetInterface	array	The IPv6 static default gateways for this interface.
<b>IsAggregation</b>	Port	boolean	Indicates whether this is a logical aggregation.
<b>IsBootCapable</b>	Volume	boolean	This property indicates whether or not the Volume contains a boot image and is capable of booting.
<b>iSCSIBoot</b>	NetworkDeviceFunction	object	The iSCSI boot capabilities, status, and configuration values for this network device function.

Property Name	Defined In Schema(s)	Type	Description
<b>IsDefault</b>	KeyPolicy	boolean	Indicates if this is the default key policy.
<b>IsLinear</b>	MetricDefinition	boolean	An indication of whether the metric values are linear versus non-linear.
<b>IsLogical</b>	StorageController	boolean	Indicates whether this is a logical storage controller.
<b>IsManaged</b>	Switch	boolean	An indication of whether the switch is in a managed or unmanaged state.
<b>IsMirrorEnabled</b>	MemoryChunks	boolean	An indication of whether memory mirroring is enabled for this memory chunk.
<b>ISOCountryCodeOfOrigin</b>	Assembly (Assemblies)	string	The manufacturing country of origin, using the ISO 3166-1 country code.
<b>IsPredefined</b>	Role	boolean	An indication of whether the role is predefined by Redfish or an OEM rather than a client-defined role.
<b>IsRankSpareEnabled</b>	Memory	boolean	An indication of whether rank spare is enabled for this memory device.
<b>IsShareable</b>	Volume (NVMeNamespaceProperties)	boolean	Indicates the namespace is shareable.
<b>IsSpare</b>	MemoryChunks	boolean	An indication of whether sparing is enabled for this memory chunk.
<b>IsSpareDeviceEnabled</b>	Memory	boolean	An indication of whether a spare device is enabled for this memory device.
<b>IsSplit</b>	Port	boolean	Indicates whether this is a subport split from a physical port.
<b>Issuer</b>	Certificate (Links)	object	A link to the certificate of the CA that issued this certificate.
	Certificate	object	The issuer of the certificate.

Property Name	Defined In Schema(s)	Type	Description
	AccountService (ActiveDirectory > OAuth2Service), AccountService (LDAP > OAuth2Service), AccountService (OAuth2 > OAuth2Service), AccountService (TACACSplus > OAuth2Service), ExternalAccountProvider (OAuth2Service)	string	The issuer string of the OAuth 2.0 service. Clients should configure this property if <code>Mode</code> contains <code>Offline</code> .
<b>IsSupervisor</b>	StorageController (MPFProperties)	boolean	Indicates whether this physical function is the supervisor, which manages the other physical functions, manages the configuration of the controller, and controls management access.
<b>IsSystemUniqueProperty</b>	AttributeRegistry (RegistryEntries > Attributes)	boolean	An indication of whether this attribute is unique for this system and should not be replicated.
<b>JobCreator</b>	JobDocument (Actions > SubmitJob (Action))	object	The link to the job that is submitting this job.
<b>JobDocument</b>	Job (Links)	object	A link to the job document that was used to create this job.
<b>JobDocuments</b>	JobService	object	The links to the job document collection.
<b>JobExecutors</b>	JobService	object	The links to the job executor collection.
<b>JobPriority</b>	Job	integer	The requested priority for this job.
<b>Jobs</b>	JobService	object	The links to the jobs collection.
<b>JobService</b>	ServiceRoot	object	The link to the job service.
<b>JobState</b>	Job	string (enum)	The state of the job.
<b>JobStatus</b>	Job	string (enum)	The status of the job.
<b>JobType</b>	Job	string (enum)	The type of this job.
<b>JournalingMedia</b>	Volume (Links)	object	A pointer to the Resource that serves as a journaling media for this volume.

Property Name	Defined In Schema(s)	Type	Description
<b>JsonBody</b>	Job (Payload)	string	The JSON payload to use in the execution of this job.
	Task (Payload)	string	The JSON payload to use in the execution of this task.
<b>JsonSchemas</b>	ServiceRoot	object	The link to a collection of JSON Schema files.
<b>KeepaliveIntervalSeconds</b>	AddressPool (Ethernet > EBGp > BGPNeighbor), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor)	integer	Border Gateway Protocol (BGP) Keepalive timer in seconds.
<b>KerberosKeytab</b>	AccountService (ActiveDirectory > Authentication), AccountService (LDAP > Authentication), AccountService (OAuth2 > Authentication), AccountService (TACACSplus > Authentication), ExternalAccountProvider (Authentication)	string	The Base64-encoded Kerberos keytab for this service. A <code>PATCH</code> or <code>PUT</code> operation writes the keytab. This property is <code>null</code> in responses.
<b>Kernel</b>	OperatingSystem	object	The kernel information for this operating system.
	SoftwareInventory (AdditionalVersions)	string	The kernel version contained in this software.
<b>KernelAuthEnabled</b>	HostInterface	boolean	An indication of whether this kernel authentication is enabled for this interface.
<b>KernelAuthRole</b>	HostInterface (Links)	object	The link to the Redfish role defining privileges for this host interface when using kernel authentication.
<b>KernelAuthRoleId</b>	HostInterface	string	The Redfish role used for kernel authentication on this interface.
<b>KernelPercent</b>	ManagerDiagnosticData (ProcessorStatistics)	number (%)	The percentage of CPU time spent in kernel mode.
	ProcessorMetrics	number (%)	The percentage of time spent in kernel mode.
<b>KernelTimeSeconds</b>	ManagerDiagnosticData (BootTimeStatistics)	number	The number of seconds the manager spent in the kernel stage.

Property Name	Defined In Schema(s)	Type	Description
	ManagerDiagnosticData (TopProcesses)	number	The number of seconds this process executed in kernel space.
<b>Key</b>	Drive (Actions > UnfreezePersonality (Action)), Storage (Actions > UnfreezePersonality (Action))	string	The authentication key for the unfreeze operation.
	Drive (Actions > SetPersonalityKey (Action)), Storage (Actions > SetPersonalityKey (Action))	string	The personality key to set on the NVMe subsystem.
<b>KeyBitLength</b>	Certificate (Actions > Rekey (Action)), CertificateService (Actions > GenerateCSR (Action))	integer	The length of the key, in bits, if needed based on the <code>KeyPairAlgorithm</code> parameter value.
	CertificateEnrollment (CSRParameters)	integer	The length of the key, in bits, if needed based on the <code>KeyPairAlgorithm</code> property value.
<b>KeyChain</b>	AddressPool (Ethernet > BFDSingleHopOnly)	string	Bidirectional Forwarding Detection (BFD) Key Chain name.
<b>KeyCurveId</b>	Certificate (Actions > Rekey (Action)), CertificateService (Actions > GenerateCSR (Action))	string	The curve ID to use with the key, if needed based on the <code>KeyPairAlgorithm</code> parameter value.
	CertificateEnrollment (CSRParameters)	string	The curve ID to use with the key, if needed based on the <code>KeyPairAlgorithm</code> property value.
<b>KeyLength</b>	UpdateService (Actions > GenerateSSHIdentityKeyPair (Action))	integer	The length of the SSH key, in bits, if the <code>KeyType</code> parameter contains <code>RSA</code> .
	AggregationSource (Actions > GenerateSSHIdentityKeyPair (Action))	integer	The length of the SSH key, in bits, if the <code>KeyType</code> parameter contains <code>RSA</code> .
<b>KeyManagement</b>	ComputerSystem	object	The key management settings of the computer system.
<b>KeyPairAlgorithm</b>	Certificate (Actions > Rekey (Action)), CertificateEnrollment (CSRParameters), CertificateService (Actions > GenerateCSR (Action))	string	The type of key-pair for use with signing algorithms.
<b>KeyPolicyType</b>	KeyPolicy	string (enum)	The type of key policy.

Property Name	Defined In Schema(s)	Type	Description
<b>Keys</b>	MetricReportDefinition (Wildcards)	array	An array of values to substitute for the wildcard.
	ManagerAccount	object	The link to the collection of keys that can be used to authenticate this account. For example, an SSH public key could be added to this collection to allow for SSH public key authentication.
<b>KeyService</b>	ServiceRoot	object	The link to the key service.
<b>KeyString</b>	Key	string	The string for the key.
<b>KeyType</b>	Key	string (enum)	The format of the key.
	AggregationSource (Actions > GenerateSSHIdentityKeyPair (Action)), UpdateService (Actions > GenerateSSHIdentityKeyPair (Action))	string (enum)	The type of SSH key.
<b>KeyUsage</b>	Certificate	array	The key usage extension, which defines the purpose of the public keys in this certificate.
	CertificateEnrollment (CSRParameters), CertificateService (Actions > GenerateCSR (Action))	array	The usage of the key contained in the certificate.
	Certificate (KeyUsage), CertificateEnrollment (CSRParameters > KeyUsage), CertificateService (Actions > GenerateCSR (Action) > KeyUsage)	string (enum)	The usages of a key contained within a certificate.
<b>KMIPCertificates</b>	ComputerSystem (KeyManagement)	object	The link to a collection of server certificates for the servers referenced by the <code>KMIPServers</code> property.
<b>KMIPClientCertificates</b>	ComputerSystem (KeyManagement)	object	The link to a collection of client identity certificates provided to the servers referenced by the <code>KMIPServers</code> property.
<b>KMIPServers</b>	ComputerSystem (KeyManagement)	array	The KMIP servers to which this computer system is subscribed.

Property Name	Defined In Schema(s)	Type	Description
<b>KVMIP</b>	ManagerNetworkProtocol	object	The settings for this manager's KVM-IP protocol support that apply to all system instances controlled by this manager.
<b>Label</b>	EthernetInterface (IPv6AddressPolicyTable)	integer	The IPv6 label, as defined in RFC6724, section 2.1.
<b>LabelStorageSizeBytes</b>	Memory (CXL)	integer (bytes)	The size of the label storage area in bytes of this memory device.
<b>LaneId</b>	PortMetrics (Transceivers > ByLane)	integer	The transceiver lane for which metrics are being supplied.
<b>Lanes</b>	NetworkAdapter (PortSplitting > CurrentConfiguration), NetworkAdapter (PortSplitting > SupportedConfigurations > Subconfigurations)	array	The number of lanes for each subport.
	PCleDevice (Slot), PCleSlots (Slots)	integer	The number of PCIe lanes supported by this slot.
<b>LanesInUse</b>	PCleDevice (PCIeInterface)	integer	The number of PCIe lanes in use by this device.
<b>LaneSplitting</b>	PCleDevice (Slot)	string (enum)	The lane splitting strategy used in the PCIe slot.
<b>Language</b>	MessageRegistryFile (Location)	string	The language code for the registry file.
	JsonSchemaFile (Location)	string	The language code for the schema file.
	AttributeRegistry	string	The RFC5646-conformant language code for the attribute registry.
	MessageRegistry	string	The RFC5646-conformant language code for the message registry.
<b>Languages</b>	MessageRegistryFile	array	The RFC5646-conformant language codes for the available registries.
	JsonSchemaFile	array	The RFC5646-conformant language codes for the available schemas.
<b>LastBootTimeSeconds</b>	ComputerSystem (BootProgress)	number	The number of seconds the system spent booting to the operating system during the last boot.

Property Name	Defined In Schema(s)	Type	Description
<b>LastOperation</b>	CertificateEnrollment (EnrollmentState)	string (enum)	The last operation performed by the automatic enrollment service.
<b>LastOperationStatus</b>	CertificateEnrollment (EnrollmentState)	string (enum)	The status of the last operation performed by automatic enrollment service.
<b>LastOperationTime</b>	CertificateEnrollment (EnrollmentState)	string	The date and time when the last operation was performed.
<b>LastOverflowTimestamp</b>	LogEntry	string	The timestamp of the last overflow captured after this log entry.
<b>LastPowerOutputWatts</b>	Power (PowerSupplies)	number (watts)	The average power output of this power supply.
<b>LastResetCause</b>	ComputerSystem	string (enum)	The last reset cause of the system.
<b>LastResetTime</b>	Manager	string	The date and time when the manager was last reset or rebooted.
	ComputerSystem	string	The date and time when the system was last reset or rebooted.
<b>LastShutdownSuccess</b>	MemoryMetrics (HealthData)	boolean	An indication of whether the last shutdown succeeded.
<b>LastState</b>	ComputerSystem (BootProgress)	string (enum)	The last boot progress state.
<b>LastStateTime</b>	ComputerSystem (BootProgress)	string	The date and time when the last boot state was updated.
<b>LastUpdated</b>	ComponentIntegrity	string	The date and time when information for the component was last updated.
	ComponentIntegrity (SPDM > MeasurementSet > Measurements), ComponentIntegrity (TPM > MeasurementSet > Measurements)	string	The date and time when information for the measurement was last updated.
<b>LBADataSizeBytes</b>	Volume (NVMeNamespaceProperties > LBAFormat), Volume (NVMeNamespaceProperties > LBAFormats)	integer	The LBA data size in bytes.
<b>LBAFormat</b>	Volume (NVMeNamespaceProperties)	object	Describes the current LBA format ID and detailed properties.

Property Name	Defined In Schema(s)	Type	Description
<b>LBAFormats</b>	Volume (NVMeNamespaceProperties)	array	Describes the LBA format IDs and detailed properties.
<b>LBAFormatsSupported</b>	Volume (NVMeNamespaceProperties)	array	A list of the LBA format types supported for the namespace, or potential namespaces.
<b>LBAFormatType</b>	Volume (NVMeNamespaceProperties > LBAFormatsSupported)	string (enum)	LBAFormatType is defined in the NVMe specification set. This field indicates the LBA data size supported; implementations may report up to 16 values. For more details refer to the appropriate NVMe specification.
	Volume (NVMeNamespaceProperties > LBAFormat), Volume (NVMeNamespaceProperties > LBAFormats)	string (enum)	The LBA format type.
<b>LBA_METADATA_SIZE_BYTES</b>	Volume (NVMeNamespaceProperties > LBAFormat), Volume (NVMeNamespaceProperties > LBAFormats)	integer	The LBA metadata size in bytes.
<b>LDAP</b>	AccountService	object	The first LDAP external account provider that this account service supports.
<b>LDAPService</b>	AccountService (ActiveDirectory), AccountService (LDAP), AccountService (OAuth2), AccountService (TACACSplus), ExternalAccountProvider	object	The additional mapping information needed to parse a generic LDAP service.
<b>LeakDetection</b>	CoolingUnit	object	A link to the leak detection components associated with this equipment.
	ThermalSubsystem	object	The link to the leak detection system within this chassis.
<b>LeakDetectorGroups</b>	LeakDetection	array	The groups of leak detection equipment.
<b>LeakDetectors</b>	Chassis	object	The link to the collection of leak detectors located in this chassis.

Property Name	Defined In Schema(s)	Type	Description
	LeakDetection	object	The link to the collection of leak detectors within this subsystem.
<b>LeakDetectorType</b>	LeakDetector	string (enum)	The type of leak detection sensor.
<b>Length</b>	Memory (Actions > ScanMedia (Action))	integer	The length of the target region to scan in bytes from the physical address.
	CXLLogicalDevice (Actions > DynamicCapacityRelease (Action))	integer	The size of dynamic capacity to release.
	CXLLogicalDevice (Actions > DynamicCapacityAdd (Action))	integer	The size of the dynamic capacity to add.
<b>LengthMeters</b>	Cable	number	The length of the cable in meters.
<b>Level</b>	ProcessorMetrics (CoreMetrics > CStateResidency)	string	The C-state level, such as C0, C1, or C2.
	ProcessorMetrics (Cache), ProcessorMetrics (CoreMetrics > CoreCache)	string	The cache level.
<b>Levels</b>	ServiceRoot (ProtocolFeaturesSupported > ExpandQuery)	boolean	An indication of whether the service supports the <code>\$levels</code> option of the <code>\$expand</code> query parameter.
<b>LicenseExpirationWarningDays</b>	LicenseService	integer	The number of days prior to a license expiration that a warning message is sent. A value of zero indicates no warning message is sent.
<b>LicenseFileURI</b>	LicenseService (Actions > Install (Action))	string	The URI of the license file to install.
<b>LicenseInfoURI</b>	License	string	The URI at which more information about this license can be obtained.
<b>LicenseOrigin</b>	License	string (enum)	This indicates the origin of the license.
<b>Licenses</b>	LicenseService	object	The link to the collection of licenses.
<b>LicenseService</b>	ServiceRoot	object	The link to the license service.
<b>LicenseString</b>	License	string	The Base64-encoded string of the license.

Property Name	Defined In Schema(s)	Type	Description
<b>LicenseType</b>	License	string (enum)	The type of the license.
<b>LifeCycleEventOnTaskStateChange</b>	TaskService	boolean	An indication of whether a task state change sends an event.
<b>LifeTime</b>	ProcessorMetrics (CacheMetricsTotal)	object	The cache metrics for the lifetime of this processor.
	MemoryMetrics	object	The memory metrics for the lifetime of the memory.
	SwitchMetrics (InternalMemoryMetrics)	object	The memory metrics for the lifetime of this switch.
	various (Circuit (EnergykWh), Circuit (PolyPhaseEnergykWh > Line1ToLine2) ... )	number	The total accumulation value for this sensor.
<b>LifetimeStartDateTime</b>	DriveMetrics	string	The date and time when the drive started accumulating data for properties that contain lifetime data, such as <code>UncorrectableIOReadErrorCount</code> .
	MemoryMetrics	string	The date and time when the memory started accumulating data for the <code>LifeTime</code> property.
	ProcessorMetrics	string	The date and time when the processor started accumulating data for the <code>LifeTime</code> property.
	Sensor	string	The date and time when the sensor started accumulating readings for the <code>LifetimeReading</code> property.
	StorageControllerMetrics	string	The date and time when the storage controller started accumulating data for properties that contain lifetime data, such as <code>UncorrectableECCErrorCount</code> .
	SwitchMetrics	string	The date and time when the switch started accumulating data for the <code>LifeTime</code> property.
<b>LimitException</b>	Power (PowerControl > PowerLimit)	string (enum)	The action that is taken if the power cannot be maintained below the <code>LimitInWatts</code> .

Property Name	Defined In Schema(s)	Type	Description
<b>LimitInWatts</b>	Power (PowerControl > PowerLimit)	number (watts)	The power limit, in watt units. If null, power capping is disabled.
<b>LimitPercent</b>	CXLLogicalDevice (QoS)	integer (%)	The bandwidth limit to this CXL logical device as a percentage.
<b>Limits</b>	NetworkDeviceFunction	array	The byte and packet limits for this network device function.
	Container	object	The resource limits allocated to this container.
<b>Line1</b>	Circuit (PolyPhaseCurrentAmps), Outlet (PolyPhaseCurrentAmps), PowerSupplyMetrics (PolyPhaseCurrentAmps)	object	Line 1 current (A).
<b>Line1ToLine2</b>	Circuit (PolyPhaseEnergykWh)	object	The Line 1 to Line 2 energy (kWh) for this circuit.
	PowerSupplyMetrics (PolyPhaseEnergykWh)	object	The Line 1 to Line 2 energy (kWh) for this power supply.
	Circuit (PolyPhasePowerWatts)	object	The Line 1 to Line 2 power (W) for this circuit.
	PowerSupplyMetrics (PolyPhasePowerWatts)	object	The Line 1 to Line 2 power (W) for this power supply.
	Circuit (PolyPhaseVoltage)	object	The Line 1 to Line 2 voltage (V) for this circuit.
	Outlet (PolyPhaseVoltage)	object	The Line 1 to Line 2 voltage (V) for this outlet.
	PowerSupplyMetrics (PolyPhaseVoltage)	object	The Line 1 to Line 2 voltage (V) for this power supply.
<b>Line1ToNeutral</b>	Circuit (PolyPhaseEnergykWh)	object	The Line 1 to Neutral energy (kWh) for this circuit.
	PowerSupplyMetrics (PolyPhaseEnergykWh)	object	The Line 1 to Neutral energy (kWh) for this power supply.
	Circuit (PolyPhasePowerWatts)	object	The Line 1 to Neutral power (W) for this circuit.
	PowerSupplyMetrics (PolyPhasePowerWatts)	object	The Line 1 to Neutral power (W) for this power supply.

Property Name	Defined In Schema(s)	Type	Description
	Circuit (PolyPhaseVoltage)	object	The Line 1 to Neutral voltage (V) for this circuit.
	Outlet (PolyPhaseVoltage)	object	The Line 1 to Neutral voltage (V) for this outlet.
	PowerSupplyMetrics (PolyPhaseVoltage)	object	The Line 1 to Neutral voltage (V) for this power supply.
<b>Line2</b>	Circuit (PolyPhaseCurrentAmps), Outlet (PolyPhaseCurrentAmps), PowerSupplyMetrics (PolyPhaseCurrentAmps)	object	Line 2 current (A).
<b>Line2ToLine3</b>	Circuit (PolyPhaseEnergykWh)	object	The Line 2 to Line 3 energy (kWh) for this circuit.
	PowerSupplyMetrics (PolyPhaseEnergykWh)	object	The Line 2 to Line 3 energy (kWh) for this power supply.
	Circuit (PolyPhasePowerWatts)	object	The Line 2 to Line 3 power (W) for this circuit.
	PowerSupplyMetrics (PolyPhasePowerWatts)	object	The Line 2 to Line 3 power (W) for this power supply.
	Circuit (PolyPhaseVoltage)	object	The Line 2 to Line 3 voltage (V) for this circuit.
	Outlet (PolyPhaseVoltage)	object	The Line 2 to Line 3 voltage (V) for this outlet.
	PowerSupplyMetrics (PolyPhaseVoltage)	object	The Line 2 to Line 3 voltage (V) for this power supply.
<b>Line2ToNeutral</b>	Circuit (PolyPhaseEnergykWh)	object	The Line 2 to Neutral energy (kWh) for this circuit.
	PowerSupplyMetrics (PolyPhaseEnergykWh)	object	The Line 2 to Neutral energy (kWh) for this power supply.
	Circuit (PolyPhasePowerWatts)	object	The Line 2 to Neutral power (W) for this circuit.
	PowerSupplyMetrics (PolyPhasePowerWatts)	object	The Line 2 to Neutral power (W) for this power supply.
	Circuit (PolyPhaseVoltage)	object	The Line 2 to Neutral voltage (V) for this circuit.

Property Name	Defined In Schema(s)	Type	Description
	Outlet (PolyPhaseVoltage)	object	The Line 2 to Neutral voltage (V) for this outlet.
	PowerSupplyMetrics (PolyPhaseVoltage)	object	The Line 2 to Neutral voltage (V) for this power supply.
<b>Line3</b>	Circuit (PolyPhaseCurrentAmps), Outlet (PolyPhaseCurrentAmps), PowerSupplyMetrics (PolyPhaseCurrentAmps)	object	Line 3 current (A).
<b>Line3ToLine1</b>	Circuit (PolyPhaseEnergykWh)	object	The Line 3 to Line 1 energy (kWh) for this circuit.
	PowerSupplyMetrics (PolyPhaseEnergykWh)	object	The Line 3 to Line 1 energy (kWh) for this power supply.
	Circuit (PolyPhasePowerWatts)	object	The Line 3 to Line 1 power (W) for this circuit.
	PowerSupplyMetrics (PolyPhasePowerWatts)	object	The Line 3 to Line 1 power (W) for this power supply.
	Circuit (PolyPhaseVoltage)	object	The Line 3 to Line 1 voltage (V) for this circuit.
	Outlet (PolyPhaseVoltage)	object	The Line 3 to Line 1 voltage (V) for this outlet.
	PowerSupplyMetrics (PolyPhaseVoltage)	object	The Line 3 to Line 1 voltage (V) for this power supply.
<b>Line3ToNeutral</b>	Circuit (PolyPhaseEnergykWh)	object	The Line 3 to Neutral energy (kWh) for this circuit.
	PowerSupplyMetrics (PolyPhaseEnergykWh)	object	The Line 3 to Neutral energy (kWh) for this power supply.
	Circuit (PolyPhasePowerWatts)	object	The Line 3 to Neutral power (W) for this circuit.
	PowerSupplyMetrics (PolyPhasePowerWatts)	object	The Line 3 to Neutral power (W) for this power supply.
	Circuit (PolyPhaseVoltage)	object	The Line 3 to Neutral voltage (V) for this circuit.
	Outlet (PolyPhaseVoltage)	object	The Line 3 to Neutral voltage (V) for this outlet.

Property Name	Defined In Schema(s)	Type	Description
	PowerSupplyMetrics (PolyPhaseVoltage)	object	The Line 3 to Neutral voltage (V) for this power supply.
<b>LineInputStatus</b>	PowerSupply	string (enum)	The status of the line input.
<b>LineInputVoltage</b>	Power (PowerSupplies)	number (volts)	The line input voltage at which the power supply is operating.
<b>LineInputVoltageType</b>	Power (PowerSupplies)	string (enum)	The line voltage type supported as an input to this power supply.
<b>LinkConfiguration</b>	Port	array	The static capabilities and configuration settings of this port.
<b>LinkFailures</b>	PortMetrics (FibreChannel)	integer	The total number of link failures.
<b>LinkNetworkTechnology</b>	Port	string (enum)	The current link network technology for this port.
	NetworkPort (SupportedLinkCapabilities)	string (enum)	The link network technology capabilities of this port.
	Port (LinkConfiguration)	string (enum)	The link network technology for this link configuration.
<b>LinkNTE</b>	PortMetrics (GenZ)	integer	The total number of link-local non-transient errors detected.
<b>Links</b>	ServiceRoot (ProtocolFeaturesSupported > ExpandQuery)	boolean	An indication of whether this service supports the tilde ( ~ ) option of the <code>\$expand</code> query parameter.
	Task, Volume	object	Contains references to other resources that are related to this resource.
	<i>various</i> (AccelerationFunction, AddressPool ... )	object	The links to other resources that are related to this resource.
<b>LinkSpeedGbps</b>	NetworkAdapter (PortSplitting > CurrentConfiguration), NetworkAdapter (PortSplitting > SupportedConfigurations > Subconfigurations)	array	The configured link speed for each subport.
<b>LinkSpeedMbps</b>	NetworkPort (SupportedLinkCapabilities)	integer (Mbit/s)	The speed of the link in Mbit/s when this link network technology is active.

Property Name	Defined In Schema(s)	Type	Description
<b>LinkState</b>	Port	string (enum)	The desired link state for this interface.
<b>LinkStatus</b>	Port	string (enum)	The link status for this interface.
	EthernetInterface	string (enum)	The link status of this interface, or port.
	NetworkPort	string (enum)	The status of the link between this port and its link partner.
<b>LinkTransitionIndicator</b>	Port	integer	The number of link state transitions for this interface.
<b>LLDPEnabled</b>	NetworkAdapter	boolean	Enable or disable LLDP globally for an adapter.
	Port (Ethernet)	boolean	Enable/disable LLDP for this port.
<b>LLDPReceive</b>	Port (Ethernet)	object	LLDP data being received on this link.
<b>LLDPTransmit</b>	Port (Ethernet)	object	LLDP data being transmitted on this link.
<b>LLRRecovery</b>	PortMetrics (GenZ)	integer	The total number of times Link-Level Reliability (LLR) recovery has been initiated.
<b>LoaderTimeSeconds</b>	ManagerDiagnosticData (BootTimeStatistics)	number	The number of seconds the manager spent in the loader stage.
<b>LoadPercent</b>	PowerSupply (EfficiencyRatings)	number (%)	The electrical load for this rating.
	Sensor	number (%)	The power load utilization for this sensor.
<b>LocalAccountAuth</b>	AccountService	string (enum)	An indication of how the service uses the accounts collection within this account service as part of authentication. The enumerated values describe the details for each mode.

Property Name	Defined In Schema(s)	Type	Description
<b>LocalAccountTypes</b>	AccountService (ActiveDirectory > RemoteRoleMapping), AccountService (LDAP > RemoteRoleMapping), AccountService (OAuth2 > RemoteRoleMapping), AccountService (TACACSplus > RemoteRoleMapping), ExternalAccountProvider (RemoteRoleMapping)	array	The list of local services in the manager that the remote user or group is allowed to access.
<b>LocalAS</b>	AddressPool (Ethernet > EBGp > BGPNeighbor), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor)	integer	Local Autonomous System (AS) number.
<b>LocalDHCHAPAuthSecret</b>	Connection (ConnectionKeys > DHCHAP)	string	The local DHCHAP authentication secret. The value is <code>null</code> in responses.
<b>LocalEncryptionKeyIdentifier</b>	Storage	string	The local encryption key identifier used by the storage subsystem.
<b>LocalImage</b>	UpdateService (Actions > SimpleUpdate (Action))	boolean	An indication of whether the service adds the image to the local image store.
<b>LocalImageStore</b>	UpdateService	object	An inventory of locally stored images.
<b>LocalImageStoreAvailableCapacityBytes</b>	UpdateService	integer	The number of bytes currently available in the local image store.
<b>LocalImageStoreTotalCapacityBytes</b>	UpdateService	integer	The total number of bytes available to the local image store.
<b>LocalMemoryBandwidthBytes</b>	ProcessorMetrics	integer (bytes)	The local memory bandwidth usage in bytes.
<b>LocalMultiplier</b>	AddressPool (Ethernet > BFDSingleHopOnly)	integer	Bidirectional Forwarding Detection (BFD) multiplier value.

Property Name	Defined In Schema(s)	Type	Description
<b>LocalOEMAccountTypes</b>	AccountService (ActiveDirectory > RemoteRoleMapping), AccountService (LDAP > RemoteRoleMapping), AccountService (OAuth2 > RemoteRoleMapping), AccountService (TACACSplus > RemoteRoleMapping), ExternalAccountProvider (RemoteRoleMapping)	array	The OEM account types for the remote user or group.
<b>LocalPorts</b>	Endpoint (Links)	array	An array of links to the device ports that this endpoint represents.
<b>LocalRole</b>	AccountService (ActiveDirectory > RemoteRoleMapping), AccountService (LDAP > RemoteRoleMapping), AccountService (OAuth2 > RemoteRoleMapping), AccountService (TACACSplus > RemoteRoleMapping), ExternalAccountProvider (RemoteRoleMapping)	string	The name of the local Redfish role to which to map the remote user or group.
<b>Location</b>	JsonSchemaFile	array	Location information for this schema file.
	MessageRegistryFile	array	The location information for this registry file.
	Drive	array	The location of the drive.
	Control	object	The location information for this control.
	LeakDetector	object	The location information for this leak detector.
	Sensor	object	The location information for this sensor.
	Drive (Location)	object	The location of a resource.
	Assembly (Assemblies), Cable	object	The location of the assembly.
	Battery	object	The location of the battery.
	Chassis	object	The location of the chassis.
	CoolingUnit, PowerDistribution	object	The location of the equipment.

Property Name	Defined In Schema(s)	Type	Description
	FabricAdapter	object	The location of the fabric adapter.
	Facility	object	The location of the facility.
	Fan, Thermal (Fans)	object	The location of the fan.
	Filter	object	The location of the filter.
	GraphicsController	object	The location of the graphics controller.
	Heater	object	The location of the heater.
	Manager	object	The location of the manager.
	Memory	object	The location of the memory device.
	NetworkAdapter (Controllers)	object	The location of the network adapter controller.
	NetworkAdapter	object	The location of the network adapter.
	PCleDevice (Slot), PCIeSlots (Slots)	object	The location of the PCIe slot.
	Port	object	The location of the port.
	Power (PowerSupplies), PowerSupply	object	The location of the power supply.
	Processor	object	The location of the processor.
	Pump	object	The location of the pump.
	Reservoir	object	The location of the reservoir.
	Storage (StorageControllers), StorageController	object	The location of the storage controller.
	Switch	object	The location of the switch.
	TrustedComponent	object	The location of the trusted component.
<b>LocationIndicatorActive</b>	<i>various</i> (Assembly (Assemblies), Battery ... )	boolean	An indicator allowing an operator to physically locate this resource.
<b>Lockdown</b>	Drive (NVMe > ConfigurationLockState), Storage (NVMeSubsystemProperties > ConfigurationLockState)	string (enum)	The lock state of the NVMe-defined Lockdown command.

Property Name	Defined In Schema(s)	Type	Description
<b>Locked</b>	ManagerAccount	boolean	An indication of whether the account service automatically locked the account because the lockout threshold was exceeded. To manually unlock the account before the lockout duration period, an administrator can change the property to <code>false</code> to clear the lockout condition.
	Chassis (Doors > Front), Chassis (Doors > Rear)	boolean	Indicates if the door is locked.
<b>Log</b>	JobService	object	The link to a log service that the job service uses. This service can be a dedicated log service or a pointer to a log service under another resource, such as a manager.
	CXLLogicalDevice	object	The link to the log service associated with this CXL logical device.
	Memory	object	The link to the log service associated with this memory.
<b>LogEntriesETag</b>	LogService (Actions > ClearLog (Action))	string	The ETag of the log entry collection within this log service. If the provided ETag does not match the current ETag of the log entry collection, the request is rejected.
<b>LogEntry</b>	Event (Events)	object	The link to a log entry if an entry was created for this event.
<b>LogEntryType</b>	LogService	string (enum)	The format of the log entries.
<b>LogFacilities</b>	EventDestination (SyslogFilters), LogService (SyslogFilters)	array	The types of programs that can log messages.
<b>LogicalContexts</b>	MetricDefinition	array	The logical contexts related to the metric.
<b>LogicalProcessorCount</b>	ComputerSystem (ProcessorSummary)	integer	The number of logical processors in the system.
<b>LogicalSizeMiB</b>	Memory	integer (mebibytes)	Total size of the logical memory in MiB.

Property Name	Defined In Schema(s)	Type	Description
<b>LogicalUnitNumber</b>	Volume	integer	Indicates the host-visible LogicalUnitNumber assigned to this Volume.
<b>LogPurposes</b>	LogService	array	The purposes of the log.
<b>LogService</b>	TelemetryService	object	The link to a log service that the telemetry service uses. This service can be a dedicated log service or a pointer to a log service under another resource, such as a manager.
<b>LogServices</b>	Manager	object	The link to a collection of logs that the manager uses.
	Switch	object	The link to the collection of log services associated with this switch.
	ComputerSystem	object	The link to the collection of log services associated with this system.
	Chassis	object	The link to the logs for this chassis.
<b>LogStateChangesEnabled</b>	AddressPool (Ethernet > EBGp > BGPNeighbor), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor)	boolean	Border Gateway Protocol (BGP) neighbor log state change status.
<b>LoopbackAddressRange</b>	AddressPool (Ethernet > IPv4)	object	Loopback-related IPv4 addressing for this Ethernet fabric.
<b>LossesOfSignal</b>	PortMetrics (FibreChannel)	integer	The total number of losses of signal.
<b>LossesOfSync</b>	PortMetrics (FibreChannel)	integer	The total number of losses of sync.
<b>LossOfDwordSynchronizationCount</b>	PortMetrics (SAS)	integer	The number of times the phy has restarted the link reset sequence because it lost dword synchronization.
<b>Lower</b>	AddressPool (Ethernet > EBGp > ASNumberRange), AddressPool (Ethernet > MultiProtocolEBGP > ASNumberRange), AddressPool (Ethernet > MultiProtocolIBGP > ASNumberRange)	integer	Lower Autonomous System (AS) number.

Property Name	Defined In Schema(s)	Type	Description
	AddressPool (Ethernet > BGPEvpn > ESINumberRange)	integer	Lower Ethernet Segment Identifier (ESI) number.
	AddressPool (Ethernet > BGPEvpn > EVINumberRange)	integer	Lower Ethernet Virtual Private Network (EVPN) Instance (EVI) number.
	AddressPool (Ethernet > BGPEvpn > RouteDistinguisherRange)	integer	Lower Route Distinguisher (RD) number.
	AddressPool (Ethernet > BGPEvpn > RouteTargetRange)	integer	Lower Route Target (RT) number.
	AddressPool (Ethernet > BGPEvpn > VLANIdentifierAddressRange), AddressPool (Ethernet > IPv4 > VLANIdentifierAddressRange)	integer	Virtual LAN (VLAN) tag lower value.
	AddressPool (Ethernet > IPv4 > EBGPAAddressRange), AddressPool (Ethernet > IPv4 > FabricLinkAddressRange), AddressPool (Ethernet > IPv4 > HostAddressRange), AddressPool (Ethernet > IPv4 > IBGPAAddressRange), AddressPool (Ethernet > IPv4 > LoopbackAddressRange), AddressPool (Ethernet > IPv4 > ManagementAddressRange)	string	Lower IPv4 network address.
	AddressPool (Ethernet > BGPEvpn > GatewayIPAddressRange)	string	The lower IPv4 address.
	AddressPool (Ethernet > IPv4 > SystemMACRange)	string	The lower system MAC address.
<b>LowerBound</b>	AttributeRegistry (RegistryEntries > Attributes)	integer	The lower limit for an integer attribute.
<b>LowerCaution</b>	Sensor (Thresholds)	object	The value at which the reading is below normal range.
<b>LowerCautionUser</b>	Sensor (Thresholds)	object	A user-defined value at which the reading is considered below normal range.
<b>LowerCritical</b>	Triggers (NumericThresholds)	object	The value at which the reading is below normal range and requires attention.

Property Name	Defined In Schema(s)	Type	Description
	DriveMetrics (PredictedMediaLifeLeftPercent > Thresholds), Sensor (Thresholds)	object	The value at which the reading is below normal range but not yet fatal.
<b>LowerCriticalUser</b>	DriveMetrics (PredictedMediaLifeLeftPercent > Thresholds), Sensor (Thresholds)	object	A user-defined value at which the reading is considered below normal range but not yet fatal.
<b>LowerFatal</b>	Sensor (Thresholds)	object	The value at which the reading is below normal range and fatal.
<b>LowerThresholdCritical</b>	Thermal (Fans)	integer	The value at which the reading is below normal range but not yet fatal.
	Thermal (Temperatures)	number (Celsius)	The value at which the reading is below normal range but not yet fatal.
	Power (Voltages)	number (volts)	The value at which the reading is below normal range but not yet fatal.
<b>LowerThresholdFatal</b>	Thermal (Fans)	integer	The value at which the reading is below normal range and fatal.
	Thermal (Temperatures)	number (Celsius)	The value at which the reading is below normal range and fatal.
	Power (Voltages)	number (volts)	The value at which the reading is below normal range and fatal.
<b>LowerThresholdNonCritical</b>	Thermal (Fans)	integer	The value at which the reading is below normal range.
	Thermal (Temperatures)	number (Celsius)	The value at which the reading is below normal range.
	Power (Voltages)	number (volts)	The value at which the reading is below normal range.
<b>LowerThresholdUser</b>	Thermal (Temperatures)	integer (Celsius)	The value at which the reading is below the user-defined range.
<b>LowerWarning</b>	Triggers (NumericThresholds)	object	The value at which the reading is below normal range.
<b>LowestIntervalReading</b>	Sensor	number	The lowest sensor value over a time interval.
<b>LowestReading</b>	Sensor	number	The lowest sensor value.

Property Name	Defined In Schema(s)	Type	Description
<b>LowestReadingTime</b>	Sensor	string	The time when the lowest sensor value occurred.
<b>LowestSeverity</b>	EventDestination (SyslogFilters)	string (enum)	The lowest severity level message that will be forwarded.
	LogService (SyslogFilters)	string (enum)	The lowest severity level message that will be logged.
<b>LowestSupportedVersion</b>	SoftwareInventory	string	The lowest supported version of this software.
<b>LowSpaceWarningThresholdPercents</b>	Volume	array (%)	Low space warning.
<b>LPRT</b>	Port (GenZ)	object	The Linear Packet Relay Table for the port.
<b>LUN</b>	Connection (Actions > RemoveVolumeInfo (Action))	integer	The initiator-visible logical unit number (LUN) assigned to the volume to remove.
	Connection (VolumeInfo)	integer	The initiator-visible logical unit number (LUN) assigned to this volume.
	Connection (Actions > AddVolumeInfo (Action))	integer	The initiator-visible logical unit number (LUN) to assign to the volume. Clients are required to provide either <code>LUN</code> , <code>AccessCapabilities</code> , or both.
<b>LUNID</b>	NetworkDeviceFunction (FibreChannel > BootTargets)	string	The logical unit number (LUN) ID from which to boot on the device to which the corresponding WWPN refers.
<b>MACAddress</b>	EthernetInterface	string	The currently configured MAC address of the interface, or logical port.
	NetworkDeviceFunction (Ethernet)	string	The currently configured MAC address.
<b>Machine</b>	OperatingSystem (Kernel)	string	The machine hardware name of the kernel.
<b>Mains</b>	PowerDistribution	object	A link to the power input circuits for this equipment.

Property Name	Defined In Schema(s)	Type	Description
<b>MainsRedundancy</b>	PowerDistribution	object	The redundancy information for the mains (input) circuits for this equipment.
<b>MaintenanceWindowDurationInSeconds</b>	UpdateService (HttpPushUriOptions > HttpPushUriApplyTime)	integer (seconds)	The expiry time, in seconds, of the maintenance window.
<b>MaintenanceWindowStartTime</b>	UpdateService (HttpPushUriOptions > HttpPushUriApplyTime)	string	The start time of a maintenance window.
<b>ManagedBy</b>	Chassis (Links)	array	An array of links to the managers responsible for managing this chassis.
	CoolingLoop (Links), CoolingUnit (Links), PowerDistribution (Links)	array	An array of links to the managers responsible for managing this equipment.
	Fabric (Links)	array	An array of links to the managers responsible for managing this fabric.
	Facility (Links)	array	An array of links to the managers responsible for managing this facility.
	PowerDomain (Links)	array	An array of links to the managers responsible for managing this power domain.
	PowerEquipment (Links)	array	An array of links to the managers responsible for managing this power equipment.
	ComputerSystem (Links)	array	An array of links to the managers responsible for this system.
	Switch (Links)	array	An array of links to the managers that manage this switch.
	Manager (Links)	array	The array of links to the managers responsible for managing this manager.
<b>ManagedResources</b>	RegisteredClient	array	An array of resources that the registered client monitors or configures.
<b>ManagedResourceURI</b>	RegisteredClient (ManagedResources)	string	The URI of the resource or resource collection managed by the registered client.

Property Name	Defined In Schema(s)	Type	Description
<b>ManagementAddressIPv4</b>	Port (Ethernet > LLDPReceive)	string	The IPv4 management address received from the remote partner across this link.
	Port (Ethernet > LLDPTransmit)	string	The IPv4 management address to be transmitted from this endpoint.
<b>ManagementAddressIPv6</b>	Port (Ethernet > LLDPReceive)	string	The IPv6 management address received from the remote partner across this link.
	Port (Ethernet > LLDPTransmit)	string	The IPv6 management address to be transmitted from this endpoint.
<b>ManagementAddressMAC</b>	Port (Ethernet > LLDPReceive)	string	The management MAC address received from the remote partner across this link.
	Port (Ethernet > LLDPTransmit)	string	The management MAC address to be transmitted from this endpoint.
<b>ManagementAddressRange</b>	AddressPool (Ethernet > IPv4)	object	Management-related addressing for this Ethernet fabric.
<b>ManagementInterfaceType</b>	Port (SFP)	string (enum)	The type of management interface for this transceiver.
<b>ManagementURIs</b>	OperatingSystem (ContainerEngines)	array	The URIs to manage this container engine.
	OperatingSystem (VirtualMachineEngines)	array	The URIs to manage this virtual machine engine.
<b>ManagementVlanId</b>	Port (Ethernet > LLDPReceive)	integer	The management VLAN ID received from the remote partner across this link.
	Port (Ethernet > LLDPTransmit)	integer	The management VLAN ID to be transmitted from this endpoint.
<b>ManagerDiagnosticData</b>	Manager	object	The diagnostic data for this manager.
<b>ManagerEthernetInterface</b>	HostInterface	object	A link to a single network interface controllers or cards (NIC) that this manager uses for network communication with this host interface.
<b>ManagerForChassis</b>	Manager (Links)	array	An array of links to the chassis this manager controls.

Property Name	Defined In Schema(s)	Type	Description
<b>ManagerForFabrics</b>	Manager (Links)	array	An array of links to the fabrics that this manager controls.
<b>ManagerForManagers</b>	Manager (Links)	array	An array of links to the managers that are managed by this manager.
<b>ManagerForServers</b>	Manager (Links)	array	An array of links to the systems that this manager controls.
<b>ManagerForSwitches</b>	Manager (Links)	array	An array of links to the switches that this manager controls.
<b>ManagerInChassis</b>	Manager (Links)	object	The link to the chassis where this manager is located.
<b>ManagerProvidingService</b>	ServiceRoot (Links)	object	The link to the manager that is providing this Redfish service.
<b>Managers</b>	Heater (Links)	array	An array of links to the managers heated by this heater.
	ServiceRoot	object	The link to a collection of managers.
<b>ManagersInChassis</b>	Chassis (Links)	array	An array of links to the managers located in this chassis.
<b>ManagerType</b>	Manager	string (enum)	The type of manager that this resource represents.
<b>Manifest</b>	CompositionService (Actions > Compose (Action))	object	The manifest containing the compose operation request.
	CompositionReservation	object	The manifest document processed by the service that resulted in this reservation.
<b>Manufacturer</b>	AccelerationFunction	string	The acceleration function code manufacturer.
	Battery	string	The manufacturer of this battery.
	Cable	string	The manufacturer of this cable.
	Chassis	string	The manufacturer of this chassis.
	CoolantConnector	string	The manufacturer of this component.
	Drive	string	The manufacturer of this drive.
	CoolingUnit, PowerDistribution	string	The manufacturer of this equipment.

Property Name	Defined In Schema(s)	Type	Description
	Fan, Thermal (Fans)	string	The manufacturer of this fan.
	Filter	string	The manufacturer of this filter.
	GraphicsController	string	The manufacturer of this graphics controller.
	Heater	string	The manufacturer of this heater.
	LeakDetector	string	The manufacturer of this leak detector.
	Manager	string	The manufacturer of this manager.
	MediaController	string	The manufacturer of this media controller.
	PCleDevice	string	The manufacturer of this PCIe device.
	Power (PowerSupplies), PowerSupply	string	The manufacturer of this power supply.
	Pump	string	The manufacturer of this pump.
	Reservoir	string	The manufacturer of this reservoir.
	Sensor	string	The manufacturer of this sensor.
	Storage (StorageControllers), StorageController	string	The manufacturer of this storage controller.
	Switch	string	The manufacturer of this switch.
	Port (SFP)	string	The manufacturer of this transceiver.
	TrustedComponent	string	The manufacturer of this trusted component.
	USBController	string	The manufacturer of this USB controller.
	FabricAdapter	string	The manufacturer or OEM of this fabric adapter.
	NetworkAdapter	string	The manufacturer or OEM of this network adapter.
	Volume	string	The manufacturer or OEM of this storage volume.

Property Name	Defined In Schema(s)	Type	Description
	ComputerSystem	string	The manufacturer or OEM of this system.
	License	string	The manufacturer or producer of this license.
	SoftwareInventory	string	The manufacturer or producer of this software.
	Memory	string	The memory device manufacturer.
	SimpleStorage (Devices)	string	The name of the manufacturer of this device.
	Processor	string	The processor manufacturer.
<b>ManufacturingMode</b>	ComputerSystem	boolean	An indication of whether the system is in manufacturing mode. Manufacturing mode is a special boot mode, not normally available to end users, that modifies features and settings for use while the system is being manufactured and tested.
<b>MapFrom</b>	AttributeRegistry (RegistryEntries > Dependencies > Dependency)	array	An array of the map-from conditions for a mapping dependency.
<b>MapFromAttribute</b>	AttributeRegistry (RegistryEntries > Dependencies > Dependency > MapFrom)	string	The attribute to use to evaluate this dependency expression.
<b>MapFromCondition</b>	AttributeRegistry (RegistryEntries > Dependencies > Dependency > MapFrom)	string (enum)	The condition to use to evaluate this dependency expression.
<b>MapFromProperty</b>	AttributeRegistry (RegistryEntries > Dependencies > Dependency > MapFrom)	string (enum)	The metadata property for the attribute that the <code>MapFromAttribute</code> property specifies to use to evaluate this dependency expression.
<b>MapFromValue</b>	AttributeRegistry (RegistryEntries > Dependencies > Dependency > MapFrom)	boolean, number, string	The value to use to evaluate this dependency expression.
<b>Mappings</b>	PrivilegeRegistry	array	The mappings between entities and the relevant privileges that access those entities.

Property Name	Defined In Schema(s)	Type	Description
<b>MapTerms</b>	AttributeRegistry (RegistryEntries > Dependencies > Dependency > MapFrom)	string (enum)	The logical term that combines two or more map-from conditions in this dependency expression. For example, <code>AND</code> for logical AND, or <code>OR</code> for logical OR.
<b>MapToAttribute</b>	AttributeRegistry (RegistryEntries > Dependencies > Dependency)	string	The <code>AttributeName</code> of the attribute that is affected by this dependency expression.
<b>MapToProperty</b>	AttributeRegistry (RegistryEntries > Dependencies > Dependency)	string (enum)	The metadata property for the attribute that contains the map-from condition that evaluates this dependency expression.
<b>MapToValue</b>	AttributeRegistry (RegistryEntries > Dependencies > Dependency)	boolean, number, string	The value that the map-to property changes to if the dependency expression evaluates to <code>true</code> .
<b>MarkedECN</b>	PortMetrics (GenZ)	integer	The number of packets with the Congestion ECN bit set.
<b>MasterPassphraseAttemptCountReached</b>	Memory (SecurityStates)	boolean	An indication of whether an incorrect master passphrase attempt count has been reached.
<b>MasterPassphraseEnabled</b>	Memory (Regions)	boolean	An indication of whether the master passphrase is enabled for this region.
<b>MaxAllowableOperatingValue</b>	Thermal (Temperatures)	integer (Celsius)	Maximum allowable operating temperature for this equipment.
	Sensor	number	The maximum allowable operating value for this equipment.
<b>MaxAttachedNamespaces</b>	StorageController (NVMeControllerProperties)	integer	The maximum number of attached namespaces allowed by this NVMe I/O controller.
<b>MaxAuthorizedDevices</b>	License	integer	The maximum number of devices authorized by the license.
<b>MaxBandwidthGbps</b>	Switch	number (Gbit/s)	The maximum internal bandwidth of this switch as currently configured.
<b>MaxBlockSizeBytes</b>	Volume	integer (bytes)	Max Block size in bytes.

Property Name	Defined In Schema(s)	Type	Description
<b>MaxBWAllocPercent</b>	NetworkPort (NetDevFuncMaxBWAlloc)	integer (%)	The maximum bandwidth allocation percentage allocated to the corresponding network device function instance.
<b>MaxChargeRateAmps</b>	Battery	number (A)	The maximum charge rate at the input of this battery in amp units.
<b>MaxChargeVoltage</b>	Battery	number (volts)	The maximum charge voltage across the cell pack of this battery when it is fully charged.
<b>MaxCID</b>	AddressPool (GenZ)	integer	The maximum value for the Component Identifier (CID).
<b>MaxCompositions</b>	ResourceBlock (CompositionStatus)	integer	The maximum number of compositions in which this resource block can participate simultaneously.
<b>MaxConcurrentSessions</b>	Manager (CommandShell), Manager (GraphicalConsole), Manager (SerialConsole)	integer	The maximum number of service sessions, regardless of protocol, that this manager can support.
	ComputerSystem (GraphicalConsole), ComputerSystem (SerialConsole)	integer	The maximum number of service sessions, regardless of protocol, that this system can support.
<b>MaxConsumedWatts</b>	Power (PowerControl > PowerMetrics)	number (watts)	The highest power consumption level, in watt units, that has occurred over the measurement window within the last <code>IntervalInMin</code> minutes.
<b>MaxDeviceLogins</b>	NetworkAdapter (Controllers > ControllerCapabilities > NPIV)	integer	The maximum number of N_Port ID Virtualization (NPIV) logins allowed simultaneously from all ports on this controller.
<b>MaxDischargeRateAmps</b>	Battery	number (A)	The maximum discharge rate at the output of this battery in amp units.
<b>MaxDynamicCapacityRegions</b>	PCleDevice (CXLDevice > DynamicCapacity)	integer	The maximum number of dynamic capacity memory regions available per host from this CXL device.
<b>MaxExecutionTime</b>	Job	string	The maximum amount of time the job is allowed to execute.

Property Name	Defined In Schema(s)	Type	Description
<b>MaxFrameSize</b>	NetworkPort, Port	integer (bytes)	The maximum frame size supported by the port.
<b>MaxHosts</b>	PCleDevice (CXLDevice > DynamicCapacity)	integer	The maximum number of hosts supported by this CXL device.
<b>MaxImageSizeBytes</b>	UpdateService	integer (bytes)	The maximum size in bytes of the software update image that this service supports.
<b>MaximumConcurrentJobs</b>	JobExecutor	integer	The maximum concurrent jobs this executor can process.
<b>MaximumConnectedClients</b>	ManagerNetworkProtocol (Modbus)	integer	The maximum number of simultaneously connected clients.
<b>MaximumFrequencyHz</b>	Power (PowerSupplies > InputRanges)	number (Hz)	The maximum line input frequency at which this power supply input range is effective.
<b>MaximumPaths</b>	AddressPool (Ethernet > EBGp > MultiplePaths), AddressPool (Ethernet > MultiProtocolEBGP > MultiplePaths), AddressPool (Ethernet > MultiProtocolIBGP > MultiplePaths)	integer	Maximum paths number.
<b>MaximumSubports</b>	NetworkAdapter (PortSplitting)	integer	The maximum number of subdivided ports that this controller supports.
<b>MaximumSubportsPerPort</b>	NetworkAdapter (PortSplitting)	integer	The maximum number of subdivided ports split from a single physical port that this controller supports.
<b>MaximumSupportedPhysicalFunctions</b>	Storage (MPF)	integer	The maximum number of physical functions supported by the storage controller in this storage subsystem.
<b>MaximumValue</b>	ActionInfo (Parameters), JobDocument (ParameterMetadata)	number	The maximum supported value for this parameter.
<b>MaximumVoltage</b>	Power (PowerSupplies > InputRanges)	number (volts)	The maximum line input voltage at which this power supply input range is effective.
<b>MaxIPv6StaticAddresses</b>	EthernetInterface	integer	The maximum number of static IPv6 addresses that can be configured on this interface.

Property Name	Defined In Schema(s)	Type	Description
<b>MaxJobs</b>	JobService (ServiceCapabilities)	integer	The maximum number of jobs supported.
<b>MaxJunctionTemperatureCelsius</b>	OperatingConfig	integer (Celsius)	The maximum temperature of the junction in degree Celsius units.
<b>MaxLanes</b>	Processor (FPGA > ExternalInterfaces > Ethernet), Processor (FPGA > HostInterface > Ethernet), Processor (SystemInterface > Ethernet)	integer	The number of lanes supported by this interface.
	PCIeDevice (PCIeInterface)	integer	The number of PCIe lanes supported by this device.
<b>MaxLength</b>	AttributeRegistry (RegistryEntries > Attributes)	integer	The maximum character length of a string attribute.
<b>MaxLevels</b>	ServiceRoot (ProtocolFeaturesSupported > ExpandQuery)	integer	The maximum <code>\$levels</code> option value in the <code>\$expand</code> query parameter.
	ServiceRoot (ProtocolFeaturesSupported > DeepOperations)	integer	The maximum levels of resources allowed in deep operations.
<b>MaxLogicalDeviceCount</b>	Port (CXL)	integer	The maximum number of logical devices supported.
<b>MaxNamespacesSupported</b>	Storage (NVMeSubsystemProperties)	number	The maximum number of namespace attachments supported by this NVMe subsystem.
<b>MaxNumberLogicalDevices</b>	PCIeDevice (CXLDevice)	integer	The maximum number of logical devices supported by this CXL device.
<b>MaxNumberOfRecords</b>	LogService	integer	The maximum number of log entries that this service can have.
<b>MaxPassphraseCount</b>	Memory (SecurityCapabilities)	integer	Maximum number of passphrases supported for this memory device.
<b>MaxPasswordLength</b>	AccountService	integer	The maximum password length for this account service.
<b>MaxPCleType</b>	PCIeDevice (PCIeInterface)	string (enum)	The highest version of the PCIe specification supported by this device.

Property Name	Defined In Schema(s)	Type	Description
<b>MaxPortLogins</b>	NetworkAdapter (Controllers > ControllerCapabilities > NPIV)	integer	The maximum number of N_Port ID Virtualization (NPIV) logins allowed per physical port on this controller.
<b>MaxPowerWatts</b>	Chassis	number (watts)	The upper bound of the total power consumed by the chassis.
<b>MaxPrefix</b>	AddressPool (Ethernet > EBGp > BGPNeighbor), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor)	object	Border Gateway Protocol (BGP) max prefix properties.
<b>MaxPrefixNumber</b>	AddressPool (Ethernet > EBGp > BGPNeighbor > MaxPrefix), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor > MaxPrefix), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor > MaxPrefix)	integer	Maximum prefix number.
<b>MaxQueueSize</b>	StorageController (NVMeControllerProperties)	integer	The maximum individual queue size that an NVMe I/O controller supports.
<b>MaxReadingRange</b>	Thermal (Fans)	integer	Maximum value for this sensor.
	MetricDefinition	number	Maximum value for metric reading.
	Power (Voltages)	number (volts)	Maximum value for this sensor.
<b>MaxReadingRangeTemp</b>	Thermal (Temperatures)	number (Celsius)	Maximum value for this sensor.
<b>MaxReports</b>	TelemetryService	integer	The maximum number of metric reports that this service supports.
<b>MaxSID</b>	AddressPool (GenZ)	integer	The maximum value for the Subnet Identifier (SID).
<b>MaxSpeedGbps</b>	Port	number (Gbit/s)	The maximum speed of this port as currently configured.
<b>MaxSpeedMbps</b>	Processor (FPGA > ExternalInterfaces > Ethernet), Processor (FPGA > HostInterface > Ethernet), Processor (SystemInterface > Ethernet)	integer (Mbit/s)	The maximum speed supported by this interface.

Property Name	Defined In Schema(s)	Type	Description
<b>MaxSpeedMHz</b>	Processor	integer (MHz)	The maximum clock speed of the processor.
	OperatingConfig	integer (MHz)	The maximum clock speed to which the processor can be configured in MHz.
	OperatingConfig (TurboProfile)	integer (MHz)	The maximum turbo clock speed that correspond to the number of active cores in MHz.
<b>MaxSteps</b>	JobService (ServiceCapabilities)	integer	The maximum number of job steps supported.
<b>MaxSupportedPIDs</b>	Switch (CXL)	integer	The maximum number of port-based routing (PBR) identifiers (PIDs) supported in this switch.
<b>MaxSustainedRequestCmpBias</b>	Port (CXL > Congestion)	integer	The estimated maximum sustained sum of requests and recent responses across the entire device, serving as the basis for the CXL Specification-defined 'QoS Limit Fraction'.
<b>MaxTDPMilliWatts</b>	Memory	array (milliwatts)	Set of maximum power budgets supported by the memory device in milliwatt units.
	Memory (PowerManagementPolicy)	integer (milliwatts)	Maximum TDP in milliwatt units.
<b>MaxTDPWatts</b>	Processor	integer (watts)	The maximum Thermal Design Power (TDP) in watt units.
<b>MaxVCSsSupported</b>	Switch (CXL)	integer	The maximum number of Virtual CXL Switches (VCSs) supported in this switch.
<b>MaxVirtualFunctions</b>	NetworkDeviceFunction	integer	The number of virtual functions that are available for this network device function.
<b>MaxZones</b>	Fabric	integer	The maximum number of zones the switch can currently configure.
<b>mDNS</b>	ManagerNetworkProtocol	object	The settings for this manager's Multicast Domain Name Service (mDNS) protocol support.

Property Name	Defined In Schema(s)	Type	Description
<b>Measurement</b>	SoftwareInventory	object	A DSP0274-defined measurement block.
	SoftwareInventory (Measurement)	string	The hexadecimal string representation of the numeric value of the DSP0274-defined 'Measurement' field of the measurement block.
	ComponentIntegrity (SPDM > MeasurementSet > Measurements), ComponentIntegrity (TPM > MeasurementSet > Measurements)	string	The measurement data.
<b>MeasurementHashAlgorithm</b>	ComponentIntegrity (SPDM > MeasurementSet > Measurements), ComponentIntegrity (TPM > MeasurementSet > Measurements)	string	The hash algorithm used to compute the measurement.
<b>MeasurementIndex</b>	SoftwareInventory (Measurement)	integer	The DSP0274-defined 'Index' field of the measurement block.
	ComponentIntegrity (SPDM > MeasurementSet > Measurements)	integer	The index of the measurement.
<b>MeasurementIndices</b>	ComponentIntegrity (Actions > SPDMGetSignedMeasurements (Action))	array	An array of indices that identify the measurement blocks to sign.
<b>Measurements</b>	Chassis, ComputerSystem, Drive, Manager, Memory, NetworkAdapter, Processor, Storage (StorageControllers), StorageController, Switch	array	An array of DSP0274-defined measurement blocks.
	ComponentIntegrity (TPM > MeasurementSet)	array	Measurements from a TPM.
	ComponentIntegrity (SPDM > MeasurementSet)	array	Measurements from an SPDM Responder.
<b>MeasurementSet</b>	ComponentIntegrity (SPDM)	object	Measurement information about the SPDM Responder.
	ComponentIntegrity (TPM)	object	Measurement information from the TPM.
<b>MeasurementSize</b>	SoftwareInventory (Measurement)	integer	The DSP0274-defined 'MeasurementSize' field of the measurement block.

Property Name	Defined In Schema(s)	Type	Description
<b>MeasurementSpecification</b>	SoftwareInventory (Measurement)	integer	The DSP0274-defined 'MeasurementSpecification' field of the measurement block.
	ComponentIntegrity (SPDM > MeasurementSet)	string (enum)	The measurement specification negotiated between the SPDM Requester and SPDM Responder.
<b>MeasurementSummary</b>	ComponentIntegrity (SPDM > MeasurementSet)	string	The measurement summary data.
<b>MeasurementSummaryHashAlgorithm</b>	ComponentIntegrity (SPDM > MeasurementSet)	string	The hash algorithm used to compute the measurement summary.
<b>MeasurementSummaryType</b>	ComponentIntegrity (SPDM > MeasurementSet)	string (enum)	The type of measurement summary.
<b>MeasurementType</b>	ComponentIntegrity (SPDM > MeasurementSet > Measurements)	string (enum)	The type or characteristics of the data that this measurement represents.
<b>MED</b>	AddressPool (Ethernet > EBGp), AddressPool (Ethernet > MultiProtocolEBGP)	integer	BGP Multi Exit Discriminator (MED) value.
<b>MediaAndDataIntegrityErrors</b>	StorageControllerMetrics (NVMeSMART)	integer	The number of occurrences where the controller detected an unrecovered data integrity error.
<b>MediaControllers</b>	MemoryDomain (Links)	array	An array of links to the media controllers for this memory domain.
	Chassis	object	The link to the collection of media controllers located in this chassis.
<b>MediaControllerType</b>	MediaController	string (enum)	The type of media controller.
<b>MediaInReadOnly</b>	StorageController (NVMeControllerProperties > NVMeSMARTCriticalWarnings)	boolean	Indicates the media has been placed in read-only mode.
<b>MediaLocation</b>	MemoryChunks	string (enum)	The location of the memory media for this memory chunk.
<b>MediaSpanCount</b>	Volume	integer	Indicates the number of media elements used per span in the secondary RAID for a hierarchical RAID type.

Property Name	Defined In Schema(s)	Type	Description
	Volume (Actions > ChangeRAIDLAYOUT (Action))	integer	The requested number of media elements used per span in the secondary RAID for a hierarchical RAID type.
<b>MediaType</b>	Drive	string (enum)	The type of media contained in this drive.
<b>MediaTypes</b>	VirtualMedia	array	The media types supported as virtual media.
<b>MediumType</b>	Port (SFP)	string (enum)	The medium type connected to this transceiver.
<b>MemberId</b>	Power (Actions > PowerSupplyReset (Action))	string	The <code>MemberId</code> of the power supply within the <code>PowerSupplies</code> array on which to perform the reset.
	Assembly (Assemblies), Event (Events), Power (PowerControl), Power (PowerSupplies), Power (Voltages), Storage (StorageControllers), Thermal (Fans), Thermal (Temperatures)	string	The unique identifier for the member within an array.
<b>Memory</b>	Processor (Links)	array	An array of links to the memory associated with this processor.
	ResourceBlock	array	An array of links to the memory available in this resource block.
	Heater (Links)	array	An array of links to the memory devices heated by this heater.
	Battery (Links)	array	An array of links to the memory devices to which this battery provides power during a power-loss event.
	MemoryChunks (InterleaveSets)	object	Describes a memory device of the interleave set.
	ComputerSystem	object	The link to the collection of memory associated with this system.
	Chassis	object	The link to the collection of memory located in this chassis that belong to fabric-related resource pools.

Property Name	Defined In Schema(s)	Type	Description
<b>MemoryBlockSizesSupported</b>	PCIeDevice (CXLDevice > DynamicCapacity)	array	The set of memory block sizes supported by memory regions in this CXL device.
<b>MemoryBytes</b>	Container (Limits)	integer (bytes)	The amount of memory available to this container in bytes.
<b>MemoryChunk</b>	Connection (MemoryChunkInfo)	object	The specified memory chunk.
<b>MemoryChunkIncrementMiB</b>	MemoryDomain	integer (mebibytes)	The incremental size, from the minimum size, allowed for a memory chunk within this domain in mebibytes (MiB).
<b>MemoryChunkInfo</b>	Connection	array	The set of memory chunks and access capabilities specified for this connection.
<b>MemoryChunks</b>	CXLLogicalDevice (Links)	array	An array of links to the memory chunks owned by this CXL logical device.
	MemoryRegion	array	The set of memory chunks providing capacity for this memory region.
	MemoryExtent	array	The set of memory chunks that provide capacity for this memory extent.
	MemoryDomain	object	The link to the collection of memory chunks associated with this memory domain.
<b>MemoryChunkSizeMiB</b>	MemoryChunks	integer (mebibytes)	Size of the memory chunk measured in mebibytes (MiB).
<b>MemoryClassification</b>	Memory (Regions)	string (enum)	The classification of memory that the memory region occupies.
<b>MemoryController</b>	Memory (MemoryLocation)	integer	The memory controller number to which the memory device is connected.
<b>MemoryDeviceType</b>	Memory	string (enum)	Type details of the memory device.
<b>MemoryDomains</b>	CXLLogicalDevice (Links)	array	An array of links to the memory domains associated with this CXL logical device.

Property Name	Defined In Schema(s)	Type	Description
	FabricAdapter (Links)	array	An array of links to the memory domains associated with this fabric adapter.
	MediaController (Links)	array	An array of links to the memory domains associated with this media controller.
	PCleFunction (Links)	array	An array of links to the memory domains that the PCIe function produces.
	ComputerSystem	object	The link to the collection of memory domains associated with this system.
	Chassis	object	The link to the collection of memory domains located in this chassis that belong to fabric-related resource pools.
<b>MemoryECCStatistics</b>	ManagerDiagnosticData	object	The memory ECC statistics of the manager.
<b>MemoryExtent</b>	MemoryChunks (Links)	object	A link to the memory extent for which this memory chunk provides capacity.
<b>MemoryExtents</b>	MemoryRegion	array	The set of memory extents defined for this memory region.
	PCleDevice (CXLDevice > DynamicCapacity)	object	The link to the collection of memory extents.
<b>MemoryLevel</b>	MemoryChunks (InterleaveSets)	integer	Level of the interleave set for multi-level tiered memory.
<b>MemoryLocation</b>	Memory	object	Memory connection information to sockets and memory controllers.
<b>MemoryMedia</b>	Memory	array	Media of this memory device.
<b>MemoryMediaSources</b>	Memory (Links)	array	An array of memory chunks providing media for this memory.
<b>MemoryMirroring</b>	ComputerSystem (MemorySummary)	string (enum)	The ability and type of memory mirroring that this computer system supports.
<b>MemoryRegion</b>	Connection (MemoryRegionInfo)	object	The specified memory region.

Property Name	Defined In Schema(s)	Type	Description
<b>MemoryRegionInfo</b>	Connection	array	The set of memory regions and access capabilities specified for this connection.
<b>MemoryRegionMediaSources</b>	Memory (Links)	array	An array of memory regions providing media for this memory.
<b>MemoryRegions</b>	MemoryChunks (Links)	array	An array of links to the memory regions for which this memory chunk provides capacity.
	MemoryExtent (Links)	array	An array of links to the memory regions through which the memory extent capacity is exposed.
	CXLLogicalDevice	object	The link to the collection of memory regions associated with this CXL logical device.
<b>MemorySet</b>	MemoryDomain (InterleavableMemorySets)	array	The set of memory for a particular interleave set.
<b>MemorySizeMiB</b>	CXLLogicalDevice	integer (mebibytes)	The total memory capacity currently available in this CXL logical device.
	MemoryDomain	integer (mebibytes)	The total size of the memory domain in mebibytes (MiB).
<b>MemoryStallCount</b>	ProcessorMetrics (CoreMetrics)	number	The number of stalled cycles due to memory operations.
<b>MemoryStatistics</b>	ManagerDiagnosticData	object	The memory statistics of the manager.
<b>MemorySubsystemControllerManufacturerID</b>	Memory	string	The manufacturer ID of the memory subsystem controller of this memory device.
<b>MemorySubsystemControllerProductID</b>	Memory	string	The product ID of the memory subsystem controller of this memory device.
<b>MemorySummary</b>	ComputerSystem	object	The central memory of the system in general detail.
	Processor	object	The summary of all memory associated with this processor.
<b>MemoryType</b>	Memory	string (enum)	The type of memory device.

Property Name	Defined In Schema(s)	Type	Description
	Processor (ProcessorMemory)	string (enum)	The type of memory used by this processor.
<b>MenuName</b>	AttributeRegistry (RegistryEntries > Menus)	string	The unique name string of this menu.
<b>MenuPath</b>	AttributeRegistry (RegistryEntries > Attributes)	string	The path that describes the menu hierarchy of this attribute.
	AttributeRegistry (RegistryEntries > Menus)	string	The path to the menu names that describes this menu hierarchy relative to other menus.
<b>Menus</b>	AttributeRegistry (RegistryEntries)	array	An array for the attributes menus and their hierarchy in the attribute registry.
<b>Message</b>	Job (Messages), Task (Messages)	object	The message that the Redfish service returns.
	Event (Events)	string	The human-readable event message.
	EventService (Actions > SubmitTestEvent (Action))	string	The human-readable message for the event to add.
	LogEntry	string	The message of the log entry. This property decodes from the entry type. If the entry type is <code>Event</code> , this property contains a message. If the entry type is <code>SEL</code> , this property contains an SEL-specific message. If the entry type is <code>CXL</code> , this property contains a CXL event record. Otherwise, this property contains an OEM-specific log entry. In most cases, this property contains the actual log entry.
<b>MessageArgs</b>	EventService (Actions > SubmitTestEvent (Action))	array	An array of message arguments for the event to add.
	Event (Events), LogEntry	array	An array of message arguments that are substituted for the arguments in the message when looked up in the message registry.
<b>MessageId</b>	EventService (SSEFilterPropertiesSupported)	boolean	An indication of whether the service supports filtering by the <code>MessageIds</code> property.

Property Name	Defined In Schema(s)	Type	Description
	EventService (Actions > SubmitTestEvent (Action))	string	The <code>MessageId</code> for the event to add.
	LogEntry	string	The <code>MessageId</code> , event data, or OEM-specific information. This property decodes from the entry type. If the entry type is <code>Event</code> , this property contains a Redfish Specification-defined <code>MessageId</code> . If the entry type is <code>SEL</code> , this property contains the Event Data. Otherwise, this property contains OEM-specific information.
	Event (Events)	string	The identifier for the message.
<b>MessageIds</b>	EventDestination	array	The list of <code>MessageId</code> values that are sent to this event destination.
<b>Messages</b>	Job	array	An array of messages associated with the job.
	Task	array	An array of messages associated with the task.
	MessageRegistry	object	The message keys contained in the message registry.
<b>MessageSeverity</b>	EventService (Actions > SubmitTestEvent (Action))	string (enum)	The severity for the event to add.
	Event (Events)	string (enum)	The severity of the message in this event.
<b>MetadataTransferredAtEndOfDataLBA</b>	Volume (NVMeNamespaceProperties)	boolean	This property indicates whether or not the metadata is transferred at the end of the LBA creating an extended data LBA.
<b>MeticulousModeEnabled</b>	AddressPool (Ethernet > BFDSingleHopOnly)	boolean	Meticulous MD5 authentication of the Bidirectional Forwarding Detection (BFD) session.
<b>MetricDataType</b>	MetricDefinition	string (enum)	The data type of the metric.
<b>MetricDefinition</b>	MetricReport (MetricValues), TelemetryService (Actions > SubmitTestMetricReport (Action) > GeneratedMetricReportValues)	object	The link to the metric definition for this metric.

Property Name	Defined In Schema(s)	Type	Description
<b>MetricDefinitions</b>	TelemetryService	object	The link to the collection of metric definitions.
<b>MetricId</b>	MetricReportDefinition (Metrics)	string	The metric definition identifier that contains the metric properties to include in the metric report.
	TelemetryService (Actions > SubmitTestMetricReport (Action) > GeneratedMetricReportValues)	string	The metric definitions identifier for this metric.
	MetricReport (MetricValues)	string	The metric definitions identifier that contains additional information for the source metric.
<b>MetricIds</b>	Triggers	array	The label for the metric definitions that contain the property identifiers for this trigger. It matches the <code>Id</code> property of the corresponding metric definition.
<b>MetricProperties</b>	Triggers	array	An array of URIs with wildcards and property identifiers for this trigger. Each wildcard, a name contained by a set of curly braces, is replaced with its corresponding entry in the <code>wildcard</code> array property.
	MetricDefinition	array	The list of URIs with wildcards and property identifiers that this metric definition defines. If a URI has wildcards, the wildcards are substituted as specified in the <code>wildcards</code> property.
	MetricReportDefinition, MetricReportDefinition (Metrics)	array	The list of URIs with wildcards and property identifiers to include in the metric report. If a URI has wildcards, the wildcards are substituted as specified in the <code>wildcards</code> property.
<b>MetricProperty</b>	MetricReport (MetricValues), TelemetryService (Actions > SubmitTestMetricReport (Action) > GeneratedMetricReportValues)	string	The URI for the property from which this metric is derived.
<b>MetricReport</b>	MetricReportDefinition	object	The most recent metric report produced by this metric report definition.

Property Name	Defined In Schema(s)	Type	Description
<b>MetricReportDefinition</b>	EventService (SSEFilterPropertiesSupported)	boolean	An indication of whether the service supports filtering by the <code>MetricReportDefinitions</code> property.
	MetricReport	object	The link to the definition of this metric report.
<b>MetricReportDefinitionEnabled</b>	MetricReportDefinition	boolean	An indication of whether the generation of new metric reports is enabled.
<b>MetricReportDefinitions</b>	EventDestination	array	A list of metric report definitions for which the service only sends related metric reports. If this property is absent or the array is empty, metric reports that originate from any metric report definition are sent to the subscriber.
	Triggers (Links)	array	The metric report definitions that generate new metric reports when a trigger condition is met and when the <code>TriggerActions</code> property contains <code>RedfishMetricReport</code> .
	TelemetryService	object	The link to the collection of metric report definitions.
<b>MetricReportDefinitionType</b>	MetricReportDefinition	string (enum)	Specifies when the metric report is generated.
<b>MetricReportHeartbeatInterval</b>	MetricReportDefinition	string	The interval at which to send the complete metric report because the Redfish client wants refreshed metric data even when the data has not changed. This property value is always greater than the recurrence interval of a metric report, and it only applies when the <code>SuppressRepeatedMetricValue</code> property is <code>true</code> .
<b>MetricReportName</b>	TelemetryService (Actions > SubmitTestMetricReport (Action))	string	The name of the metric report in generated metric report.
<b>MetricReports</b>	TelemetryService	object	The link to the collection of metric reports.

Property Name	Defined In Schema(s)	Type	Description
<b>MetricReportValues</b>	TelemetryService (Actions > SubmitTestMetricReport (Action))	string	The contents of the <code>MetricReportValues</code> array in the generated metric report.
<b>Metrics</b>	MetricReportDefinition	array	The list of metrics to include in the metric report. The metrics might include calculations to apply to metric properties.
	PowerDistribution	object	A link to the summary metrics for this equipment.
	Battery	object	The link to the battery metrics resource associated with this battery.
	Heater	object	The link to the heater metrics resource associated with this heater.
	Processor (MemorySummary)	object	The link to the memory metrics associated with all memory of this processor.
	ComputerSystem (MemorySummary)	object	The link to the metrics associated with all memory in this system.
	ComputerSystem (ProcessorSummary)	object	The link to the metrics associated with all processors in this system.
	NetworkAdapter	object	The link to the metrics associated with this adapter.
	Drive	object	The link to the metrics associated with this drive.
	Memory	object	The link to the metrics associated with this memory device.
	NetworkDeviceFunction	object	The link to the metrics associated with this network function.
	Port	object	The link to the metrics associated with this port.
	Processor	object	The link to the metrics associated with this processor.
	StorageController	object	The link to the metrics associated with this storage controller.

Property Name	Defined In Schema(s)	Type	Description
	Storage	object	The link to the metrics associated with this storage subsystem.
	Switch	object	The link to the metrics associated with this switch.
	Volume	object	The link to the metrics for this volume.
	PowerSupply	object	The link to the power supply metrics resource associated with this power supply.
<b>MetricsURIs</b>	Application	array	The URIs that provide access to data or other information in this application.
<b>MetricType</b>	Triggers	string (enum)	The metric type of the trigger.
	MetricDefinition	string (enum)	The type of metric.
<b>MetricValue</b>	MetricReport (MetricValues), TelemetryService (Actions > SubmitTestMetricReport (Action) > GeneratedMetricReportValues)	string	The metric value, as a string.
<b>MetricValues</b>	MetricReport	array	An array of metric values for the metered items of this metric report.
<b>MFABypass</b>	ManagerAccount	object	The multi-factor authentication bypass settings for this account.
	AccountService (ActiveDirectory > RemoteRoleMapping), AccountService (LDAP > RemoteRoleMapping), AccountService (OAuth2 > RemoteRoleMapping), AccountService (TACACSplus > RemoteRoleMapping), ExternalAccountProvider (RemoteRoleMapping)	object	The multi-factor authentication bypass settings.
<b>Microcode</b>	SoftwareInventory (AdditionalVersions)	string	The microcode version contained in this software, such as processor microcode.

Property Name	Defined In Schema(s)	Type	Description
<b>MicrocodeInfo</b>	Processor (ProcessorId)	string	The microcode information for this processor.
<b>MicrosoftAuthenticator</b>	AccountService (MultiFactorAuth)	object	The settings related to Microsoft Authenticator multi-factor authentication. For generic Time-Based One-Time Password (TOTP) multi-factor authentication, use the <code>TimeBasedOneTimePassword</code> property.
<b>MinAllowableOperatingValue</b>	Thermal (Temperatures)	integer (Celsius)	Minimum allowable operating temperature for this equipment.
	Sensor	number	The minimum allowable operating value for this equipment.
<b>MinAssignmentGroupSize</b>	NetworkAdapter (Controllers > ControllerCapabilities > VirtualizationOffload > VirtualFunction)	integer	The minimum number of virtual functions that can be allocated or moved between physical functions for this controller.
<b>MinBWAAllocPercent</b>	NetworkPort (NetDevFuncMinBWAAlloc)	integer (%)	The minimum bandwidth allocation percentage allocated to the corresponding network device function instance.
<b>MinCID</b>	AddressPool (GenZ)	integer	The minimum value for the Component Identifier (CID).
<b>MinCollectionInterval</b>	TelemetryService	string	The minimum time interval between gathering metric data that this service allows.
<b>MinConsumedWatts</b>	Power (PowerControl > PowerMetrics)	number (watts)	The lowest power consumption level, in watt units, over the measurement window that occurred within the last <code>IntervalInMin</code> minutes.
<b>MinimumAdvertisementIntervalSeconds</b>	AddressPool (Ethernet > EBGp > BGPNeighbor), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor)	integer	Minimum Border Gateway Protocol (BGP) advertisement interval in seconds.
<b>MinimumFrequencyHz</b>	Power (PowerSupplies > InputRanges)	number (Hz)	The minimum line input frequency at which this power supply input range is effective.

Property Name	Defined In Schema(s)	Type	Description
<b>MinimumHopCount</b>	RouteEntry	integer	The minimum number of hops.
<b>MinimumRequiredResetType</b>	Drive (NVMe > ActivePersonalities), Storage (NVMeSubsystemProperties > ActivePersonalities)	string (enum)	The minimum reset type required to change the personality settings.
<b>MinimumValue</b>	ActionInfo (Parameters), JobDocument (ParameterMetadata)	number	The minimum supported value for this parameter.
<b>MinimumVoltage</b>	Power (PowerSupplies > InputRanges)	number (volts)	The minimum line input voltage at which this power supply input range is effective.
<b>MinLength</b>	AttributeRegistry (RegistryEntries > Attributes)	integer	The minimum character length of the string attribute.
<b>MinMemoryChunkSizeMiB</b>	MemoryDomain	integer (mebibytes)	The minimum size allowed for a memory chunk within this domain in mebibytes (MiB).
<b>MinPasswordLength</b>	AccountService	integer	The minimum password length for this account service.
<b>MinPowerWatts</b>	Chassis	number (watts)	The lower bound of the total power consumed by the chassis.
<b>MinReadingRange</b>	Thermal (Fans)	integer	Minimum value for this sensor.
	MetricDefinition	number	Minimum value for metric reading.
	Power (Voltages)	number (volts)	Minimum value for this sensor.
<b>MinReadingRangeTemp</b>	Thermal (Temperatures)	number (Celsius)	Minimum value for this sensor.
<b>MinSID</b>	AddressPool (GenZ)	integer	The minimum value for the Subnet Identifier (SID).
<b>MinSpeedMHz</b>	Processor	integer (MHz)	The minimum clock speed of the processor in MHz.
<b>Modbus</b>	SerialInterface	object	The Modbus settings for the serial interface.
	ManagerNetworkProtocol	object	The settings for this manager's Modbus TCP protocol support.
<b>ModbusTargetServerId</b>	AggregationSource	integer	The Modbus identifier of this aggregation source.

Property Name	Defined In Schema(s)	Type	Description
<b>Mode</b>	CoolingUnit (Actions > SetMode (Action))	string (enum)	The desired operating mode of the cooling unit.
	Pump (Actions > SetMode (Action))	string (enum)	The desired operating mode of the pump.
	AccountService (ActiveDirectory > OAuth2Service), AccountService (LDAP > OAuth2Service), AccountService (OAuth2 > OAuth2Service), AccountService (TACACSPplus > OAuth2Service), ExternalAccountProvider (OAuth2Service)	string (enum)	The mode of operation for token validation.
<b>Model</b>	Processor (FPGA)	string	The FPGA model.
	Manager	string	The model information of this manager, as defined by the manufacturer.
	Drive	string	The model number for the drive.
	PCIeDevice	string	The model number for the PCIe device.
	Storage (StorageControllers), StorageController	string	The model number for the storage controller.
	Battery	string	The model number for this battery.
	Fan, Thermal (Fans)	string	The model number for this fan.
	Filter	string	The model number for this filter.
	Heater	string	The model number for this heater.
	Power (PowerSupplies), PowerSupply	string	The model number for this power supply.
	Pump	string	The model number for this pump.
	Reservoir	string	The model number for this reservoir.
	Volume	string	The model number for this storage volume.
	Assembly (Assemblies)	string	The model number of the assembly.
Cable	string	The model number of the cable.	

Property Name	Defined In Schema(s)	Type	Description
	Chassis	string	The model number of the chassis.
	CoolantConnector	string	The model number of the component.
	LeakDetector	string	The model number of the leak detector.
	Sensor	string	The model number of the sensor.
	TrustedComponent	string	The model number of the trusted component.
	MediaController	string	The model of this media controller.
	FabricAdapter	string	The model string for this fabric adapter.
	NetworkAdapter	string	The model string for this network adapter.
	ComputerSystem (ProcessorSummary)	string	The processor model for the primary or majority of processors in this system.
	Memory, Processor, SimpleStorage (Devices)	string	The product model number of this device.
	CoolingUnit, PowerDistribution	string	The product model number of this equipment.
	GraphicsController	string	The product model number of this graphics controller.
	Switch	string	The product model number of this switch.
	USBController	string	The product model number of this USB controller.
	ComputerSystem	string	The product name for this system, without the manufacturer name.
<b>Modified</b>	LogEntry	string	The date and time when the log entry was last modified.
<b>ModifyRedundancySet (Action)</b>	Manager (Actions)	object	The <code>ModifyRedundancySet</code> operation adds members to or removes members from a redundant group of managers.

Property Name	Defined In Schema(s)	Type	Description
<b>ModuleManufacturerID</b>	Memory	string	The manufacturer ID of this memory device.
<b>ModuleProductID</b>	Memory	string	The product ID of this memory device.
<b>MotionAxis</b>	AutomationNode	string (enum)	The primary axis of motion for this motion-related node.
<b>MotionProfile</b>	AutomationNode	string (enum)	The motion profile type used for this node.
<b>MountPoints</b>	Container	array	The file system mount points configured for this container.
<b>MPF</b>	Storage	object	The multiple physical function-related properties for storage controllers in this storage subsystem.
<b>MPFProperties</b>	StorageController	object	The physical function-related properties for this storage controller within a multiple physical function storage controller.
<b>MPRT</b>	Port (GenZ)	object	The Multi-subnet Packet Relay Table for the port.
<b>MSDT</b>	FabricAdapter (GenZ)	object	The Multi Subnet Destination Table for the component.
<b>MTUSize</b>	EthernetInterface	integer	The currently configured maximum transmission unit (MTU), in bytes, on this interface.
	NetworkDeviceFunction (Ethernet)	integer	The hardware maximum transmission unit (MTU) configured for this network device function.
	NetworkDeviceFunction (InfiniBand)	integer	The maximum transmission unit (MTU) configured for this network device function.
<b>MTUSizeMaximum</b>	NetworkDeviceFunction (Ethernet)	integer	The largest maximum transmission unit (MTU) size supported for this network device function.
<b>MultiFactorAuth</b>	AccountService	object	The multi-factor authentication settings that this account service supports.

Property Name	Defined In Schema(s)	Type	Description
<b>MultihopEnabled</b>	AddressPool (Ethernet > EBGp), AddressPool (Ethernet > MultiProtocolEBGP)	boolean	External BGP (eBGP) multihop status.
<b>MultihopTTL</b>	AddressPool (Ethernet > EBGp), AddressPool (Ethernet > MultiProtocolEBGP)	integer	External BGP (eBGP) multihop Time to Live (TTL) value.
<b>MultipartHttpPushUri</b>	UpdateService	string	The URI used to perform a Redfish Specification-defined multipart HTTP or HTTPS push update to the update service.
<b>MultipartImportConfigurationPushURI</b>	ComputerSystem, CoolingUnit, PowerDistribution	string	The URI used to perform a Redfish Specification-defined multipart HTTP or HTTPS push import of a vendor-specific configuration file.
<b>Multipath</b>	Drive	boolean	An indication of whether the drive is accessible from multiple paths.
<b>MultipleHTTPRequests</b>	ServiceRoot (ProtocolFeaturesSupported)	boolean	An indication of whether the service supports multiple outstanding HTTP requests.
<b>MultiplePaths</b>	AddressPool (Ethernet > EBGp), AddressPool (Ethernet > MultiProtocolEBGP), AddressPool (Ethernet > MultiProtocolIBGP)	object	Multiple path related properties.
<b>MultiProtocolIEBGP</b>	AddressPool (Ethernet)	object	Multi Protocol eBGP (MP eBGP) related properties for this Ethernet fabric.
<b>MultiProtocolIBGP</b>	AddressPool (Ethernet)	object	Multi Protocol iBGP (MP iBGP) related properties for this Ethernet fabric.
<b>MutualCHAPSecret</b>	NetworkDeviceFunction (iSCSIBoot)	string	The CHAP secret for two-way CHAP authentication.
<b>MutualCHAPUsername</b>	NetworkDeviceFunction (iSCSIBoot)	string	The CHAP username for two-way CHAP authentication.
<b>MutuallyExclusiveEndpoints</b>	Endpoint (Links)	array	An array of links to the endpoints that cannot be used in zones if this endpoint is in a zone.
<b>NACKCount</b>	ManagerDiagnosticData (I2CBuses)	integer	The number of NACKs on this I2C bus.

Property Name	Defined In Schema(s)	Type	Description
<b>NameServers</b>	EthernetInterface	array	The DNS servers in use on this interface.
<b>NamespaceFeatures</b>	Volume (NVMeNamespaceProperties)	object	This property contains a set of Namespace Features.
<b>NamespaceId</b>	Volume (NVMeNamespaceProperties)	string	The NVMe Namespace Identifier for this namespace.
<b>Namespaces</b>	StorageController (Actions > AttachNamespaces (Action))	array	The namespaces or volumes to attach to the storage controller.
	StorageController (Actions > DetachNamespaces (Action))	array	The namespaces or volumes to detach from the storage controller.
<b>NamespacesInReadOnlyMode</b>	StorageControllerMetrics (NVMeSMART > EGCriticalWarningSummary)	boolean	An indication of whether namespaces in one or more Endurance Groups are in read-only mode not as a result of a change in the write protection state of a namespace.
<b>NamespaceType</b>	Volume (NVMeNamespaceProperties)	string (enum)	Identifies the type of namespace.
<b>NativeCommandQueueDepth</b>	DriveMetrics	integer	The current depth of the Native Command Queue.
<b>NativeVLAN</b>	AddressPool (Ethernet > IPv4)	integer	The untagged Virtual LAN (VLAN) ID value.
<b>NCSIRXBytes</b>	NetworkAdapterMetrics	integer (bytes)	The total number of NC-SI bytes received since reset.
<b>NCSIRXFrames</b>	NetworkAdapterMetrics	integer	The total number of NC-SI frames received since reset.
<b>NCSITXBytes</b>	NetworkAdapterMetrics	integer (bytes)	The total number of NC-SI bytes sent since reset.
<b>NCSITXFrames</b>	NetworkAdapterMetrics	integer	The total number of NC-SI frames sent since reset.
<b>NDPProxyEnabled</b>	AddressPool (Ethernet > BGPEvpn)	boolean	Network Discovery Protocol (NDP) proxy status.
<b>NDPSuppressionEnabled</b>	AddressPool (Ethernet > BGPEvpn)	boolean	Network Discovery Protocol (NDP) suppression status.
<b>NDPSuppressionEnabled</b>	AddressPool (Ethernet > BGPEvpn)	boolean	Network Discovery Protocol (NDP) suppression status.

Property Name	Defined In Schema(s)	Type	Description
<b>NegotiatedPowerWatts</b>	PortMetrics (PoE)	number (watts)	The negotiated maximum power for this port.
<b>NegotiatedSpeedGbs</b>	Drive	number (Gbit/s)	The speed, in gigabits per second (Gbit/s) units, at which this drive currently communicates to the storage controller.
<b>NetDevFuncCapabilities</b>	NetworkDeviceFunction	array	An array of capabilities for this network device function.
<b>NetDevFuncMaxBWAlloc</b>	NetworkPort	array	An array of maximum bandwidth allocation percentages for the network device functions associated with this port.
<b>NetDevFuncMinBWAlloc</b>	NetworkPort	array	An array of minimum bandwidth allocation percentages for the network device functions associated with this port.
<b>NetDevFuncType</b>	NetworkDeviceFunction	string (enum)	The configured capability of this network device function.
<b>NetworkAdapter</b>	NetworkInterface (Links)	object	The link to the network adapter that contains this network interface.
<b>NetworkAdapters</b>	Heater (Links)	array	An array of links to the network adapters heated by this heater.
	Chassis	object	The link to the collection of network adapters associated with this chassis.
<b>NetworkDeviceFunction</b>	Endpoint (Links)	array	When <code>NetworkDeviceFunction</code> resources are present, this array contains links to the network device functions that connect to this endpoint.
	NetworkPort (NetDevFuncMaxBWAlloc), NetworkPort (NetDevFuncMinBWAlloc), Port (FunctionMaxBandwidth), Port (FunctionMinBandwidth)	object	The link to the network device function associated with this bandwidth setting of this network port.

Property Name	Defined In Schema(s)	Type	Description
	EthernetInterface (Links)	object	The link to the parent network device function and is only used when representing one of the VLANs on that network device function, such as is done in Unix.
<b>NetworkDeviceFunctionCount</b>	NetworkAdapter (Controllers > ControllerCapabilities)	integer	The maximum number of physical functions available on this controller.
<b>NetworkDeviceFunctions</b>	NetworkAdapter (Controllers > Links)	array	An array of links to the network device functions associated with this network controller.
	Drive (Links)	array	An array of links to the network device functions that provide network connectivity for this drive.
	PCIeFunction (Links)	array	An array of links to the network device functions that the PCIe function produces.
	EthernetInterface (Links)	array	The link to the network device functions that constitute this Ethernet interface.
	StorageController (Links)	array	The network device functions that provide connectivity to this controller.
	Processor (Links)	array	The network device functions to which this processor performs offload computation, such as with a SmartNIC.
	NetworkAdapter	object	The link to the collection of network device functions associated with this network adapter.
	NetworkInterface	object	The link to the network device functions associated with this network interface. This does not include Ethernet network device functions.
<b>Networking</b>	PortMetrics	object	The port metrics for network ports, including Ethernet, Fibre Channel, and InfiniBand, that are not specific to one of these protocols.

Property Name	Defined In Schema(s)	Type	Description
<b>NetworkInterfaces</b>	ResourceBlock	array	An array of links to the Network Interfaces available in this resource block.
	ComputerSystem	object	The link to the collection of Network Interfaces associated with this system.
<b>NetworkPortCount</b>	NetworkAdapter (Controllers > ControllerCapabilities)	integer	The number of physical ports on this controller.
<b>NetworkPortMaxCount</b>	NetworkAdapter (Controllers > ControllerCapabilities > VirtualizationOffload > VirtualFunction)	integer	The maximum number of virtual functions supported per network port for this controller.
<b>NetworkPorts</b>	NetworkAdapter (Controllers > Links)	array	An array of links to the network ports associated with this network controller.
	NetworkAdapter	object	The link to the collection of network ports associated with this network adapter.
	NetworkInterface	object	The link to the network ports associated with this network interface.
<b>NetworkProtocol</b>	HostInterface	object	A link to the network services and their settings that the manager controls. In this property, clients find configuration options for the network and network services.
	Manager	object	The link to the network services and their settings that the manager controls.
<b>NetworkSuppliedServers</b>	ManagerNetworkProtocol (NTP)	array	The NTP servers supplied by other network protocols to this manager.
<b>Neutral</b>	Circuit (PolyPhaseCurrentAmps), Outlet (PolyPhaseCurrentAmps), PowerSupplyMetrics (PolyPhaseCurrentAmps)	object	Neutral line current (A).
<b>NewManager</b>	Manager (Actions > ForceFailover (Action))	object	The manager to which to fail over.

Property Name	Defined In Schema(s)	Type	Description
<b>NewPassphrase</b>	CXLLogicalDevice (Actions > SetPassphrase (Action))	string	The new passphrase to set for the CXL logical device.
<b>NewPassword</b>	ManagerAccount (Actions > ChangePassword (Action))	string	The new account password.
	Bios (Actions > ChangePassword (Action))	string	The new BIOS password.
	Storage (Actions > SetControllerPassword (Action))	string	The new password to set for the controller.
<b>NodeControl</b>	AutomationInstrumentation	object	The control for this node.
<b>NoDefaultValue</b>	ActionInfo (Parameters)	boolean	Indicates that there is no default value for this parameter.
<b>NodeGUID</b>	NetworkDeviceFunction (InfiniBand)	string	This is the currently configured node GUID of the network device function.
<b>NodeState</b>	AutomationInstrumentation, AutomationNode	string (enum)	The current state of the node.
<b>NodeType</b>	AutomationNode	string (enum)	The type of automation node.
<b>NoEventLog</b>	Memory (Actions > ScanMedia (Action))	boolean	Indicates whether events related to the media scan are not logged.
<b>NoLinks</b>	ServiceRoot (ProtocolFeaturesSupported > ExpandQuery)	boolean	An indication of whether the service supports the period ( . ) option of the <code>\$expand</code> query parameter.
<b>NominalFrequencyHz</b>	Circuit	number	The nominal frequency (Hz) for this circuit.
<b>NominalOutputVoltage</b>	Battery	number (volts)	The nominal output voltage of this battery.
<b>NominalVoltage</b>	PowerSupply (OutputRails)	number	The nominal voltage of this output power rail.
	Circuit	string (enum)	The nominal voltage for this circuit.
	Outlet	string (enum)	The nominal voltage for this outlet.
<b>NominalVoltageType</b>	PowerSupply (InputRanges)	string (enum)	The input voltage range.

Property Name	Defined In Schema(s)	Type	Description
<b>Nonce</b>	ComponentIntegrity (Actions > SPDMGetSignedMeasurements (Action))	string	A 32-byte hex-encoded string that is signed with the measurements. The value should be unique.
	ComponentIntegrity (Actions > TPMGetSignedMeasurements (Action))	string	A set of bytes as a hex-encoded string that is signed with the measurements. The value should be unique.
	Drive (Actions > UnfreezePersonality (Action)), Storage (Actions > UnfreezePersonality (Action))	string	The personality nonce provided by the <code>GetPersonalityNonce</code> action.
<b>NonceSizeBytesMaximum</b>	ComponentIntegrity (TPM)	integer	The maximum number of bytes that can be specified in the <code>Nonce</code> parameter of the <code>TPMGetSignedMeasurements</code> action.
<b>NonCRCTransientErrors</b>	PortMetrics (GenZ)	integer	The total number transient errors detected that are unrelated to CRC validation.
<b>NonStrictOrderingModeEnabled</b>	Port (UALink)	boolean	An indication of whether non-strict ordering mode is enabled.
<b>NonVolatileRegion</b>	MemoryRegion	boolean	An indication of whether this memory region represents non-volatile memory.
<b>NonVolatileSizeLimitMiB</b>	Memory	integer (mebibytes)	The total non-volatile memory capacity in mebibytes (MiB).
<b>NonVolatileSizeMiB</b>	Memory	integer (mebibytes)	Total size of the non-volatile portion memory in MiB.
<b>NotificationType</b>	Event (Events > CPER), LogEntry (CPER)	string	The CPER Notification Type for a CPER record.
<b>NotifyIPv6Scope</b>	ManagerNetworkProtocol (SSDP)	string (enum)	The IPv6 scope for multicast NOTIFY messages for SSDP.
<b>NotifyMulticastIntervalSeconds</b>	ManagerNetworkProtocol (SSDP)	integer (seconds)	The time interval, in seconds, between transmissions of the multicast NOTIFY ALIVE message from this service for SSDP.
<b>NotifyTTL</b>	ManagerNetworkProtocol (SSDP)	integer	The time-to-live hop count for SSDP multicast NOTIFY messages.

Property Name	Defined In Schema(s)	Type	Description
<b>NPAR</b>	NetworkAdapter (Controllers > ControllerCapabilities)	object	NIC Partitioning (NPAR) capabilities for this controller.
<b>NparCapable</b>	NetworkAdapter (Controllers > ControllerCapabilities > NPAR)	boolean	An indication of whether the controller supports NIC function partitioning.
<b>NparEnabled</b>	NetworkAdapter (Controllers > ControllerCapabilities > NPAR)	boolean	An indication of whether NIC function partitioning is active on this controller.
<b>NPIV</b>	NetworkAdapter (Controllers > ControllerCapabilities)	object	N_Port ID Virtualization (NPIV) capabilities for this controller.
<b>NQN</b>	Key (NVMeoF)	string	The NVMe Qualified Name (NQN) of the host or target subsystem associated with this key.
<b>NTP</b>	ManagerNetworkProtocol	object	The settings for this manager's NTP protocol support.
<b>NTPOffsetHoursMinutes</b>	AddressPool (Ethernet > IPv4)	integer	The Network Time Protocol (NTP) offset configuration.
<b>NTPServer</b>	AddressPool (Ethernet > IPv4)	array	The Network Time Protocol (NTP) servers for this Ethernet fabric.
<b>NTPServers</b>	ManagerNetworkProtocol (NTP)	array	Indicates to which user-supplied NTP servers this manager is subscribed.
<b>NTPTimezone</b>	AddressPool (Ethernet > IPv4)	string	The Network Time Protocol (NTP) time zone for this Ethernet fabric.
<b>NumberDiscoveredRemotePorts</b>	Port (FibreChannel)	integer	The number of ports not on the associated device that the associated device has discovered through this port.
	NetworkPort	integer	The number of ports not on this adapter that this port has discovered.
<b>NumberLBAFormats</b>	Volume (NVMeNamespaceProperties)	integer (bytes)	The number of LBA data size and metadata size combinations supported by this namespace. The value of this property is between 0 and 16.

Property Name	Defined In Schema(s)	Type	Description
<b>NumberOfBoundvPPBs</b>	Switch (CXL)	integer	The total number of vPPBs (Virtual PCI-to-PCI Bridges) that are currently bound on this switch.
<b>NumberOfCompositions</b>	ResourceBlock (CompositionStatus)	integer	The number of compositions in which this resource block is currently participating.
<b>NumberOfConnectedClients</b>	ManagerNetworkProtocol (Modbus)	integer	The current number of connected clients.
<b>NumberOfErrorInformationLogEntries</b>	StorageControllerMetrics (NVMeSMART)	integer	The number of error information log entries over the life of the controller.
<b>NumericThresholds</b>	Triggers	object	The thresholds for a numeric metric trigger.
<b>NumOffloadedIPv4Conns</b>	NetworkDeviceFunctionMetrics (Ethernet)	integer	The total number of offloaded TCP/IPv4 connections.
<b>NumOffloadedIPv6Conns</b>	NetworkDeviceFunctionMetrics (Ethernet)	integer	The total number of offloaded TCP/IPv6 connections.
<b>NVMe</b>	Drive	object	NVMe properties for this drive.
<b>NVMeControllerAttributes</b>	StorageController (NVMeControllerProperties)	object	The NVMe controller attributes.
<b>NVMeControllerProperties</b>	StorageController	object	The NVMe-related properties for this storage controller.
<b>NVMeDiscoveredSubsystems</b>	StorageController (Links)	array	The NVMe subsystems discovered by this discovery controller.
<b>NVMeDomains</b>	ServiceRoot	object	The link to a collection of NVMe domains.
<b>NVMeNamespaceProperties</b>	Volume	object	This property contains properties to use when Volume is used to describe an NVMe Namespace.
<b>NVMeoF</b>	Key, KeyPolicy	object	NVMe-oF specific properties.
<b>NVMeoFCipherSuiteType</b>	KeyPolicy (NVMeoF > CipherSuiteAllowList)	string (enum)	The NVMe cipher suites that a key is allowed to use.
<b>NVMeoFDHGroupType</b>	KeyPolicy (NVMeoF > DHGroupAllowList)	string (enum)	The NVMe Diffie-Hellman (DH) groups that a key is allowed to use.

Property Name	Defined In Schema(s)	Type	Description
<b>NVMeoFDiscoverySubsystems</b>	Storage (Links)	array	An array of links to the discovery subsystems that discovered this subsystem in an NVMe-oF environment.
<b>NVMeoFKeyPolicies</b>	KeyService	object	The NVMe-oF key policies maintained by this service.
<b>NVMeoFSecrets</b>	KeyService	object	The NVMe-oF keys maintained by this service.
<b>NVMeoFSecureHashType</b>	Key (NVMeoF > SecureHashAllowList), KeyPolicy (NVMeoF > SecureHashAllowList)	string (enum)	The NVMe secure hash algorithms that a key is allowed to use.
<b>NVMeoFSecurityProtocolType</b>	KeyPolicy (NVMeoF > SecurityProtocolAllowList)	string (enum)	The NVMe security protocols that a key is allowed to use.
<b>NVMeoFSecurityTransportType</b>	KeyPolicy (NVMeoF > SecurityTransportAllowList)	string (enum)	The NVMe security transports that a key is allowed to use.
<b>NVMeSMART</b>	DriveMetrics	object	The NVMe SMART metrics for the drive.
	StorageControllerMetrics	object	The NVMe SMART metrics for this storage controller.
<b>NVMeSMARTCriticalWarnings</b>	StorageController (NVMeControllerProperties)	object	The NVMe SMART Critical Warnings for this storage controller. This property contains possible triggers for the predictive drive failure warning for the corresponding drive.
<b>NVMeSubsystemProperties</b>	Storage	object	Information specific to NVMe subsystems.
<b>NVMeVersion</b>	StorageController (NVMeControllerProperties), Volume (NVMeNamespaceProperties)	string	The version of the NVMe Base Specification supported.
<b>OAuth2</b>	AccountService	object	The first OAuth 2.0 external account provider that this account service supports.

Property Name	Defined In Schema(s)	Type	Description
<b>OAuth2Service</b>	AccountService (ActiveDirectory), AccountService (LDAP), AccountService (OAuth2), AccountService (TACACSPplus), ExternalAccountProvider	object	The additional information needed to parse an OAuth 2.0 service.
<b>OAuthServiceSigningKeys</b>	AccountService (ActiveDirectory > OAuth2Service), AccountService (LDAP > OAuth2Service), AccountService (OAuth2 > OAuth2Service), AccountService (TACACSPplus > OAuth2Service), ExternalAccountProvider (OAuth2Service)	string	The Base64-encoded signing keys of the issuer of the OAuth 2.0 service. Clients should configure this property if <code>Mode</code> contains <code>Offline</code> .
<b>ObjectDataType</b>	ActionInfo (Parameters)	string	The data type of an object-based parameter.
<b>OccupancyBytes</b>	ProcessorMetrics (Cache), ProcessorMetrics (CoreMetrics > CoreCache)	integer (bytes)	The total cache level occupancy in bytes.
<b>OccupancyPercent</b>	ProcessorMetrics (Cache), ProcessorMetrics (CoreMetrics > CoreCache)	number (%)	The total cache occupancy percentage.
<b>OEMAccountTypes</b>	ManagerAccount	array	The OEM account types.
<b>OEMCalculationAlgorithm</b>	MetricDefinition	string	The OEM-defined calculation that is performed on a source metric to obtain the metric being defined.
<b>OEMComponents</b>	CoolingUnit (Actions > ExportConfiguration (Action)), PowerDistribution (Actions > ExportConfiguration (Action))	array	The OEM-specific components of the equipment for which to export configuration data.
	ComputerSystem (Actions > ExportConfiguration (Action))	array	The OEM-specific components of the system for which to export configuration data.
<b>OEMDecommissionTypes</b>	ComputerSystem (Actions > Decommission (Action))	array	The OEM-specific types of data to remove from the system.
<b>OEMDiagnosticDataType</b>	Event (Events), LogEntry	string	The OEM-defined type of data available in the <code>DiagnosticData</code> property or retrieved from the URI specified by the <code>AdditionalDataURI</code> property.

Property Name	Defined In Schema(s)	Type	Description
	LogService (DiagnosticDataDetails)	string	The OEM-defined type of diagnostic data to collect with the <code>CollectDiagnosticData</code> action.
	LogService (Actions > CollectDiagnosticData (Action))	string	The OEM-defined type of diagnostic data to collect.
<b>OemLastState</b>	ComputerSystem (BootProgress)	string	The OEM-specific last state, if the LastState type is <code>OEM</code> .
<b>OemLogEntryCode</b>	LogEntry	string	The OEM-specific entry code, if the <code>LogEntryCode</code> type is <code>OEM</code> .
<b>OEMLogPurpose</b>	LogService	string	The OEM-specified purpose of the log if <code>LogPurposes</code> contains <code>OEM</code> .
<b>OEMPrivilegeDescriptions</b>	PrivilegeRegistry	array	The descriptions of the OEM privileges used in this mapping.
<b>OemPrivileges</b>	Role	array	The OEM privileges for this role.
<b>OEMPrivilegesUsed</b>	PrivilegeRegistry	array	The set of OEM privileges used in this mapping.
<b>OEMProtocol</b>	EventDestination	string	The OEM-defined protocol type of the event connection.
<b>OemRecordFormat</b>	LogEntry	string	The OEM-specific format of the entry. If the entry type is <code>oem</code> , this property contains more information about the record format from the OEM.
<b>OEMSecurityMode</b>	Manager	string	The OEM-specific security compliance mode(s) that the manager is currently configured to enforce.
	Manager (Actions > UpdateSecurityMode (Action))	string	The OEM-specific security mode to apply to the manager.
<b>OEMSecurityProtocolAllowList</b>	KeyPolicy (NVMeoF)	array	The OEM security protocols that this key policy allows.
<b>OEMSecurityProtocolType</b>	Key (NVMeoF)	string	The OEM security protocol that this key uses.
<b>OemSensorType</b>	LogEntry	string	The OEM-specific sensor type if the sensor type is <code>OEM</code> .

Property Name	Defined In Schema(s)	Type	Description
<b>OemSessionType</b>	Session	string	The active OEM-defined session type.
<b>OEMSubscriptionType</b>	EventDestination	string	The OEM-defined subscription type for events.
<b>OEMTelemetryDataType</b>	TelemetryData	string	The OEM-defined type of telemetry data available in the <code>AdditionalData</code> property or retrieved from the URI specified by the <code>AdditionalDataURI</code> property.
	TelemetryService (Actions > CollectTelemetryData (Action))	string	The OEM-defined type of telemetry data to collect.
<b>OffloadedNetworkDeviceFunctions</b>	ComputerSystem (Links)	array	The network device functions to which this system performs offload computation, such as with a SmartNIC.
<b>OffloadProcessors</b>	NetworkDeviceFunction (Links)	array	The processors that perform offload computation for this network function, such as with a SmartNIC.
<b>OffloadSystem</b>	NetworkDeviceFunction (Links)	object	The system that performs offload computation for this network function, such as with a SmartNIC.
<b>OffsetMiB</b>	MemoryChunks (InterleaveSets)	integer (mebibytes)	Offset within the DIMM that corresponds to the start of this memory region, measured in mebibytes (MiB).
	Memory (Regions)	integer (mebibytes)	Offset within the memory that corresponds to the start of this memory region in mebibytes (MiB).
<b>OffsetMinutes</b>	Manager (DaylightSavingTime)	integer	The daylight saving time offset in minutes.
<b>OldPassword</b>	Bios (Actions > ChangePassword (Action))	string	The existing BIOS password. This parameter is not needed if the password is currently not set.
<b>OneTimePasscode</b>	AccountService (MultiFactorAuth)	object	The settings related to one-time passcode (OTP) multi-factor authentication.

Property Name	Defined In Schema(s)	Type	Description
<b>OneTimePasscodeDeliveryAddress</b>	ManagerAccount	string	The address used to receive one-time passcode messages for multi-factor authentication.
<b>OnlyMemberQuery</b>	ServiceRoot (ProtocolFeaturesSupported)	boolean	An indication of whether the service supports the <code>only</code> query parameter.
<b>OperatingConfigs</b>	Processor	object	The link to the collection of operating configurations that can be applied to this processor.
<b>OperatingMemoryModes</b>	Memory	array	Memory modes supported by the memory device.
<b>OperatingMode</b>	EthernetInterface (DHCPv6)	string (enum)	Determines the DHCPv6 operating mode for this interface.
<b>OperatingSpeedMhz</b>	Memory	integer (MHz)	Operating speed of the memory device in MHz or MT/s as appropriate.
<b>OperatingSpeedMHz</b>	MemoryMetrics	integer (MHz)	Operating speed of memory in MHz or MT/s as appropriate.
	Processor, ProcessorMetrics	integer (MHz)	Operating speed of the processor in MHz.
<b>OperatingSpeedRangeMHz</b>	Memory, Processor	object	Range of allowed operating speeds (MHz).
<b>OperatingSystem</b>	ComputerSystem	object	The link to the operating system information associated with this system.
<b>Operation</b>	Drive (Operations), Volume (Operations)	string (enum)	The type of the operation.
<b>OperationMap</b>	PrivilegeRegistry (Mappings)	object	List mapping between HTTP methods and privilege required for the resource.
	PrivilegeRegistry (Mappings > PropertyOverrides), PrivilegeRegistry (Mappings > ResourceURIOverrides), PrivilegeRegistry (Mappings > SubordinateOverrides)	object	The mapping between the HTTP operation and the privilege required to complete the operation.

Property Name	Defined In Schema(s)	Type	Description
<b>OperationName</b>	Drive (Operations), Volume (Operations)	string	The name of the operation.
<b>Operations</b>	Drive	array	The operations currently running on the drive.
	Volume	array	The operations currently running on the Volume.
<b>OptimumIOSizeBytes</b>	Volume	integer (bytes)	The size in bytes of this Volume's optimum IO size.
<b>Organization</b>	CertificateEnrollment (CSRParameters), CertificateService (Actions > GenerateCSR (Action))	string	The name of the organization making the request.
	Certificate (Issuer), Certificate (Subject)	string	The name of the organization of the entity.
<b>OrganizationalUnit</b>	CertificateEnrollment (CSRParameters), CertificateService (Actions > GenerateCSR (Action))	string	The name of the unit or division of the organization making the request.
	Certificate (Issuer), Certificate (Subject)	string	The name of the unit or division of the organization of the entity.
<b>OriginAddress</b>	Event (Events), LogEntry	string	The IP address, with scheme, of the user associated with the log entry.
<b>Originator</b>	LogEntry	string	The source of the log entry.
<b>OriginatorType</b>	LogEntry	string (enum)	The type of originator data.
<b>OriginOfCondition</b>	Event (Events)	object	A link to the resource or object that originated the condition that caused the event to be generated.
	LogEntry (Links)	object	The link to the resource that caused the log entry.
	EventService (Actions > SubmitTestEvent (Action))	string	The URL in the <code>OriginOfCondition</code> property of the event to add. It is not a reference object.
<b>OriginOfConditionUnavailable</b>	LogEntry	boolean	Indicates whether the <code>OriginOfCondition</code> link is unavailable, such as after the deletion of the resource.

Property Name	Defined In Schema(s)	Type	Description
	Event (Events)	boolean	Indicates whether the <code>OriginOfCondition</code> link is unavailable, such as due to the deletion of the resource.
<b>OriginResource</b>	EventService (SSEFilterPropertiesSupported)	boolean	An indication of whether the service supports filtering by the <code>OriginResources</code> property.
<b>OriginResources</b>	EventDestination	array	The array of resources for which the service sends only related events.
<b>OriginResourcesSupported</b>	EventService	boolean	An indication of whether the service supports filtering by the <code>OriginResources</code> property.
<b>OSDistribution</b>	SoftwareInventory (AdditionalVersions)	string	The operating system name of this software.
<b>OutboundConnection</b>	Session (Links)	object	The outbound connection associated with this session.
<b>OutboundConnections</b>	AccountService	object	The collection of outbound connection configurations.
<b>Outlet</b>	PowerSupply (Links)	object	A link to the outlet connected to this power supply.
<b>OutletCombinationTypes</b>	Outlet	array	The combination of supported receptacle types according to NEMA, IEC, or regional standards.
<b>OutletGroups</b>	OutletGroup (Links)	array	The set of outlet groups in this outlet group.
	PowerDistribution	object	A link to the outlet groups for this equipment.
<b>OutletGroupType</b>	OutletGroup	string (enum)	The type of outlet group that this resource represents.
<b>Outlets</b>	Circuit (Links)	array	An array of references to the outlets contained by this circuit.
	OutletGroup (Links)	array	The set of outlets in this outlet group.
	PowerDistribution	object	A link to the outlets for this equipment.

Property Name	Defined In Schema(s)	Type	Description
<b>OutletType</b>	Outlet	string (enum)	The type of receptacle according to NEMA, IEC, or regional standards.
<b>OutputControl</b>	AutomationNode (Links)	object	A link to the output control.
<b>OutputCurrentAmps</b>	BatteryMetrics	array	The output currents (A) for this battery.
<b>OutputNominalVoltageType</b>	PowerSupply	string (enum)	The nominal output voltage type of this power supply.
<b>OutputPowerWatts</b>	PowerSupplyMetrics	object	The total power output (W) for this power supply.
<b>OutputRails</b>	PowerSupply	array	The output power rails provided by this power supply.
<b>OutputVoltages</b>	BatteryMetrics	array	The output voltages (V) for this battery.
<b>OutputWattage</b>	Power (PowerSupplies > InputRanges)	number (watts)	The maximum capacity of this power supply when operating in this input range.
<b>OverallSubsystemDegraded</b>	StorageController (NVMeControllerProperties > NVMeSMARTCriticalWarnings)	boolean	Indicates that the NVM subsystem reliability has been compromised.
<b>Overflow</b>	LogService	boolean	Indicates whether the log service has overflowed.
<b>OverflowErrorCount</b>	LogEntry	integer	The count of overflow errors that occurred after this log entry.
<b>OverNominalFrequencyHz</b>	PowerDistribution (TransferCriteria)	number (Hz)	The frequency in hertz units over the nominal value that satisfies a criterion for transfer.
<b>OverrideParentManager</b>	SecurityPolicy	boolean	Override the security policy of the parent manager.
<b>OverVoltageRMSPercentage</b>	PowerDistribution (TransferCriteria)	number (%)	The positive percentage of voltage RMS over the nominal value that satisfies a criterion for transfer.
<b>OverwritePasses</b>	Drive (Actions > SecureErase (Action))	integer	The number of times to overwrite the drive if performing an overwrite type of sanitization.
<b>OverWritePolicy</b>	LogService	string (enum)	The overwrite policy for this service that takes place when the log is full.

Property Name	Defined In Schema(s)	Type	Description
<b>OverwriteUnit (Action)</b>	Memory (Actions)	object	This contains the action for securely erasing given regions using the NIST SP800-88 Purge: Overwrite.
<b>Owner</b>	TrustedComponent (Links)	object	A link to the resource that owns this trusted component.
<b>OwningEntity</b>	AttributeRegistry	string	The organization or company that publishes this attribute registry.
	MessageRegistry	string	The organization or company that publishes this message registry.
<b>OwningStorageResource</b>	Volume (Links)	object	A pointer to the Storage resource that owns or contains this volume.
<b>OwningStorageService</b>	Volume (Links)	object	A pointer to the StorageService that owns or contains this volume.
<b>PacketCRCErrors</b>	PortMetrics (GenZ)	integer	The total number of PCRC transient errors detected.
<b>PacketDeadlineDiscards</b>	PortMetrics (GenZ)	integer	The number of packets discarded due to the Congestion Deadline subfield reaching zero.
<b>ParameterMetadata</b>	JobDocument	array	The metadata for each of the parameters supported by this job document for the <code>SubmitJob</code> action.
<b>Parameters</b>	ActionInfo	array	The list of parameters included in the specified Redfish action.
	JobDocument (Actions > SubmitJob (Action))	object	The list of parameters for the new job that are specific to this job document.
	Job	object	The parameters specified for running this document-based job.
<b>ParentJob</b>	Job (Links)	object	The link to the job that created this job.
<b>Parity</b>	SerialInterface	string (enum)	The type of parity used by the sender and receiver to detect errors over the serial connection.
<b>PartNumber</b>	NetworkAdapter	string	Part number for this network adapter.

Property Name	Defined In Schema(s)	Type	Description
	LogEntry	string	The part number associated with the source of this log entry.
	Battery	string	The part number for this battery.
	Cable	string	The part number for this cable.
	Drive	string	The part number for this drive.
	CoolingUnit, PowerDistribution	string	The part number for this equipment.
	FabricAdapter	string	The part number for this fabric adapter.
	Fan, Thermal (Fans)	string	The part number for this fan.
	Filter	string	The part number for this filter.
	GraphicsController	string	The part number for this graphics controller.
	Heater	string	The part number for this heater.
	License	string	The part number for this license.
	PCleDevice	string	The part number for this PCIe device.
	Power (PowerSupplies), PowerSupply	string	The part number for this power supply.
	Pump	string	The part number for this pump.
	Reservoir	string	The part number for this reservoir.
	Storage (StorageControllers), StorageController	string	The part number for this storage controller.
	Switch	string	The part number for this switch.
	ComputerSystem	string	The part number for this system.
	Port (SFP)	string	The part number for this transceiver.
	USBController	string	The part number for this USB controller.
	Assembly (Assemblies)	string	The part number of the assembly.
	Chassis	string	The part number of the chassis.

Property Name	Defined In Schema(s)	Type	Description
	CoolantConnector	string	The part number of the component.
	LeakDetector	string	The part number of the leak detector.
	Manager	string	The part number of the manager.
	Processor	string	The part number of the processor.
	Sensor	string	The part number of the sensor.
	TrustedComponent	string	The part number of the trusted component.
	MediaController	string	The part number of this media controller.
	Memory	string	The product part number of this device.
<b>PartofSummaryHash</b>	ComponentIntegrity (SPDM > MeasurementSet > Measurements)	boolean	Indicates whether this measurement is part of the measurement summary.
<b>PassiveModeEnabled</b>	AddressPool (Ethernet > EBGp > BGPNeighbor), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor)	boolean	Border Gateway Protocol (BGP) passive mode status.
<b>Passphrase</b>	Memory (Actions > DisablePassphrase (Action)), Memory (Actions > OverwriteUnit (Action)), Memory (Actions > SecureEraseUnit (Action)), Memory (Actions > SetPassphrase (Action))	string	Passphrase for doing the operation.
	Memory (Actions > DisableMasterPassphrase (Action))	string	The master passphrase for the specified region.
	Memory (Actions > SetMasterPassphrase (Action))	string	The master passphrase to set for the specified region.

Property Name	Defined In Schema(s)	Type	Description
	CXLLogicalDevice (Actions > DisablePassphrase (Action)), CXLLogicalDevice (Actions > PassphraseSecureErase (Action)), CXLLogicalDevice (Actions > SetPassphrase (Action)), CXLLogicalDevice (Actions > Unlock (Action)), Memory (Actions > UnlockUnit (Action))	string	The passphrase required to complete the operation.
<b>PassphraseCapable</b>	Memory (SecurityCapabilities)	boolean	An indication of whether the memory device is passphrase capable.
<b>PassphraseEnabled</b>	Memory (Regions)	boolean	An indication of whether the passphrase is enabled for this region.
<b>PassphraseLockLimit</b>	Memory (SecurityCapabilities)	integer	The maximum number of incorrect passphrase attempts allowed before memory device is locked.
<b>PassphraseSecureErase (Action)</b>	CXLLogicalDevice (Actions)	object	This action securely erases the CXL logical device.
<b>PassphraseState</b>	Memory (Regions)	boolean	An indication of whether the state of the passphrase for this region is enabled.
<b>PassphraseType</b>	CXLLogicalDevice (Actions > DisablePassphrase (Action)), CXLLogicalDevice (Actions > PassphraseSecureErase (Action)), CXLLogicalDevice (Actions > SetPassphrase (Action)), CXLLogicalDevice (Actions > Unlock (Action))	string (enum)	The type of passphrase supplied for the operation.
<b>Password</b>	AggregationSource	string	The password for accessing the aggregation source. The value is <code>null</code> in responses.
	EventService (SMTP)	string	The password for authentication with the SMTP server. The value is <code>null</code> in responses.
	Certificate, CertificateService (Actions > ReplaceCertificate (Action))	string	The password for the certificate.

Property Name	Defined In Schema(s)	Type	Description
	ManagerNetworkProtocol (Proxy)	string	The password for the proxy. The value is <code>null</code> in responses.
	AccountService (ActiveDirectory > Authentication), AccountService (LDAP > Authentication), AccountService (OAuth2 > Authentication), AccountService (TACACSPplus > Authentication), ExternalAccountProvider (Authentication)	string	The password for this service. A <code>PATCH</code> or <code>PUT</code> request writes the password. This property is <code>null</code> in responses.
	Session	string	The password for this session. The value is <code>null</code> in responses.
	ComputerSystem (KeyManagement > KMIPServers)	string	The password to access the KMIP server. The value is <code>null</code> in responses.
	VirtualMedia (Actions > InsertMedia (Action))	string	The password to access the URI specified by the <code>Image</code> parameter.
	VirtualMedia	string	The password to access the URI specified by the <code>Image</code> property. The value is <code>null</code> in responses.
	UpdateService (Actions > SimpleUpdate (Action))	string	The password to access the URI specified by the <code>ImageURI</code> parameter.
	LicenseService (Actions > Install (Action))	string	The password to access the URI specified by the <code>LicenseFileURI</code> parameter.
	LogService (Actions > CollectDiagnosticData (Action)), LogService (Actions > PushDiagnosticData (Action))	string	The password to access the URI specified by the <code>TargetURI</code> parameter.
	ManagerAccount	string	The password. Use this property with a <code>PATCH</code> or <code>PUT</code> to write the password for the account. This property is <code>null</code> in responses.
<b>PasswordChangeRequired</b>	ManagerAccount	boolean	An indication of whether the service requires that the password for this account be changed before further access to the account is allowed.

Property Name	Defined In Schema(s)	Type	Description
<b>PasswordExchangeProtocols</b>	AccountService (ActiveDirectory > TACACSPplusService), AccountService (LDAP > TACACSPplusService), AccountService (OAuth2 > TACACSPplusService), AccountService (TACACSPplus > TACACSPplusService), ExternalAccountProvider (TACACSPplusService)	array	Indicates the allowed TACACS+ password exchange protocols.
<b>PasswordExpiration</b>	ManagerAccount	string	Indicates the date and time when this account password expires. If <code>null</code> , the account password never expires.
<b>PasswordExpirationDays</b>	AccountService	integer	The number of days before account passwords in this account service will expire.
<b>PasswordGuidanceMessage</b>	AccountService	string	Password creation guidance for manager accounts.
<b>PasswordGuidanceMessageId</b>	AccountService	string	A <code>MessageId</code> that contains password creation guidance for manager accounts.
<b>PasswordName</b>	Bios (Actions > ChangePassword (Action))	string	The name of the BIOS password to change.
<b>Passwords</b>	Bios	object	The list of BIOS passwords specific to the manufacturer or provider.
<b>PasswordSet</b>	AccountService (ActiveDirectory), AccountService (LDAP), AccountService (OAuth2), AccountService (TACACSPplus), EventService (SMTP), ManagerNetworkProtocol (Proxy)	boolean	Indicates if the <code>Password</code> property is set.
<b>PATCH</b>	PrivilegeRegistry (Mappings > OperationMap), PrivilegeRegistry (Mappings > PropertyOverrides > OperationMap), PrivilegeRegistry (Mappings > ResourceURIOverrides > OperationMap), PrivilegeRegistry (Mappings > SubordinateOverrides > OperationMap)	array	The privilege required to complete an HTTP <code>PATCH</code> operation.

Property Name	Defined In Schema(s)	Type	Description
<b>PathMTUDiscoveryEnabled</b>	AddressPool (Ethernet > EBGp > BGPNeighbor), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor)	boolean	Path MTU discovery status.
<b>Payload</b>	Task	object	The HTTP and JSON request payload details for this task, unless they are hidden from view by the service.
	Job	object	The HTTP and JSON request payload details for this user-specified job.
<b>PBRCapable</b>	Switch (CXL)	boolean	An indication of whether the switch is capable of performing port-based routing.
<b>PciClassCode</b>	Endpoint (ConnectedEntities)	string	The Class Code, Subclass, and Programming Interface code of this PCIe function.
<b>PCle</b>	Port	object	PCle properties for this port.
	Processor (FPGA > ExternalInterfaces), Processor (FPGA > HostInterface), Processor (SystemInterface)	object	The PCIe-related information for this interface.
<b>PCleDevice</b>	PCleSlots (Slots > Links)	array	An array of links to the PCIe devices contained in this slot.
	GraphicsController (Links)	object	A link to the PCIe device that represents this graphics controller.
	USBController (Links)	object	A link to the PCIe device that represents this USB controller.
	Processor (Links)	object	The link to the PCIe device associated with this processor.
	PCleFunction (Links)	object	The link to the PCIe device on which this function resides.
	Switch (Links)	object	The link to the PCIe device providing this switch.

Property Name	Defined In Schema(s)	Type	Description
<b>PCleDevices</b>	FabricAdapter (Links)	array	An array of links to the PCIe devices associated with this fabric adapter.
	NetworkAdapter (Controllers > Links)	array	An array of links to the PCIe devices associated with this network controller.
	Chassis (Links)	array	An array of links to the PCIe devices located in this chassis.
	ComputerSystem	array	The link to a collection of PCIe devices that this computer system uses.
<b>PCleErrors</b>	Chassis	object	The link to the collection of PCIe devices located in this chassis.
	PortMetrics	object	The PCIe errors associated with this port.
	ProcessorMetrics	object	The PCIe errors associated with this processor.
<b>PCleFunctions</b>	SwitchMetrics	object	The PCIe errors associated with this switch.
	NetworkDeviceFunction (Links)	object	The link to the PCIe function associated with this network device function.
<b>PCleFunctions</b>	PCleDevice (Links)	array	An array of links to PCIe functions exposed by this device.
	CXLLogicalDevice (Links)	array	An array of links to the PCIe functions assigned to this CXL logical device.
	AccelerationFunction (Links)	array	An array of links to the PCIe functions associated with this acceleration function.
	MemoryDomain (Links)	array	An array of links to the PCIe functions representing this memory domain.
	Drive (Links)	array	An array of links to the PCIe functions that the drive produces.

Property Name	Defined In Schema(s)	Type	Description
	Storage (StorageControllers > Links), StorageController (Links)	array	An array of links to the PCIe functions that the storage controller produces.
	Processor (Links)	array	An array of links to the PCIeFunctions associated with this processor.
	ComputerSystem	array	The link to a collection of PCIe functions that this computer system uses.
	PCleDevice	object	The link to the collection of PCIe functions associated with this PCIe device.
<b>PCleInterface</b>	NetworkAdapter (Controllers), Storage (StorageControllers), StorageController	object	The PCIe interface details for this controller.
	FabricAdapter	object	The PCIe interface details for this fabric adapter.
	PCleDevice	object	The PCIe interface details for this PCIe device.
<b>PCleMetrics</b>	PortMetrics	object	The PCIe metrics associated with this port.
<b>PCleSlots</b>	Chassis	object	The link to the PCIe slot properties for this chassis.
<b>PCleType</b>	PCleSlots (Slots)	string (enum)	The PCIe specification supported by this slot.
	PCleDevice (Slot)	string (enum)	The PCIe specification this slot supports.
	PCleDevice (PCleInterface)	string (enum)	The version of the PCIe specification in use by this device.
<b>PCleVirtualFunctions</b>	Processor (FPGA)	integer	The number of PCIe Virtual Functions.
<b>PciFunctionNumber</b>	Endpoint (ConnectedEntities)	integer	The PCI ID of the connected entity.
<b>Pcild</b>	Endpoint	object	The PCI ID of the endpoint.
<b>PCR</b>	ComponentIntegrity (TPM > MeasurementSet > Measurements)	integer	The Platform Configuration Register (PCR) bank of the measurement.

Property Name	Defined In Schema(s)	Type	Description
<b>PCRSelection</b>	ComponentIntegrity (Actions > TPMGetSignedMeasurements (Action))	string	An object that identifies the PCRs to sign.
<b>PeakIntervalReading</b>	Sensor	number	The peak sensor value over a time interval.
<b>PeakPowerBudgetMilliWatts</b>	Memory (PowerManagementPolicy)	integer (milliwatts)	Peak power budget, in milliwatt units.
<b>PeakReading</b>	Sensor	number	The peak sensor value.
<b>PeakReadingTime</b>	Sensor	string	The time when the peak sensor value occurred.
<b>PeerAS</b>	AddressPool (Ethernet > EBGp > BGPNeighbor), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor)	integer	Peer Autonomous System (AS) number.
<b>PeerDHCHAPAuthSecret</b>	Connection (ConnectionKeys > DHCHAP)	string	The peer DHCHAP authentication secret. The value is <code>null</code> in responses.
<b>Pending</b>	MemoryRegion (MemoryExtents)	boolean	An indication of whether the device received a memory extent acceptance from the host that owns the memory region.
	Drive (NVMe > ActivePersonalities), Storage (NVMeSubsystemProperties > ActivePersonalities)	boolean	An indication of whether this personality contains pending changes.
<b>PercentageComplete</b>	Volume (Operations)	integer	The percentage of the operation that has been completed.
	Drive (Operations)	integer (%)	The percentage of the operation that has been completed.
<b>PercentageUsed</b>	StorageControllerMetrics (NVMeSMART)	number (%)	The percentage of the NVM subsystem life used.
<b>PercentComplete</b>	Job	integer (%)	The completion percentage of this job.
	Task	integer (%)	The completion percentage of this task.

Property Name	Defined In Schema(s)	Type	Description
<b>PerformanceDegraded</b>	MemoryMetrics (HealthData)	boolean	An indication of whether performance has degraded.
<b>PermanentMACAddress</b>	NetworkDeviceFunction (Ethernet)	string	The permanent MAC address assigned to this function.
	EthernetInterface	string	The permanent MAC address assigned to this interface, or port.
<b>PermanentNodeGUID</b>	NetworkDeviceFunction (InfiniBand)	string	The permanent node GUID assigned to this network device function.
<b>PermanentPortGUID</b>	NetworkDeviceFunction (InfiniBand)	string	The permanent port GUID assigned to this network device function.
<b>PermanentSystemGUID</b>	NetworkDeviceFunction (InfiniBand)	string	The permanent system GUID assigned to this network device function.
<b>PermanentWWNN</b>	NetworkDeviceFunction (FibreChannel)	string	The permanent World Wide Node Name (WWNN) address assigned to this function.
<b>PermanentWWPN</b>	NetworkDeviceFunction (FibreChannel)	string	The permanent World Wide Port Name (WWPN) address assigned to this function.
<b>Persistency</b>	LogEntry	boolean	Indicates whether the log entry is persistent across a cold reset of the device.
	LogService	boolean	Indicates whether the log service is persistent across a cold reset.
<b>PersistentCacheSizeMiB</b>	Storage (StorageControllers > CacheSummary), StorageController (CacheSummary)	integer (mebibytes)	The portion of the cache memory that is persistent, measured in MiB.
<b>PersistentRegionNumberLimit</b>	Memory	integer	Total number of persistent regions this memory device can support.
<b>PersistentRegionSizeLimitMiB</b>	Memory	integer (mebibytes)	Total size of persistent regions in mebibytes (MiB).
<b>PersistentRegionSizeMaxMiB</b>	Memory	integer (mebibytes)	Maximum size of a single persistent region in mebibytes (MiB).

Property Name	Defined In Schema(s)	Type	Description
<b>Personality</b>	Drive (Actions > FreezePersonality (Action)), Drive (Actions > UnfreezePersonality (Action)), Storage (Actions > FreezePersonality (Action)), Storage (Actions > UnfreezePersonality (Action))	integer	The personality to freeze. 255 indicates all personalities.
<b>PhaseAngleDegrees</b>	<i>various</i> (Circuit (PolyPhasePowerWatts > Line1ToLine2), Circuit (PolyPhasePowerWatts > Line1ToNeutral) ... )	number	The phase angle (degrees) between the current and voltage waveforms.
<b>PhaseWiringType</b>	PowerSupply	string (enum)	The number of ungrounded current-carrying conductors (phases) and the total number of conductors (wires) provided for the power supply input connector.
	Circuit, Outlet	string (enum)	The number of ungrounded current-carrying conductors (phases) and the total number of conductors (wires).
<b>PhoneNumber</b>	License (Contact)	string	Phone number for this contact.
	ManagerAccount	string	The contact phone number associated with this account.
<b>PhyResetProblemCount</b>	PortMetrics (SAS)	integer	The number of times a phy reset problem has occurred.
<b>PhysicalAddress</b>	Memory (Actions > InjectPersistentPoison (Action))	string	The device persistent physical address in which to perform a poison injection as a hex-encoded string.
	Memory (Actions > ScanMedia (Action))	string	The starting device physical address to scan as a hex-encoded string.
<b>PhysicalContext</b>	Fan, Thermal (Fans)	string (enum)	The area or device associated with this fan.
	Filter	string (enum)	The area or device associated with this filter.
	Heater	string (enum)	The area or device associated with this heater.

Property Name	Defined In Schema(s)	Type	Description
	Pump	string (enum)	The area or device associated with this pump.
	Reservoir	string (enum)	The area or device associated with this reservoir.
	Assembly (Assemblies)	string (enum)	The area or device to which the assembly data applies.
	Control	string (enum)	The area or device to which this control applies.
	LeakDetection (LeakDetectorGroups > Detectors), LeakDetector	string (enum)	The area or device to which this leak detector applies.
	PowerSupply (OutputRails)	string (enum)	The area or device to which this power rail applies.
	EnvironmentMetrics (FanSpeedsPercent), HeaterMetrics (TemperatureReadingsCelsius), PowerSupplyMetrics (FanSpeedsPercent), Sensor, ThermalMetrics (TemperatureReadingsCelsius)	string (enum)	The area or device to which this sensor measurement applies.
	Thermal (Temperatures)	string (enum)	The area or device to which this temperature measurement applies.
	Power (Voltages)	string (enum)	The area or device to which this voltage measurement applies.
	Power (PowerControl)	string (enum)	The area, device, or set of devices to which this power control applies.
	MetricDefinition	string (enum)	The physical context of the metric.
<b>PhysicalLocation</b>	Drive	object	The location of the drive. This property is equivalent to the <code>Location</code> property common to other standard Redfish resources.
<b>PhysicalNetworkPortAssignment</b>	NetworkDeviceFunction (Links), NetworkDeviceFunction	object	The physical port or logical aggregated port to which this network device function is currently assigned.

Property Name	Defined In Schema(s)	Type	Description
<b>PhysicalPortAssignment</b>	NetworkDeviceFunction (Links), NetworkDeviceFunction	object	The physical port to which this network device function is currently assigned.
<b>PhysicalPortNumber</b>	NetworkPort	string	The physical port number label for this port.
<b>PhysicalSecureID</b>	Drive (Actions > RevertToOriginalFactoryState (Action))	string	The physical secure ID (PSID). The PSID is generally printed on the drive label and used to revert an encrypted SED.
<b>PhysicalSecurity</b>	Chassis	object	The physical security state of the chassis.
<b>PhysicalSubContext</b>	Control	string (enum)	The usage or location within a device to which this control applies.
	LeakDetection (LeakDetectorGroups > Detectors), LeakDetector	string (enum)	The usage or location within a device to which this leak detector applies.
	EnvironmentMetrics (FanSpeedsPercent), HeaterMetrics (TemperatureReadingsCelsius), PowerSupplyMetrics (FanSpeedsPercent), Sensor, ThermalMetrics (TemperatureReadingsCelsius)	string (enum)	The usage or location within a device to which this sensor measurement applies.
<b>PID</b>	Switch (CXL > PIDTargetList)	integer	The PID assigned to this port.
	AutomationInstrumentation	object	A PID control loop.
<b>PidFeedbackSensor</b>	AutomationNode (Links)	object	A link to the PID feedback sensor.
<b>PIDT</b>	FabricAdapter (GenZ)	array	An array of table entry values for the Packet Injection Delay Table.
<b>PIDTargetList</b>	Switch (CXL)	array	The target list of port-based routing (PBR) identifiers (PIDs).
<b>PinOut</b>	SerialInterface	string (enum)	The physical pinout configuration for a serial connector.
<b>PlugType</b>	Circuit, PowerSupply	string (enum)	The type of plug according to NEMA, IEC, or regional standards.
<b>PMRUnreliable</b>	StorageController (NVMeControllerProperties > NVMeSMARTCriticalWarnings)	boolean	The Persistent Memory Region has become read-only or unreliable.

Property Name	Defined In Schema(s)	Type	Description
<b>PoE</b>	Port (Ethernet)	object	The Power over Ethernet (PoE) input and output power configuration on this port.
	PortMetrics	object	The Power over Ethernet (PoE) metrics for this port.
<b>PoisonListMaxMediaErrorRecords</b>	Memory	integer	The maximum number of media error records this device can track in its poison list.
<b>Policy</b>	CXLLogicalDevice (Actions > DynamicCapacityAdd (Action)), CXLLogicalDevice (Actions > DynamicCapacityRelease (Action))	string (enum)	The policy to apply to this operation.
<b>PolicyEnabled</b>	Memory (PowerManagementPolicy)	boolean	An indication of whether the power management policy is enabled.
<b>PolyPhaseCurrentAmps</b>	Circuit	object	The current readings for this circuit.
	Outlet	object	The current readings for this outlet.
	PowerSupplyMetrics	object	The input polyphase current readings for this power supply.
<b>PolyPhaseEnergykWh</b>	Circuit	object	The energy readings for this circuit.
	PowerSupplyMetrics	object	The input polyphase energy consumption readings for this power supply.
<b>PolyPhasePowerWatts</b>	PowerSupplyMetrics	object	The input polyphase power readings for this power supply.
	Circuit	object	The power readings for this circuit.
	PowerSupplyMetrics	object	The input polyphase voltage readings for this power supply.
<b>PolyPhaseVoltage</b>	Circuit	object	The voltage readings for this circuit.
	Outlet	object	The voltage readings for this outlet.
	PowerSupplyMetrics	object	The input polyphase voltage readings for this power supply.
<b>Pool</b>	ResourceBlock	string (enum)	The pool to which this resource block belongs.
<b>Port</b>	EventService (SMTP)	integer	The destination SMTP port.
	ComputerSystem (KeyManagement > KMIPServers)	integer	The KMIP server port.

Property Name	Defined In Schema(s)	Type	Description
	AggregationSource	integer	The network port.
	<i>various</i> (ComputerSystem (GraphicalConsole), ComputerSystem (SerialConsole > IPMI) ... )	integer	The protocol port.
	Endpoint (IPTransportDetails)	integer	The UDP or TCP port number used by the endpoint.
	VirtualCXLSwitch (Links)	object	The link to the local upstream port of the switch that is physically connected to a host or another switch for this Virtual CXL Switch.
	VirtualPCI2PCIBridge (Links)	object	The link to the port associated with this vPPB.
<b>PortAggregation</b>	NetworkAdapter	object	The port aggregation capabilities for this controller.
<b>PortConnectionType</b>	Port (FibreChannel)	string (enum)	The connection type of this port.
<b>PortGUID</b>	NetworkDeviceFunction (InfiniBand)	string	The currently configured port GUID of the network device function.
<b>PortId</b>	Port (Ethernet > LLDPTransmit)	string	A colon-delimited string of hexadecimal octets identifying a port to be transmitted from this endpoint.
	Port (Ethernet > LLDPReceive)	string	A colon-delimited string of hexadecimal octets identifying a port.
	Port	string	The hardware-defined identifier of this port.
<b>PortID</b>	Switch (CXL > PIDTargetList)	integer	The physical port identifier of the target port.
<b>PortIdSubtype</b>	Port (Ethernet > LLDPReceive)	string (enum)	The port ID subtype received from the remote partner across this link.
	Port (Ethernet > LLDPTransmit)	string (enum)	The port ID subtype to be transmitted from this endpoint.
<b>PortLoginAccepts</b>	NetworkDeviceFunctionMetrics (FibreChannel)	integer	The total number of port login (PLOGI) accept (ACC) responses.

Property Name	Defined In Schema(s)	Type	Description
<b>PortLoginRejects</b>	NetworkDeviceFunctionMetrics (FibreChannel)	integer	The total number of port login (PLOGI) reject (RJT) responses.
<b>PortLoginRequests</b>	NetworkDeviceFunctionMetrics (FibreChannel)	integer	The total number of port login (PLOGI) requests transmitted.
<b>PortMaximumMTU</b>	NetworkPort	integer	The largest maximum transmission unit (MTU) that can be configured for this network port.
<b>PortMedium</b>	Port	string (enum)	The physical connection medium for this port.
<b>PortProtocol</b>	Port	string (enum)	The protocol being sent over this port.
<b>Ports</b>	Endpoint (Links)	array	An array of links to the physical ports associated with this endpoint.
	NetworkAdapter (Controllers > Links)	array	An array of links to the ports associated with this network controller.
	EthernetInterface (Links)	array	The links to the ports providing this Ethernet interface.
	MediaController	object	The link to the collection of ports associated with this media controller.
	NetworkAdapter	object	The link to the collection of ports associated with this network adapter.
	Processor	object	The link to the collection of ports for this processor.
	FabricAdapter	object	The link to the collection of ports that exist on the fabric adapter.
	Storage (StorageControllers), StorageController	object	The link to the collection of ports that exist on the storage controller.
	Switch	object	The link to the collection ports for this switch.
	NetworkInterface	object	The link to the ports associated with this network interface.
	GraphicsController	object	The ports of the graphics controller.

Property Name	Defined In Schema(s)	Type	Description
	USBController	object	The ports of the USB controller.
<b>PortSplitting</b>	NetworkAdapter	object	The port splitting capabilities for this controller.
<b>PortType</b>	Port	string (enum)	The type of this port.
<b>PositionSensor</b>	AutomationNode (Links)	object	A link to the position sensor.
<b>POST</b>	PrivilegeRegistry (Mappings > OperationMap), PrivilegeRegistry (Mappings > PropertyOverrides > OperationMap), PrivilegeRegistry (Mappings > ResourceURIOverrides > OperationMap), PrivilegeRegistry (Mappings > SubordinateOverrides > OperationMap)	array	The privilege required to complete an HTTP <code>POST</code> operation.
<b>Power</b>	Chassis	object	The link to the power properties, or power supplies, power policies, and sensors, for this chassis.
<b>PowerAllocatedWatts</b>	Power (PowerControl)	number (watts)	The total amount of power that has been allocated or budgeted to chassis.
<b>PowerAvailableWatts</b>	Power (PowerControl)	number (watts)	The amount of reserve power capacity, in watt units, that remains. This value is the <code>PowerCapacityWatts</code> value minus the <code>PowerAllocatedWatts</code> value.
<b>PowerBackupFailed</b>	StorageController (NVMeControllerProperties > NVMeSMARTCriticalWarnings)	boolean	Indicates that the volatile memory backup device has failed.
<b>PowerCapacityVA</b>	PowerDistribution	integer (V.A)	The maximum power capacity, rated as apparent power, of this equipment, in volt-ampere units.
<b>PowerCapacityWatts</b>	Power (PowerSupplies), PowerSupply	number (watts)	The maximum capacity of this power supply.
	Power (PowerControl)	number (watts)	The total amount of power that can be allocated to the chassis. This value can be either the power supply capacity or the power budget that an upstream chassis assigns to this chassis.

Property Name	Defined In Schema(s)	Type	Description
<b>PowerClass</b>	Port (Ethernet > PoE)	integer	The power class negotiated by this port.
<b>PowerConsumedWatts</b>	Power (PowerControl)	number (watts)	The actual power that the chassis consumes, in watt units.
<b>PowerControl</b>	Power	array	The set of power control functions, including power reading and limiting.
<b>PowerControl (Action)</b>	Circuit (Actions)	object	This action turns the circuit on or off.
	OutletGroup (Actions)	object	This action turns the outlet group on or off.
	Outlet (Actions)	object	This action turns the outlet on or off.
<b>PowerControlLocked</b>	Circuit, Outlet, OutletGroup	boolean	Indicates whether power control requests are locked.
<b>PowerCycleDelaySeconds</b>	Circuit, Outlet, OutletGroup	number	The number of seconds to delay power on after a <code>PowerControl</code> action to cycle power. Zero seconds indicates no delay.
	ComputerSystem	number	The number of seconds to delay power on after a <code>Reset</code> action requesting <code>PowerCycle</code> or <code>FullPowerCycle</code> . Zero seconds indicates no delay.
<b>PowerCycles</b>	StorageControllerMetrics (NVMeSMART)	integer	The number of power cycles.
<b>PowerCyclesLifetime</b>	DriveMetrics	integer	The number of times the drive has been power cycled over its lifetime.
<b>PowerDistribution</b>	Chassis (Links)	object	A link to power distribution functionality contained in this chassis.
<b>PowerDistributionRedundancy</b>	PowerDistribution	array	The redundancy information for the groups of power distribution units.
<b>PowerDomains</b>	Facility	object	Link to the power domains in this facility.

Property Name	Defined In Schema(s)	Type	Description
<b>PoweredBy</b>	Chassis (Links)	array	An array of links to resources or objects that power this chassis. Normally, the link is for either a chassis or a specific set of power supplies.
	ComputerSystem (Links)	array	An array of links to resources or objects that power this computer system. Normally, the link is for either a chassis or a specific set of power supplies.
<b>PoweredByParent</b>	Chassis	boolean	Indicates that the chassis receives power from the containing chassis.
<b>PowerEnabled</b>	Circuit	boolean	Indicates if the circuit can be powered.
	Outlet	boolean	Indicates if the outlet can be powered.
	OutletGroup	boolean	Indicates if the outlet group can be powered.
<b>PowerEquipment</b>	ServiceRoot	object	The link to a set of power equipment.
<b>PowerFactor</b>	<i>various</i> (Circuit (PolyPhasePowerWatts > Line1ToLine2), Circuit (PolyPhasePowerWatts > Line1ToNeutral) ... )	number	The power factor for this sensor.
<b>PoweringChassis</b>	PowerSupply (Links)	array	An array of links to the chassis that are directly powered by this power supply.
<b>PowerInputWatts</b>	Power (PowerSupplies)	number (watts)	The measured input power of this power supply.
<b>PowerLimit</b>	Power (PowerControl)	object	The power limit status and configuration information for this chassis.
<b>PowerLimitThrottleDuration</b>	ProcessorMetrics	string	The total duration of throttling caused by a power limit of the processor since reset.
<b>PowerLimitWatts</b>	EnvironmentMetrics	object	Power limit (W).

Property Name	Defined In Schema(s)	Type	Description
<b>PowerLoadPercent</b>	Circuit	object	The power load (percent) for this circuit.
	EnvironmentMetrics	object	The power load (percent) for this device.
	PowerDistributionMetrics	object	The power load (percent) for this equipment.
	Outlet	object	The power load (percent) for this outlet.
<b>PowerManagementICManufacturerID</b>	Memory	string	The manufacturer ID of the Power Management Integrated Controller on this memory device.
<b>PowerManagementICRevisionID</b>	Memory	string	The revision ID of the Power Management Integrated Controller on this memory device.
<b>PowerManagementPolicy</b>	Memory	object	Power management policy information.
<b>PowerMetrics</b>	Power (PowerControl)	object	The power readings for this chassis.
<b>PowerMode</b>	Port (Ethernet > PoE)	string (enum)	The current power mode of this port.
	ComputerSystem	string (enum)	The power mode setting of the computer system.
<b>PowerOffDelaySeconds</b>	Circuit, Outlet, OutletGroup	number	The number of seconds to delay power off after a <code>PowerControl</code> action. Zero seconds indicates no delay to power off.
	ComputerSystem	number	The number of seconds to delay power off during a reset. Zero seconds indicates no delay to power off.
<b>PowerOnDelaySeconds</b>	ComputerSystem	number	The number of seconds to delay power on after an externally performed power cycle or during a reset. Zero seconds indicates no delay to power up.

Property Name	Defined In Schema(s)	Type	Description
	Circuit, Outlet, OutletGroup	number	The number of seconds to delay power up after a power cycle or a <code>PowerControl</code> action. Zero seconds indicates no delay to power up.
<b>PowerOnHours</b>	DriveMetrics	number	The number of power-on hours for the lifetime of the drive.
	StorageControllerMetrics (NVMeSMART)	number	The number of power-on hours.
<b>PowerOutlet</b>	Circuit (Links)	object	A link to the power outlet that provides power to this circuit.
<b>PowerOutlets</b>	Chassis (Links)	array	An array of links to the outlets that provide power to this chassis.
	PowerSupply (Links)	array	An array of links to the outlets that provide power to this power supply.
<b>PowerOutputWatts</b>	Power (PowerSupplies)	number (watts)	The measured output power of this power supply.
<b>PowerRequestedWatts</b>	Power (PowerControl)	number (watts)	The potential power, in watt units, that the chassis requests, which might be higher than the current level being consumed because the requested power includes a budget that the chassis wants for future use.
<b>PowerRestoreDelaySeconds</b>	Circuit, Outlet, OutletGroup	number	The number of seconds to delay power on after power has been restored. Zero seconds indicates no delay.
<b>PowerRestorePolicy</b>	Circuit	string (enum)	The desired power state of the circuit when power is restored after a power loss.
	OutletGroup	string (enum)	The desired power state of the outlet group when power is restored after a power loss.
	Outlet	string (enum)	The desired power state of the outlet when power is restored after a power loss.

Property Name	Defined In Schema(s)	Type	Description
	ComputerSystem	string (enum)	The desired power state of the system when power is restored after a power loss.
<b>PowerShelves</b>	Facility (Links)	array	An array of links to the power shelves in this facility.
	PowerDomain (Links)	array	An array of links to the power shelves in this power domain.
	PowerEquipment	object	A link to a collection of power shelves.
<b>PowerState</b>	Chassis	string (enum)	The current power state of the chassis.
	Manager	string (enum)	The current power state of the manager.
	Processor	string (enum)	The current power state of the processor.
	Switch	string (enum)	The current power state of the switch.
	ComputerSystem	string (enum)	The current power state of the system.
	Circuit (Actions > BreakerControl (Action))	string (enum)	The desired power state of the circuit if the breaker is reset successfully.
	Circuit (Actions > PowerControl (Action))	string (enum)	The desired power state of the circuit.
	OutletGroup (Actions > PowerControl (Action))	string (enum)	The desired power state of the outlet group.
	Outlet (Actions > PowerControl (Action))	string (enum)	The desired power state of the outlet.
	Circuit	string (enum)	The power state of the circuit.
	OutletGroup	string (enum)	The power state of the outlet group.
	Outlet	string (enum)	The power state of the outlet.

Property Name	Defined In Schema(s)	Type	Description
<b>PowerStateInTransition</b>	Circuit, Outlet, OutletGroup	boolean	Indicates whether the power state is undergoing a delayed transition.
<b>PowerSubsystem</b>	Chassis	object	The link to the power subsystem properties for this chassis.
<b>PowerSupplies</b>	Outlet (Links)	array	An array of links to the power supplies connected to this outlet.
	Chassis (Links)	array	An array of links to the power supplies that provide power to this chassis.
	Power	array	The set of power supplies associated with this system or device.
<b>PowerSupplyRedundancy</b>	PowerDistribution	object	The link to the collection of power supplies for this equipment.
	PowerSubsystem	object	The link to the collection of power supplies within this subsystem.
	PowerDistribution	array	The redundancy information for the set of power supplies for this equipment.
<b>PowerSupplyReset (Action)</b>	PowerSubsystem	array	The redundancy information for the set of power supplies in this subsystem.
	Power (Actions)	object	This action resets the targeted power supply.
<b>PowerSupplyType</b>	Power (PowerSupplies), PowerSupply	string (enum)	The power supply type (AC or DC).
<b>PowerWatts</b>	AccelerationFunction	integer (watts)	The acceleration function power consumption, in watt units.
	PortMetrics (PoE)	number (watts)	The current power delivered or consumed on this port.
	ThermalMetrics	object	Power consumption (W) of the thermal management subsystem.
<b>PowerWatts</b>	EnvironmentMetrics, Fan, HeaterMetrics, PowerDistributionMetrics	object	Power consumption (W).
	Circuit	object	The power (W) for this circuit.

Property Name	Defined In Schema(s)	Type	Description
	OutletGroup	object	The power (W) for this outlet group.
	Outlet	object	The power (W) for this outlet.
<b>Precedence</b>	EthernetInterface (IPv6AddressPolicyTable)	integer	The IPv6 precedence, as defined in RFC6724, section 2.1.
<b>Precision</b>	MetricDefinition	integer	Number of significant digits in the metric reading.
	Sensor	number	The number of significant digits in the reading.
<b>PredictedMediaLifeLeftPercent</b>	Memory (HealthData)	number (%)	The current health of the memory device as a percentage.
	Drive	number (%)	The percentage of reads and writes that are predicted to be available for the media.
	MemoryMetrics (HealthData)	number (%)	The percentage of reads and writes that are predicted to still be available for the media.
	DriveMetrics	object	The percentage of reads and writes that are predicted to be available for the media.
<b>PredictedMediaLifeLeftThreshold</b>	Storage (Actions > SetPredictedMediaLifeLeftThreshold (Action))	integer	The predicted media life left threshold.
<b>PreferExclusive</b>	RegisteredClient (ManagedResources)	boolean	Indicates whether the registered client expects to have exclusive access to the managed resource.
<b>Preferred</b>	EndpointGroup	boolean	An indication if access to the resources through the endpoint group is preferred.
<b>PreferredAuthentications</b>	ManagerNetworkProtocol (SSH)	array	The SSH authentication methods that are permitted and the order in which they are preferred to be attempted.
<b>PreferredExecutors</b>	Job (Links), JobDocument (Actions > SubmitJob (Action))	array	An array of links to the preferred executors to run this job.
<b>PreferredMainsId</b>	PowerDistribution (TransferConfiguration)	string	The preferred source for the mains circuit to this equipment.

Property Name	Defined In Schema(s)	Type	Description
<b>Prefix</b>	EthernetInterface (IPv6AddressPolicyTable)	string	The IPv6 address prefix, as defined in RFC6724, section 2.1.
<b>PrePowerOnHeatingTimeSeconds</b>	HeaterMetrics	integer	The total number of seconds the heater was active while the device it heats was powered off.
<b>PresentedPublicHostKey</b>	AggregationSource (SSHSettings)	object	A link to the last public host key presented by the remote service corresponding to the aggregation source. A client that trusts this public host key can add the public host key to the TrustedPublicHostKeys collection to allow SSH communication with the aggregation source.
<b>PresentedPublicHostKeyTimestamp</b>	AggregationSource (SSHSettings)	string	The date and time when the key referenced by the PresentedPublicHostKey property was last updated.
<b>PreUpgradeHTTPHeaders</b>	OutboundConnection	object	The HTTP headers to send to the remote client during the initial connection prior to the WebSocket upgrade. This property is an empty object in responses.
<b>PrimaryCoolantConnectors</b>	CoolingLoop, CoolingUnit	object	A link to the primary coolant connectors for this equipment.
<b>PrimaryDNS</b>	NetworkDeviceFunction (iSCSIBoot)	string	The IPv6 or IPv4 address of the primary DNS server for the iSCSI boot initiator.
<b>PrimaryLUN</b>	NetworkDeviceFunction (iSCSIBoot)	integer	The logical unit number (LUN) for the primary iSCSI boot target.
<b>PrimaryTargetIPAddress</b>	NetworkDeviceFunction (iSCSIBoot)	string	The IPv4 or IPv6 address for the primary iSCSI boot target.
<b>PrimaryTargetName</b>	NetworkDeviceFunction (iSCSIBoot)	string	The name of the iSCSI primary boot target.
<b>PrimaryTargetTCPPort</b>	NetworkDeviceFunction (iSCSIBoot)	integer	The TCP port for the primary iSCSI boot target.
<b>PrimaryVLANEnable</b>	NetworkDeviceFunction (iSCSIBoot)	boolean	An indication of whether the primary VLAN is enabled.

Property Name	Defined In Schema(s)	Type	Description
<b>PrimaryVLANId</b>	NetworkDeviceFunction (iSCSIBoot)	integer	The 802.1q VLAN ID to use for iSCSI boot from the primary target.
<b>Priority</b>	AccountService (ActiveDirectory), AccountService (LDAP), AccountService (OAuth2), AccountService (TACACSplus), ExternalAccountProvider	integer	The authentication priority for the external account provider.
<b>PrivateEnterpriseId</b>	ManagerNetworkProtocol (SNMP > EngineId)	string	The private enterprise ID.
<b>Privilege</b>	<i>various</i> (PrivilegeRegistry (Mappings > OperationMap > DELETE), PrivilegeRegistry (Mappings > OperationMap > GET) ... )	array	An array of privileges that are required to complete a specific HTTP operation on a resource.
<b>PrivilegeLevelArgument</b>	AccountService (ActiveDirectory > TACACSplusService), AccountService (LDAP > TACACSplusService), AccountService (OAuth2 > TACACSplusService), AccountService (TACACSplus > TACACSplusService), ExternalAccountProvider (TACACSplusService)	string	Indicates the name of the TACACS+ argument name in an authorization request.
<b>PrivilegeMap</b>	AccountService	object	The link to the mapping of the privileges required to complete a requested operation on a URI associated with this service.
<b>Privileges</b>	AttributeRegistry (RegistryEntries > Attributes > RequiredPrivileges)	array	An array of privileges that are required to modify this attribute.
<b>PrivilegesUsed</b>	PrivilegeRegistry	array	The set of Redfish standard privileges used in this mapping.
<b>Processor</b>	PCleFunction (Links)	object	The link to a processor that is hosted on this PCIe function.
<b>ProcessorArchitecture</b>	Processor	string (enum)	The architecture of the processor.
<b>ProcessorId</b>	Processor	object	The identification information for this processor.

Property Name	Defined In Schema(s)	Type	Description
<b>ProcessorIndex</b>	Processor	integer	The logical index of this processor within the system.
<b>ProcessorMemory</b>	Processor	array	The memory directly attached or integrated within this processor. Examples include internal cache, dedicated memory for the processor, and system memory.
<b>Processors</b>	Memory (Links)	array	An array of links to the processors associated with this memory device.
	ResourceBlock	array	An array of links to the processors available in this resource block.
	Heater (Links)	array	An array of links to the processors heated by this heater.
	Chassis (Links)	array	An array of links to the processors located in this chassis.
	GraphicsController (Links)	array	An array of links to the processors that are a part of this graphics controller.
	PCleDevice (Links)	array	An array of links to the processors that are directly connected or directly bridged to this PCIe device.
	PCleSlots (Slots > Links)	array	An array of links to the processors that are directly connected or directly bridged to this PCIe slot.
	USBController (Links)	array	An array of links to the processors that can utilize this USB controller.
	FabricAdapter (Links)	array	An array of links to the processors that this fabric adapter provides to a fabric.
	NetworkAdapter	object	The link to the collection of offload processors contained in this network adapter.
ComputerSystem	object	The link to the collection of processors associated with this system.	

Property Name	Defined In Schema(s)	Type	Description
	Chassis	object	The link to the collection of processors located in this chassis that belong to fabric-related resource pools.
<b>ProcessorStatistics</b>	ManagerDiagnosticData	object	The processor statistics of the manager.
<b>ProcessorSummary</b>	ComputerSystem	object	The central processors of the system in general detail.
<b>ProcessorType</b>	Processor	string (enum)	The type of processor.
<b>Producer</b>	Assembly (Assemblies)	string	The producer or manufacturer of the assembly.
<b>Product</b>	ServiceRoot	string	The product associated with this Redfish service.
<b>ProductionDate</b>	Assembly (Assemblies)	string	The production date of the assembly.
	Battery	string	The production or manufacturing date of this battery.
	CoolingUnit, PowerDistribution, Pump	string	The production or manufacturing date of this equipment.
	Memory	string	The production or manufacturing date of this memory device.
	PowerSupply	string	The production or manufacturing date of this power supply.
<b>ProductName</b>	AttributeRegistry (SupportedSystems)	string	The product name of the computer system to which this attribute registry applies.
<b>ProgrammableFromHost</b>	Processor (FPGA)	boolean	An indication of whether the FPGA firmware can be reprogrammed from the host by using system software.
	Processor (FPGA > ReconfigurationSlots)	boolean	An indication of whether the reconfiguration slot can be reprogrammed from the host by using system software.
<b>ProgrammaticId</b>	ContainerImage	string	The programmatic identifier for this container image.

Property Name	Defined In Schema(s)	Type	Description
	Container	string	The programmatic identifier for this container.
<b>PropertyOverrides</b>	PrivilegeRegistry (Mappings)	array	The privilege overrides of properties within a resource.
<b>Proportional</b>	AutomationInstrumentation (PID > ControlLoop), Control (ControlLoop), CoolantConnector (DeltaPressureControlkPa > ControlLoop), CoolantConnector (DeltaTemperatureControlCelsius > ControlLoop), CoolantConnector (FlowControlLitersPerMinute > ControlLoop), CoolantConnector (ReturnTemperatureControlCelsius > ControlLoop), CoolantConnector (SupplyTemperatureControlCelsius > ControlLoop), CoolantConnector (ValvePositionControlPercent > ControlLoop), Pump (SpeedControlPercent > ControlLoop)	number	The proportional coefficient.
<b>ProtectedIdentificationNumber</b>	Processor (ProcessorId)	string	The Protected Processor Identification Number (PPIN) for this processor.
<b>Protocol</b>	Drive	string (enum)	The protocol that this drive currently uses to communicate to the storage controller.
	EventDestination	string (enum)	The protocol type of the event connection.
<b>ProtocolEnabled</b>	<i>various</i> (ManagerNetworkProtocol (DHCP), ManagerNetworkProtocol (DHCPv6) ... )	boolean	An indication of whether the protocol is enabled.
<b>ProtocolFeaturesSupported</b>	ServiceRoot	object	The information about protocol features that the service supports.
<b>ProvidedCertificate</b>	ComponentIntegrity (SPDM > IdentityAuthentication > RequesterAuthentication)	object	A link to the certificate that represents the identity of the SPDM Requester provided in mutual authentication.
<b>ProvidingStoragePool</b>	Volume (Links)	object	The StoragePool resource that provides this volume resource.

Property Name	Defined In Schema(s)	Type	Description
<b>ProvisioningPolicy</b>	Volume	string (enum)	This property specifies the volume's storage allocation, or provisioning policy.
<b>Proxy</b>	ManagerNetworkProtocol	object	The HTTP/HTTPS proxy information for this manager.
<b>ProxyAutoConfigURI</b>	ManagerNetworkProtocol (Proxy)	string	The URI used to access a proxy auto-configuration (PAC) file.
<b>ProxyServerURI</b>	ManagerNetworkProtocol (Proxy)	string	The URI of the proxy server, including the scheme and any non-default port value.
<b>PublicationUri</b>	JsonSchemaFile (Location)	string	The link to publicly available (canonical) URI for schema.
	MessageRegistryFile (Location)	string	The link to publicly available (canonical) URI for the registry.
<b>PublicIdentityKey</b>	AggregationSource (SSHSettings)	object	A link to the public key that is used with the aggregation source when the authentication method is configured to use a public key. The <code>GenerateSSHIdentityKeyPair</code> and <code>RemoveSSHIdentityKeyPair</code> are used to update the key for this aggregation source.
<b>PublicIdentitySSHKey</b>	UpdateService	object	A link to the public key that is used with the <code>SimpleUpdate</code> action for the key-based authentication. The <code>GenerateSSHIdentityKeyPair</code> and <code>RemoveSSHIdentityKeyPair</code> are used to update the key for the <code>SimpleUpdate</code> action.
<b>PumpRedundancy</b>	CoolingUnit	array	The redundancy information for the groups of pumps in this unit.
<b>Pumps</b>	CoolingUnit, ThermalSubsystem	object	A link to the pumps for this equipment.
<b>PumpSpeedPercent</b>	Pump	object	The pump speed (%).
<b>PumpType</b>	Pump	string (enum)	The type of pump.
<b>PushDiagnosticData (Action)</b>	LogService (Actions)	object	The action to push an existing diagnostic data to a target URI.

Property Name	Defined In Schema(s)	Type	Description
<b>PUT</b>	PrivilegeRegistry (Mappings > OperationMap), PrivilegeRegistry (Mappings > PropertyOverrides > OperationMap), PrivilegeRegistry (Mappings > ResourceURIOverrides > OperationMap), PrivilegeRegistry (Mappings > SubordinateOverrides > OperationMap)	array	The privilege required to complete an HTTP <code>PUT</code> operation.
<b>QoS</b>	CXLLogicalDevice	object	The quality of service configuration for this CXL logical device.
<b>QoSTelemetryCapabilities</b>	CXLLogicalDevice	object	The quality of service telemetry capabilities for this CXL logical device.
	Port (CXL)	object	The quality of service telemetry capabilities for this CXL port.
<b>RackMountCapacityUnits</b>	Chassis	number	The usable capacity of rack units provided by this chassis.
<b>RackMountDepthMm</b>	Chassis	number (mm)	The usable depth of the rack-mountable area of the chassis.
<b>RackMountWidth</b>	Chassis	string (enum)	The width of the rack-mountable chassis or rack-mounting space.
<b>RackPDUs</b>	Facility (Links)	array	An array of links to the rack-level power distribution units in this facility.
	PowerDomain (Links)	array	An array of links to the rack-level power distribution units in this power domain.
	PowerEquipment	object	A link to a collection of rack-level power distribution units.
<b>RackUnits</b>	Chassis	string (enum)	The type of rack-mount units.
<b>RAIDType</b>	Volume	string (enum)	The RAID type of this volume.
	Volume (Actions > ChangeRAIDLAYOUT (Action))	string (enum)	The requested RAID type for the volume.
<b>RailCurrentAmps</b>	PowerSupplyMetrics	array	The output currents (A) for this power supply.

Property Name	Defined In Schema(s)	Type	Description
<b>RailPowerWatts</b>	PowerSupplyMetrics	array	The output power readings (W) for this power supply.
<b>RailVoltage</b>	PowerSupplyMetrics	array	The output voltages (V) for this power supply.
<b>RankCount</b>	Memory	integer	Number of ranks available in the memory device.
<b>RatedCurrentAmps</b>	Circuit	number (A)	The rated maximum current allowed for this circuit.
	Outlet	number (A)	The rated maximum current allowed for this outlet.
<b>RatedFlowLitersPerMinute</b>	CoolingLoop	number (L/min)	The rated liquid flow (L/min) for this cooling loop.
	CoolantConnector	number (L/min)	The rated liquid flow (L/min) for this loop interface.
<b>RatedFlowPressurekPa</b>	CoolantConnector	number (kPa)	The pressure (kPa) at which the rated liquid flow is valid.
<b>RatedPressurekPa</b>	CoolantConnector	number (kPa)	The rated pressure (kPa) for this connector.
	CoolingLoop	number (kPa)	The rated pressure (kPa) for this cooling loop.
<b>RatedSecondarySpeedRPM</b>	Fan	integer (rev/min)	The rated maximum rotational speed of the second rotor in a multi-rotor fan.
<b>RatedServiceHours</b>	CoolingLoop (Coolant)	number	The rated hours of service life for this coolant.
	Filter	number	The rated hours of service life for this filter.
<b>RatedSpeedRPM</b>	Fan	integer (rev/min)	The rated maximum rotational speed of the fan.
<b>RatedThermalLossToAirWatts</b>	CoolingUnit	integer	The rated maximum amount of heat, in watt units, lost to the surrounding environment during normal operation.
<b>RawEntryHex</b>	VCATEntry	string	The hexadecimal value of the Virtual Channel Action Table entries.

Property Name	Defined In Schema(s)	Type	Description
	RouteEntry	string	The raw data of route entry rows.
<b>RDMAProtectionErrors</b>	PortMetrics (Networking)	integer	The total number of RDMA protection errors.
<b>RDMAProtocolErrors</b>	PortMetrics (Networking)	integer	The total number of RDMA protocol errors.
<b>RDMARXBytes</b>	PortMetrics (Networking)	integer	The total number of RDMA bytes received on a port since reset.
<b>RDMARXRequests</b>	PortMetrics (Networking)	integer	The total number of RDMA requests received on a port since reset.
<b>RDMATXBytes</b>	PortMetrics (Networking)	integer	The total number of RDMA bytes transmitted on a port since reset.
<b>RDMATXReadRequests</b>	PortMetrics (Networking)	integer	The total number of RDMA read requests transmitted on a port since reset.
<b>RDMATXRequests</b>	PortMetrics (Networking)	integer	The total number of RDMA requests transmitted on a port since reset.
<b>RDMATXSendRequests</b>	PortMetrics (Networking)	integer	The total number of RDMA send requests transmitted on a port since reset.
<b>RDMATXWriteRequests</b>	PortMetrics (Networking)	integer	The total number of RDMA write requests transmitted on a port since reset.
<b>RDP</b>	ManagerNetworkProtocol	object	The settings for this manager's Remote Desktop Protocol support.
<b>ReactionDelaySeconds</b>	LeakDetector	integer (seconds)	The delay in seconds after a leak is detected before the selected reaction is executed.
<b>ReactivekVARh</b>	<i>various</i> (Circuit (EnergykWh), Circuit (PolyPhaseEnergykWh > Line1ToLine2) ... )	number (kV.A.h)	Reactive energy (kVARh).
<b>ReactiveVAR</b>	<i>various</i> (Circuit (PolyPhasePowerWatts > Line1ToLine2), Circuit (PolyPhasePowerWatts > Line1ToNeutral) ... )	number (V.A)	The square root of the difference term of squared apparent VA and squared power (Reading) for a circuit, in VAR units.
<b>ReadCachePolicy</b>	Volume	string (enum)	Indicates the read cache policy setting for the Volume.

Property Name	Defined In Schema(s)	Type	Description
<b>Reading</b>	Thermal (Fans)	integer	The fan speed.
	<i>various</i> (AutomationInstrumentation (NodeControl), AutomationInstrumentation (PID) ... )	number	The reading of the sensor associated with this control.
	<i>various</i> (AutomationInstrumentation (CurrentAmps), AutomationInstrumentation (TemperatureCelsius) ... )	number	The sensor value.
	<i>various</i> (DriveMetrics (PredictedMediaLifeLeftPercent > Thresholds > LowerCritical), DriveMetrics (PredictedMediaLifeLeftPercent > Thresholds > LowerCriticalUser) ... )	number	The threshold value.
<b>ReadingAccuracy</b>	Sensor	number	Accuracy (+/-) of the reading.
<b>ReadingBasis</b>	Sensor	string (enum)	The basis for the reading of this sensor.
<b>ReadingCelsius</b>	Thermal (Temperatures)	number (Celsius)	The temperature (C).
<b>ReadingRangeMax</b>	Sensor	number	The maximum possible value for this sensor.
<b>ReadingRangeMin</b>	Sensor	number	The minimum possible value for this sensor.
<b>ReadingTime</b>	Sensor	string	The date and time that the reading was acquired from the sensor.
<b>ReadingType</b>	Sensor	string (enum)	The type of sensor.
<b>ReadingUnits</b>	Sensor	string	The units of the reading, thresholds, and other reading-related properties in UCUM c/s format.
	AutomationInstrumentation (NodeControl)	string	The units of the sensor reading associated with this control.
	Thermal (Fans)	string (enum)	The units in which the fan reading and thresholds are measured.
<b>ReadingVolts</b>	Power (Voltages)	number (volts)	The reading of the voltage sensor.

Property Name	Defined In Schema(s)	Type	Description
<b>ReadIOKiBytes</b>	DriveMetrics	integer (KiBy)	The number of kibibytes read.
<b>ReadOnly</b>	AttributeRegistry (RegistryEntries > Attributes)	boolean	An indication of whether this attribute is read-only. A read-only attribute cannot be modified, and should be grayed out in user interfaces.
	AttributeRegistry (RegistryEntries > Menus)	boolean	An indication of whether this menu is read-only. A read-only menu, its properties, and sub-menus are not accessible in user interfaces.
	ManagerNetworkProtocol (Modbus), SerialInterface (Modbus)	boolean	Indicates if the interface is read only.
<b>ReadOnlyRegion</b>	MemoryRegion	boolean	An indication of whether the memory region is read-only.
<b>ReadyToRemove</b>	Assembly (Assemblies)	boolean	An indication of whether the assembly is prepared by the system for removal.
	Chassis	boolean	An indication of whether the chassis is prepared by the system for removal.
	Drive	boolean	An indication of whether the drive is prepared by the system for removal.
	Manager	boolean	An indication of whether the manager is prepared by the system for removal.
	PCleDevice	boolean	An indication of whether the PCIe device is prepared by the system for removal.
<b>Rear</b>	Chassis (Doors)	object	The rear door of the chassis.
<b>RebuildRatePercent</b>	Storage (StorageControllers > ControllerRates)	integer	The percentage of controller resources used for rebuilding/repairing volumes.
	StorageController (ControllerRates)	integer (%)	The percentage of controller resources used for rebuilding/repairing volumes.

Property Name	Defined In Schema(s)	Type	Description
<b>ReceivedECN</b>	PortMetrics (GenZ)	integer	The number of packets received on this interface with the Congestion ECN bit set.
<b>ReconfigurationSlots</b>	Processor (FPGA)	array	An array of the FPGA reconfiguration slots. An FPGA uses a reconfiguration slot to contain an acceleration function that can change as the FPGA is provisioned.
<b>RecoverableCapacitySourceCount</b>	Volume	integer	Current number of capacity source resources that are available as replacements.
<b>RedfishVersion</b>	ServiceRoot	string	The version of the Redfish service.
<b>Redundancy</b>	Endpoint	array	Redundancy information for the lower-level endpoints supporting this endpoint.
	Storage	array	Redundancy information for the storage subsystem.
	Switch	array	Redundancy information for the switches.
	ComputerSystem	array	The link to a collection of redundancy entities. Each entity specifies a kind and level of redundancy and a collection, or redundancy set, of other computer systems that provide the specified redundancy to this computer system.
	Manager	array	The redundancy information for the managers of this system.
	Thermal	array	The redundancy information for the set of fans in this chassis.
	Power	array	The redundancy information for the set of power supplies in this chassis.
	Thermal (Fans)	array	The set of redundancy groups for this fan.

Property Name	Defined In Schema(s)	Type	Description
	Power (PowerSupplies)	array	The set of redundancy groups for this power supply.
<b>RedundantGroup</b>	CoolingUnit (CoolantConnectorRedundancy), CoolingUnit (CoolingUnitRedundancy), CoolingUnit (FilterRedundancy), CoolingUnit (PumpRedundancy), PowerDistribution (PowerDistributionRedundancy), PowerDistribution (PowerSupplyRedundancy), PowerSubsystem (PowerSupplyRedundancy), ThermalEquipment (CoolingLoopRedundancy), ThermalSubsystem (CoolantConnectorRedundancy), ThermalSubsystem (FanRedundancy)	object	The redundancy information for the devices in a redundancy group.
<b>ReferenceClockMode</b>	Port (PCIe)	string (enum)	The PCIe reference clock mode for this port.
<b>RegionBaseOffsetMiB</b>	MemoryRegion	integer (mebibytes)	The offset of the memory region in the device address range in mebibytes (MiB).
<b>RegionId</b>	MemoryChunks (InterleaveSets)	string	DIMM region identifier.
	Memory (Actions > SetMasterPassphrase (Action))	string	The memory region ID to which to apply the master passphrase.
	Memory (Actions > DisablePassphrase (Action)), Memory (Actions > OverwriteUnit (Action)), Memory (Actions > SecureEraseUnit (Action)), Memory (Actions > SetPassphrase (Action)), Memory (Actions > UnlockUnit (Action))	string	The memory region ID to which to apply this action.
	Memory (Actions > DisableMasterPassphrase (Action))	string	The memory region ID to which to disable the master passphrase.
	Memory (Regions)	string	Unique region ID representing a specific region within the memory device.

Property Name	Defined In Schema(s)	Type	Description
<b>RegionKey</b>	Endpoint (ConnectedEntities > GenZ)	string	The Region Key for the entity.
<b>RegionNumber</b>	CXLLogicalDevice (Actions > DynamicCapacityAdd (Action)), MemoryRegion, PCIeDevice (CXLDevice > DynamicCapacity > MemoryBlockSizesSupported), PCIeDevice (CXLDevice > DynamicCapacity > SanitizationOnReleaseSupport)	integer	The memory region number.
<b>Regions</b>	Memory	array	Memory regions information within the memory device.
<b>RegionSizeMiB</b>	MemoryRegion	integer (mebibytes)	The size of the memory region in mebibytes (MiB).
<b>RegionType</b>	MemoryRegion	string (enum)	The type of memory region.
<b>RegisteredClients</b>	ServiceRoot	object	The link to a collection of registered clients.
<b>Registries</b>	ServiceRoot	object	The link to a collection of registries.
<b>Registry</b>	MessageRegistryFile	string	The registry name and its major and minor versions. This registry can be any type of registry, such as a message registry, privilege registry, or attribute registry.
<b>RegistryEntries</b>	AttributeRegistry	object	The list of all attributes and their metadata for this component.
<b>RegistryPrefix</b>	EventService (SSEFilterPropertiesSupported)	boolean	An indication of whether the service supports filtering by the <code>RegistryPrefixes</code> property.
	MessageRegistry	string	The single-word prefix that is used in forming and decoding <code>MessageId</code> values.
<b>RegistryPrefixes</b>	EventDestination	array	The list of prefixes for the message registries that contain the <code>MessageId</code> values that are sent to this event destination.

Property Name	Defined In Schema(s)	Type	Description
	EventService	array	The list of the prefixes of the message registries that can be used for the <code>RegistryPrefixes</code> or <code>ExcludeRegistryPrefixes</code> properties on a subscription. If this property is absent or contains an empty array, the service does not support registry prefix-based subscriptions.
<b>RegistryVersion</b>	AttributeRegistry	string	The attribute registry version.
	MessageRegistry	string	The message registry version in the middle portion of a <code>MessageId</code> .
<b>Rekey (Action)</b>	Certificate (Actions)	object	This action generates a new key-pair for a certificate and produces a certificate signing request.
<b>RekeyExternalKey (Action)</b>	Storage (Actions)	object	This action causes the controllers of the storage subsystem to request new encryption keys managed by an external key service.
<b>RelatedInterfaces</b>	EthernetInterface (Links)	array	The links to the Ethernet interfaces that constitute this Ethernet interface.
<b>RelatedItem</b>	LogEntry (Links)	array	An array of links to resources associated with this log entry.
	BootOption	array	An array of links to resources or objects associated with this boot option.
	Power (PowerControl)	array	An array of links to resources or objects associated with this power limit.
	Power (PowerSupplies)	array	An array of links to resources or objects associated with this power supply.
	Thermal (Temperatures)	array	An array of links to resources or objects that represent areas or devices to which this temperature applies.

Property Name	Defined In Schema(s)	Type	Description
	SoftwareInventory	array	An array of links to resources or objects that represent devices to which this software inventory applies.
	Thermal (Fans)	array	An array of links to resources or objects that this fan services.
	Sensor	array	An array of links to resources or objects that this sensor services.
	Power (Voltages)	array	An array of links to resources or objects to which this voltage measurement applies.
	Control	array	An array of links to resources that this control services.
<b>RelatedLogEntries</b>	LogEntry (Links)	array	An array of links to other log entries that are related to this log entry.
<b>RelativePerformance</b>	Volume (NVMeNamespaceProperties > LBAFormat), Volume (NVMeNamespaceProperties > LBAFormats)	string (enum)	The LBA Relative Performance type.
<b>Release</b>	MessageRegistry	string	The release bundle that first included this version of the message registry.
	OperatingSystem (Kernel)	string	The release of the kernel.
<b>ReleaseCapacityPoliciesSupported</b>	PCIeDevice (CXLDevice > DynamicCapacity)	array	The set of removal policies supported by the CXL device when dynamic capacity is released.
<b>ReleaseDate</b>	SoftwareInventory	string	The release date of this software.
<b>ReleaseType</b>	SoftwareInventory	string (enum)	The type of release.
<b>ReliabilityDegraded</b>	StorageControllerMetrics (NVMeSMART > EGCriticalWarningSummary)	boolean	An indication of whether the reliability of one or more Endurance Groups is degraded due to significant media-related errors or any internal error that degrades the NVM subsystem reliability.
<b>RemainingAutomaticRetryAttempts</b>	ComputerSystem (Boot)	integer	The number of remaining automatic retry boots.

Property Name	Defined In Schema(s)	Type	Description
<b>RemainingCapacityPercent</b>	Volume	integer	The percentage of the capacity remaining in the Volume.
<b>RemainingDuration</b>	License	string	The remaining usage duration before the license expires.
<b>RemainingSpareBlockPercentage</b>	MemoryMetrics (HealthData)	number (%)	The remaining spare blocks, as a percentage.
<b>RemainingUseCount</b>	License	integer	The remaining usage count before the license expires.
<b>RemoteAccountService</b>	Manager	object	The link to the account service resource for the remote manager that this resource represents.
<b>RemoteGroup</b>	AccountService (ActiveDirectory > RemoteRoleMapping), AccountService (LDAP > RemoteRoleMapping), AccountService (OAuth2 > RemoteRoleMapping), AccountService (TACACSplus > RemoteRoleMapping), ExternalAccountProvider (RemoteRoleMapping)	string	The name of the remote group, or the remote role in the case of a Redfish service, that maps to the local Redfish role to which this entity links.
<b>RemoteMemoryBandwidthBytes</b>	ProcessorMetrics	integer (bytes)	The remote memory bandwidth usage in bytes.
<b>RemotePortId</b>	Port	string	The identifier of the remote port to which this port is connected.
<b>RemoteRedfishServiceUri</b>	Manager	string	The URI of the Redfish service root for the remote manager that this resource represents.
<b>RemoteReplicaTargets</b>	Volume	array	URIs to the resources that are remote target replicas of this source.
<b>RemoteRoleMapping</b>	AccountService (ActiveDirectory), AccountService (LDAP), AccountService (OAuth2), AccountService (TACACSplus), ExternalAccountProvider	array	The mapping rules to convert the external account providers account information to the local Redfish role.

Property Name	Defined In Schema(s)	Type	Description
<b>RemoteServerCertificates</b>	UpdateService	object	The link to a collection of server certificates for the server referenced by the <code>ImageURI</code> parameter in <code>SimpleUpdate</code> .
<b>RemoteServerHostName</b>	Key (SSH)	string	The host name of the remote server associated with this key.
<b>RemoteServerSSHKeys</b>	UpdateService	object	The link to a collection of keys that can be used to authenticate the server referenced by the <code>ImageURI</code> parameter in <code>SimpleUpdate</code> .
<b>RemoteUser</b>	AccountService (ActiveDirectory > RemoteRoleMapping), AccountService (LDAP > RemoteRoleMapping), AccountService (OAuth2 > RemoteRoleMapping), AccountService (TACACSplus > RemoteRoleMapping), ExternalAccountProvider (RemoteRoleMapping)	string	The name of the remote user that maps to the local Redfish role to which this entity links.
<b>Removable</b>	License	boolean	An indication of whether the license is removable.
<b>Remove</b>	Manager (Actions > ModifyRedundancySet (Action))	array	An array of managers to remove from the redundancy set.
<b>RemoveElements (Action)</b>	Aggregate (Actions)	object	This action is used to remove one or more resources from the aggregate.
<b>RemoveEndpoint (Action)</b>	Zone (Actions)	object	This action removes an endpoint from a zone.
<b>RemoveReplicaRelationship (Action)</b>	Volume (Actions)	object	This action is used to disable data synchronization between a source and target volume, remove the replication relationship, and optionally delete the target volume.
<b>RemoveResourceBlock (Action)</b>	ComputerSystem (Actions)	object	This action removes a resource block from a system.
<b>RemoveSSHIdentityKeyPair (Action)</b>	UpdateService (Actions)	object	This action removes the SSH identity key-pair used with the <code>UpdateService</code> resource.

Property Name	Defined In Schema(s)	Type	Description
	AggregationSource (Actions)	object	This action removes the SSH identity key-pair used with this aggregation source.
<b>RemoveVolumeInfo (Action)</b>	Connection (Actions)	object	This action removes a volume from the connection. Volumes are removed from the <code>VolumeInfo</code> property.
<b>Renew (Action)</b>	Certificate (Actions)	object	This action generates a certificate signing request by using the existing information and key-pair of the certificate.
<b>RenewBeforeExpiryDays</b>	CertificateEnrollment	integer	The number of days before certificate expiry to begin automatic renewal of the certificate.
<b>Replaceable</b>	Assembly (Assemblies)	boolean	An indication of whether the component associated this assembly can be independently replaced as allowed by the vendor's replacement policy.
	Battery, Chassis, Fan, Filter, PowerSupply, Processor	boolean	An indication of whether this component can be independently replaced as allowed by the vendor's replacement policy.
<b>ReplaceCertificate (Action)</b>	CertificateService (Actions)	object	This action replaces a certificate.
<b>ReplacePeerASEnabled</b>	AddressPool (Ethernet > EBGP > BGPNeighbor), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor)	boolean	Replace Border Gateway Protocol (BGP) peer Autonomous System (AS) status.
<b>ReplicaInfo</b>	Volume	object	Describes this storage volume in its role as a target replica.
<b>ReplicaTargets</b>	Volume	array	The resources that are target replicas of this source.
<b>ReplicationEnabled</b>	Volume	boolean	Indicates whether or not replication is enabled on the volume.

Property Name	Defined In Schema(s)	Type	Description
<b>ReplicaType</b>	Volume (Actions > AssignReplicaTarget (Action)), Volume (Actions > CreateReplicaTarget (Action))	string (enum)	The type of replica relationship to be created.
<b>ReplicaUpdateMode</b>	Volume (Actions > AssignReplicaTarget (Action)), Volume (Actions > CreateReplicaTarget (Action))	string (enum)	The replica update mode (synchronous vs asynchronous).
<b>ReportActions</b>	MetricReportDefinition	array	The set of actions to perform when a metric report is generated.
<b>ReportActionsEnum</b>	MetricReportDefinition (ReportActions)	string (enum)	Actions to perform when a metric report is generated.
<b>ReportSequence</b>	MetricReport	string	The current sequence identifier for this metric report.
<b>ReportsNamespaceGranularity</b>	StorageController (NVMeControllerProperties > NVMeControllerAttributes)	boolean	Indicates whether or not the controller supports reporting of Namespace Granularity.
<b>ReportsUUIDList</b>	StorageController (NVMeControllerProperties > NVMeControllerAttributes)	boolean	Indicates whether or not the controller supports reporting of a UUID list.
<b>ReportTimespan</b>	MetricReportDefinition	string	The maximum timespan that a metric report can cover.
<b>ReportUpdates</b>	MetricReportDefinition	string (enum)	The behavior for how subsequent metric reports are handled in relationship to an existing metric report created from the metric report definition. Namely, whether to overwrite, append, or create a metric report.
<b>RequestedOperationalState</b>	MemoryChunks	string (enum)	The requested operational state of this memory chunk.
<b>RequestedWatts</b>	PowerSubsystem (Allocation)	number (watts)	The potential power, in watt units, that the subsystem requests, which might be higher than the current level being consumed because the requested power includes a budget that the subsystem wants for future use.

Property Name	Defined In Schema(s)	Type	Description
<b>Requester</b>	ComponentIntegrity (SPDM)	object	The link to the component that is reporting the integrity information of the target component.
<b>RequesterAuthentication</b>	ComponentIntegrity (SPDM > IdentityAuthentication)	object	Authentication information of the identity of the SPDM Requester.
<b>RequestFormat</b>	CompositionService (Actions > Compose (Action))	string (enum)	The format of the request.
<b>RequestorVCAT</b>	FabricAdapter (GenZ)	object	The Requestor Virtual Channel Action Table for the component.
<b>RequestType</b>	CompositionService (Actions > Compose (Action))	string (enum)	The type of request.
<b>RequireChangePasswordAction</b>	AccountService	boolean	An indication of whether clients are required to invoke the <code>ChangePassword</code> action to modify account passwords.
<b>Required</b>	ActionInfo (Parameters)	boolean	An indication of whether the parameter is required to complete this action.
	JobDocument (ParameterMetadata)	boolean	An indication of whether the parameter is required.
<b>RequiredMinRxIntervalMilliseconds</b>	AddressPool (Ethernet > BFDSingleHopOnly)	integer	Bidirectional Forwarding Detection (BFD) receive value.
<b>RequiredPrivileges</b>	AttributeRegistry (RegistryEntries > Attributes)	array	The privileges required to complete an HTTP <code>PATCH</code> or <code>PUT</code> operation to modify this attribute.
<b>RequireSecureErase</b>	ComputerSystem (Actions > Decommission (Action))	boolean	Ensure secure erasure of all devices and fail the request if not possible.
<b>ReservationDuration</b>	CompositionService	string	The length of time a composition reservation is held before the service deletes the reservation and marks any related resource blocks as no longer reserved.

Property Name	Defined In Schema(s)	Type	Description
<b>ReservationId</b>	CompositionService (Actions > Compose (Action))	string	The identifier of the composition reservation if applying a reservation. The value for this parameter is obtained from the response of a <code>Compose</code> action where the <code>RequestType</code> parameter contains the value <code>PreviewReserve</code> .
<b>ReservationTime</b>	CompositionReservation	string	The date and time the service created the reservation.
<b>Reserved</b>	ResourceBlock (CompositionStatus)	boolean	An indication of whether any client has reserved the resource block.
<b>ReservedResourceBlocks</b>	CompositionReservation	array	The array of links to the reserved resource blocks.
<b>Reservoirs</b>	CoolingUnit	object	A link to the reservoirs for this equipment.
<b>ReservoirType</b>	Reservoir	string (enum)	The type of reservoir.
<b>Reset (Action)</b>	AutomationNode (Actions)	object	Resets the node.
	Manager (Actions)	object	The reset action resets/reboots the manager.
	Aggregate (Actions)	object	This action is used to reset a collection of resources. For example, this could be an aggregate or a list of computer systems.
	AggregationService (Actions)	object	This action is used to reset a set of resources. For example this could be a list of computer systems.
	Application (Actions)	object	This action resets the application.
	Battery (Actions)	object	This action resets the battery.
	Chassis (Actions)	object	This action resets the chassis. Additionally, it could reset systems or other contained resources depending on the <code>ResetType</code> used to invoke this action.
	Container (Actions)	object	This action resets the container.

Property Name	Defined In Schema(s)	Type	Description
	NetworkAdapter (Actions)	object	This action resets the network adapter.
	PowerSupply (Actions)	object	This action resets the power supply.
	Processor (Actions)	object	This action resets the processor.
	ComputerSystem (Actions)	object	This action resets the system.
	Drive (Actions)	object	This action resets this drive.
	MediaController (Actions)	object	This action resets this media controller.
	Memory (Actions)	object	This action resets this memory device.
	Port (Actions)	object	This action resets this port.
	StorageController (Actions)	object	This action resets this storage controller.
	Switch (Actions)	object	This action resets this switch.
<b>ResetBios (Action)</b>	Bios (Actions)	object	This action resets the BIOS attributes to default.
<b>ResetBiosToDefaultsPending</b>	Bios	boolean	An indication of whether there is a pending request to reset the BIOS attributes to default values.
<b>ResetKeys (Action)</b>	SecureBootDatabase (Actions)	object	This action is used to reset the UEFI Secure Boot keys of this database.
	SecureBoot (Actions)	object	This action resets the UEFI Secure Boot keys.
<b>ResetKeyType</b>	SecureBoot (Actions > ResetKeys (Action))	string (enum)	The type of reset or delete to perform on the UEFI Secure Boot databases.
	SecureBootDatabase (Actions > ResetKeys (Action))	string (enum)	The type of reset or delete to perform on this UEFI Secure Boot database.
<b>ResetMetricReportDefinitionsToDefaults (Action)</b>	TelemetryService (Actions)	object	The action to reset the metric report definitions to factory defaults.
<b>ResetMetrics (Action)</b>	Sensor (Actions)	object	Resets metrics related to this sensor.

Property Name	Defined In Schema(s)	Type	Description
	ManagerDiagnosticData (Actions)	object	Resets time intervals or counted values of the diagnostic data for this manager.
	Circuit (Actions)	object	This action resets metrics related to this circuit.
	OutletGroup (Actions)	object	This action resets metrics related to this outlet group.
	Outlet (Actions)	object	This action resets metrics related to this outlet.
	NetworkAdapterMetrics (Actions), NetworkDeviceFunctionMetrics (Actions), PortMetrics (Actions)	object	This action resets the summary metrics related to this device.
	EnvironmentMetrics (Actions), HeaterMetrics (Actions), PowerDistributionMetrics (Actions), PowerSupplyMetrics (Actions), ThermalMetrics (Actions)	object	This action resets the summary metrics related to this equipment.
<b>ResetPPB (Action)</b>	Port (Actions)	object	This action resets the PCI-to-PCI bridge (PPB) for this port.
<b>ResetRequired</b>	AttributeRegistry (RegistryEntries > Attributes)	boolean	An indication of whether a system or device reset is required for this attribute value change to take effect.
<b>ResetRequiredOnUpdate</b>	SoftwareInventory	boolean	An indication of whether a reset is required to apply an update to this software.
<b>ResetSettingsToDefault (Action)</b>	NetworkAdapter (Actions)	object	This action is to clear the settings back to factory defaults.
<b>ResetThresholdsToDefaults (Action)</b>	Sensor (Actions)	object	The action resets the sensor thresholds to factory defaults.
<b>ResetToDefaults (Action)</b>	Control (Actions), EnvironmentMetrics (Actions), Memory (Actions), Processor (Actions), Sensor (Actions)	object	The action resets the values of writable properties to factory defaults.
	Manager (Actions)	object	The reset action resets the manager settings to factory defaults. This can cause the manager to reset.

Property Name	Defined In Schema(s)	Type	Description
	Storage (Actions)	object	The reset action resets the storage device to factory defaults. This can cause the loss of data.
<b>ResetTriggersToDefaults (Action)</b>	TelemetryService (Actions)	object	The action to reset the triggers to factory defaults.
<b>ResetType</b>	Manager (Actions > ResetToDefaults (Action)), Storage (Actions > ResetToDefaults (Action))	string (enum)	The type of reset to defaults.
	<i>various</i> (Aggregate (Actions > Reset (Action)), AggregationService (Actions > Reset (Action)) ... )	string (enum)	The type of reset.
<b>ResidencyPercent</b>	ProcessorMetrics (CoreMetrics > CStateResidency)	number (%)	The percentage of time that the processor or core has spent in this particular level of C-state.
<b>ResidentSetSizeBytes</b>	ManagerDiagnosticData (TopProcesses)	integer (bytes)	The resident set size of this process in bytes.
<b>Resolution</b>	Event (Events)	string	Used to provide suggestions on how to resolve the situation that caused the event.
	LogEntry	string	Used to provide suggestions on how to resolve the situation that caused the log entry.
<b>ResolutionStep</b>	Event (Events > ResolutionSteps), LogEntry (ResolutionSteps)	object	This type describes a recommended step of the service-defined resolution.
<b>ResolutionSteps</b>	Event (Events)	array	The list of recommended steps to resolve the cause of the event.
	LogEntry	array	The list of recommended steps to resolve the cause of the log entry.
<b>Resolved</b>	LogEntry	boolean	Indicates if the cause of the log entry has been resolved or repaired.
<b>ResourceBlock</b>	ComputerSystem (Actions > AddResourceBlock (Action))	object	The resource block to add to the system.
	ComputerSystem (Actions > RemoveResourceBlock (Action))	object	The resource block to remove from the system.

Property Name	Defined In Schema(s)	Type	Description
<b>ResourceBlockETag</b>	ComputerSystem (Actions > AddResourceBlock (Action))	string	The current ETag of the resource block to add to the system.
	ComputerSystem (Actions > RemoveResourceBlock (Action))	string	The current ETag of the resource block to remove from the system.
<b>ResourceBlocks</b>	Chassis (Links)	array	An array of links to the resource blocks located in this chassis.
	ComputerSystem (Links)	array	An array of links to the resource blocks that are used in this computer system.
	Zone (Links)	array	The links to the resource blocks with which this zone is associated.
	ServiceRoot	object	The link to a collection of resource blocks. This collection is intended for implementations that do not contain a composition service but that expose resources to an orchestrator that implements a composition service.
	CompositionService	object	The resource blocks available on the service.
<b>ResourceBlockType</b>	ResourceBlock	array	The types of resources available on this resource block.
<b>ResourcesAccessed</b>	AggregationSource (Links)	array	An array links to the resources added to the service through this aggregation source. It is recommended that this be the minimal number of properties needed to find the resources that would be lost when the aggregation source is deleted.
<b>ResourceType</b>	EventService (SSEFilterPropertiesSupported)	boolean	An indication of whether the service supports filtering by the <code>ResourceTypes</code> property.

Property Name	Defined In Schema(s)	Type	Description
<b>ResourceTypes</b>	EventService	array	The list of @odata.type values, or schema names, that can be specified in the ResourceTypes array in a subscription. If this property is absent or contains an empty array, the service does not support resource type-based subscriptions.
	EventDestination	array	The list of resource type values (schema names) that correspond to the OriginOfCondition. The version and full namespace should not be specified.
<b>ResourceURIOverrides</b>	PrivilegeRegistry (Mappings)	array	The privilege overrides of resource URIs.
<b>ResourceZones</b>	CompositionService	object	The resource zones available on the service.
<b>ResponderAuthentication</b>	ComponentIntegrity (SPDM > IdentityAuthentication)	object	Authentication information of the identity of the SPDM Responder.
<b>ResponderVCAT</b>	FabricAdapter (GenZ)	object	The Responder Virtual Channel Action Table for the component.
<b>RespondToUnauthenticatedClients</b>	AccountService (MultiFactorAuth > ClientCertificate)	boolean	An indication of whether the service responds to clients that do not successfully authenticate.
<b>RestartAfterFailureCount</b>	ManagerDiagnosticData (TopProcesses)	integer	The number of times this process has restarted unexpectedly.
<b>RestartCount</b>	ManagerDiagnosticData (TopProcesses)	integer	The number of times this process has restarted.
<b>RestartTimerSeconds</b>	AddressPool (Ethernet > EBG > BGPNeighbor > MaxPrefix), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor > MaxPrefix), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor > MaxPrefix)	integer	Border Gateway Protocol (BGP) restart timer in seconds.
<b>RestrictAccessToAllowedClients</b>	ManagerNetworkProtocol (Modbus)	boolean	Indicates if access to this Modbus TCP server protocol interface is restricted to allowed clients.

Property Name	Defined In Schema(s)	Type	Description
<b>RestrictCommunityToIPv4AddressRange</b>	ManagerNetworkProtocol (SNMP > CommunityStrings)	boolean	Indicates if this community is restricted to accessing the service from a range of IPv4 addresses.
<b>Restricted</b>	Role	boolean	An indication of whether use of the role is restricted.
<b>RestrictedOemPrivileges</b>	AccountService	array	The set of restricted OEM privileges.
<b>RestrictedPrivileges</b>	AccountService	array	The set of restricted Redfish privileges.
<b>Resubmit (Action)</b>	Job (Actions)	object	Resubmits the job.
<b>ResultMetric</b>	MetricDefinition (CalculationParameters)	string	The URI with wildcards and property identifiers of the metric property that stores the result of the calculation. If the URI has wildcards, the wildcards are substituted as specified in the <code>wildcards</code> property.
<b>Resume (Action)</b>	Job (Actions)	object	Resumes the job.
<b>ResumeReplication (Action)</b>	Volume (Actions)	object	This action is used to resume the active data synchronization between a source and target volume, without otherwise altering the replication relationship.
<b>ResumeSubscription (Action)</b>	EventDestination (Actions)	object	This action resumes a suspended event subscription.
<b>RetransferDelaySeconds</b>	PowerDistribution (TransferConfiguration)	integer	The time in seconds to delay the automatic transfer from the alternate mains circuit back to the preferred mains circuit.
<b>RetransferEnabled</b>	PowerDistribution (TransferConfiguration)	boolean	Indicates if the automatic transfer is permitted from the alternate mains circuit back to the preferred mains circuit after the preferred mains circuit is qualified again and the retransfer delay time has expired.

Property Name	Defined In Schema(s)	Type	Description
<b>Retries</b>	AccountService (ActiveDirectory), AccountService (LDAP), AccountService (OAuth2), AccountService (TACACSplus), ExternalAccountProvider	integer	The number of times to retry connecting to an address in the <code>ServiceAddresses</code> property before attempting the next address in the array.
<b>RetryCount</b>	OutboundConnection (RetryPolicy)	integer	The number of retries to attempt if the retry policy specifies a maximum number of retries.
<b>RetryIntervalMinutes</b>	OutboundConnection (RetryPolicy)	integer	The retry interval in minutes.
<b>RetryPolicy</b>	OutboundConnection	object	The retry policy for this outbound connection.
<b>ReturnPressurekPa</b>	CoolantConnector	object	The return pressure (kPa).
<b>ReturnTemperatureCelsius</b>	CoolantConnector	object	The return temperature (C).
<b>ReturnTemperatureControlCelsius</b>	CoolantConnector	object	The desired return temperature (C).
<b>ReverseReplicationRelationship (Action)</b>	Volume (Actions)	object	This action is used to reverse the replication relationship between a source and target volume.
<b>RevertPersonalitiesToDefaults (Action)</b>	Drive (Actions), Storage (Actions)	object	This action reverts all personalities to their manufacturing default state for the NVMe subsystem.
<b>RevertToOriginalFactoryState (Action)</b>	Drive (Actions)	object	This action reverts a self-encrypting drive (SED) to the original factory state.
<b>Revision</b>	Drive	string	The revision of a SCSI-based drive, as returned from the 'Inquiry' command, which can be the firmware or hardware version. For other types of drives, the <code>HardwareVersion</code> and <code>FirmwareVersion</code> properties are recommended in favor of this property.
<b>RevisionId</b>	PCleFunction	string	The Revision ID of this PCIe function.
<b>RevokedCertificates</b>	SecurityPolicy (SPDM)	object	The revoked SPDM device certificates.

Property Name	Defined In Schema(s)	Type	Description
	SecurityPolicy (TLS > Client), SecurityPolicy (TLS > Server)	object	The revoked TLS server certificates.
<b>RFB</b>	ManagerNetworkProtocol	object	The settings for this manager's Remote Frame Buffer protocol support, which can support VNC.
<b>RITable</b>	FabricAdapter (GenZ)	array	An array of table entry values for the Responder Interface Table.
<b>RKeyDomainCheckingEnabled</b>	Connection (ConnectionKeys > GenZ)	boolean	Indicates whether Region Key domain checking is enabled for this connection.
<b>RKeyReadOnlyKey</b>	Connection (ConnectionKeys > GenZ)	string	The read-only Region Key for this connection.
<b>RKeyReadWriteKey</b>	Connection (ConnectionKeys > GenZ)	string	The read-write Region Key for this connection.
<b>Role</b>	ManagerAccount (Links)	object	The link to the Redfish role that defines the privileges for this account.
	SerialInterface (Modbus)	string (enum)	The role of the serial interface.
<b>RoleId</b>	Role	string	The name of the role.
	ManagerAccount	string	The role for this account.
	HostInterface (CredentialBootstrapping)	string	The role used for the bootstrap account created for this interface.
<b>Roles</b>	OutboundConnection	array	The Redfish roles that contain the privileges of the remote client for the outbound connection.
	Session	array	The Redfish roles that contain the privileges of this session.
	AccountService	object	The collection of Redfish roles.
<b>RotationSpeedRPM</b>	Drive	number ({rev}/min)	The rotation speed of this drive, in revolutions per minute (RPM) units.
<b>RouteDistinguisherAdministratorSubfield</b>	AddressPool (Ethernet > BGPEvpn)	string	The Route Distinguisher (RD) Administrator subfield.
<b>RouteDistinguisherRange</b>	AddressPool (Ethernet > BGPEvpn)	object	The Route Distinguisher (RD) number range for the fabric.

Property Name	Defined In Schema(s)	Type	Description
<b>RouterAdvertisementEnabled</b>	NetworkDeviceFunction (iSCSIBoot)	boolean	An indication of whether IPv6 router advertisement is enabled for the iSCSI boot target.
<b>RouteSet</b>	RouteEntry	object	The link to the collection of route set entries associated with this route.
<b>RouteTargetAdministratorSubfield</b>	AddressPool (Ethernet > BGPEvpn)	string	The Route Target (RT) Administrator Subfield.
<b>RouteTargetRange</b>	AddressPool (Ethernet > BGPEvpn)	object	The Route Target (RT) number range for the fabric.
<b>RoutingScope</b>	EthernetInterface	string (enum)	The routing scope for this interface.
<b>RPUs</b>	ThermalEquipment	object	A link to a collection of reservoir and pumping units (RPUs).
<b>RunningDisparityErrorCount</b>	PortMetrics (SAS)	integer	The number of dwords containing running disparity errors that have been received by the phy outside of phy reset sequences.
<b>RuntimeHeatingTimeSeconds</b>	HeaterMetrics	integer	The total number of seconds the heater was active while the device it heats was powered on.
<b>RXAvgQueueDepthPercent</b>	NetworkDeviceFunctionMetrics	number (%)	The average RX queue depth as the percentage.
<b>RXBBCreditZero</b>	PortMetrics (FibreChannel)	integer	The number of times the receive buffer-to-buffer credit count transitioned to zero.
<b>RXBroadcastFrames</b>	PortMetrics (Networking)	integer	The total number of valid broadcast frames received on a port since reset.
<b>RXBytes</b>	NetworkDeviceFunctionMetrics	integer (bytes)	The total number of bytes received on a network function.
	PortMetrics	integer (bytes)	The total number of bytes received on a port since reset.
	NetworkAdapterMetrics	integer (bytes)	The total number of bytes received since reset.
<b>RXCongestionFPINs</b>	NetworkDeviceFunctionMetrics (FibreChannel)	integer	The total number of Congestion Fabric Performance Impact Notifications (FPINs) received.

Property Name	Defined In Schema(s)	Type	Description
<b>RXDeliveryFPINs</b>	NetworkDeviceFunctionMetrics (FibreChannel)	integer	The total number of Delivery Fabric Performance Impact Notifications (FPINs) received.
<b>RXDiscards</b>	PortMetrics (Networking)	integer	The total number of frames discarded in a port's receive path since reset.
<b>RXErrors</b>	PortMetrics	integer	The total number of received errors on a port since reset.
<b>RXExchanges</b>	NetworkDeviceFunctionMetrics (FibreChannel), PortMetrics (FibreChannel)	integer	The total number of Fibre Channel exchanges received.
<b>RXFalseCarrierErrors</b>	PortMetrics (Networking)	integer	The total number of false carrier errors received from phy on a port since reset.
<b>RXFCSErrors</b>	PortMetrics (Networking)	integer	The total number of frames received with frame check sequence (FCS) errors on a port since reset.
<b>RXFrameAlignmentErrors</b>	PortMetrics (Networking)	integer	The total number of frames received with alignment errors on a port since reset.
<b>RXFrames</b>	NetworkDeviceFunctionMetrics	integer	The total number of frames received on a network function.
	PortMetrics (Networking)	integer	The total number of frames received on a port since reset.
<b>RXInputPowerMilliWatts</b>	PortMetrics (Transceivers > ByLane)	number (milliwatts)	The RX input power value of the transceiver for the lane identified as <code>LaneId</code> .
	PortMetrics (Transceivers)	number (milliwatts)	The RX input power value of the transceiver, aggregated across all lanes of this port.
<b>RXLinkIntegrityFPINs</b>	NetworkDeviceFunctionMetrics (FibreChannel)	integer	The total number of Link Integrity Fabric Performance Impact Notifications (FPINs) received.
<b>RXMulticastFrames</b>	NetworkDeviceFunctionMetrics	integer	The total number of good multicast frames received on a network function since reset.

Property Name	Defined In Schema(s)	Type	Description
	NetworkAdapterMetrics	integer	The total number of good multicast frames received since reset.
	PortMetrics (Networking)	integer	The total number of valid multicast frames received on a port since reset.
<b>RXOversizeFrames</b>	PortMetrics (Networking)	integer	The total number of frames that exceed the maximum frame size.
<b>RXPauseXOFFFrames</b>	PortMetrics (Networking)	integer	The total number of flow control frames from the network to pause transmission.
<b>RXPauseXONFrames</b>	PortMetrics (Networking)	integer	The total number of flow control frames from the network to resume transmission.
<b>RXPeerCongestionFPINs</b>	NetworkDeviceFunctionMetrics (FibreChannel)	integer	The total number of Peer Congestion Fabric Performance Impact Notifications (FPINs) received.
<b>RXPFCFrames</b>	PortMetrics (Networking)	integer	The total number of priority flow control (PFC) frames received on a port since reset.
<b>RXQueuesEmpty</b>	NetworkDeviceFunctionMetrics	boolean	Whether nothing is in a network function's RX queues to DMA.
<b>RXQueuesFull</b>	NetworkDeviceFunctionMetrics	integer	The number of RX queues that are full.
<b>RXSequences</b>	NetworkDeviceFunctionMetrics (FibreChannel), PortMetrics (FibreChannel)	integer	The total number of Fibre Channel sequences received.
<b>RXStompedECRC</b>	PortMetrics (GenZ)	integer	The total number of packets received with a stomped ECRC field.
<b>RXUndersizeFrames</b>	PortMetrics (Networking)	integer	The total number of frames that are smaller than the minimum frame size of 64 bytes.
<b>RXUnicastFrames</b>	NetworkDeviceFunctionMetrics	integer	The total number of good unicast frames received on a network function since reset.
	NetworkAdapterMetrics	integer	The total number of good unicast frames received since reset.

Property Name	Defined In Schema(s)	Type	Description
	PortMetrics (Networking)	integer	The total number of valid unicast frames received on a port since reset.
<b>SanitizationOnReleaseSupport</b>	PCleDevice (CXLDevice > DynamicCapacity)	array	An indication of whether the sanitization on capacity release is configurable for the memory regions in this CXL device.
<b>SanitizationOnReleaseSupported</b>	PCleDevice (CXLDevice > DynamicCapacity > SanitizationOnReleaseSupport)	boolean	An indication of whether the sanitization on capacity release is configurable for this memory region.
<b>SanitizationType</b>	Drive (Actions > SecureErase (Action))	string (enum)	The type of data sanitization to perform.
<b>SanitizeOnRelease</b>	MemoryRegion	boolean	An indication of whether the capacity released from this memory region will be sanitized before it is made available to any host.
	CXLLogicalDevice (Actions > DynamicCapacityRelease (Action))	boolean	Indicates whether the dynamic capacity is sanitized after release.
<b>SAS</b>	PortMetrics	array	The physical (phy) metrics for Serial Attached SCSI (SAS). Each member represents a single phy.
<b>SAVIEEnabled</b>	NetworkDeviceFunction	boolean	Indicates if Source Address Validation Improvement (SAVI) is enabled for this network device function.
<b>ScalarIncrement</b>	AttributeRegistry (RegistryEntries > Attributes)	integer	The amount to increment or decrement an integer attribute each time a user requests a value change. The 0 value indicates a free-form numeric user-input attribute.
<b>ScanMedia (Action)</b>	Memory (Actions)	object	Scans the media of the memory device.
<b>SCEP</b>	CertificateEnrollment	object	SCEP (Simple Certificate Enrollment Protocol) protocol specific configuration for automatic certificate enrollment.
<b>Schedule</b>	MetricReportDefinition	object	The schedule for generating the metric report.

Property Name	Defined In Schema(s)	Type	Description
	Job	object	The schedule settings for this job.
<b>Scheduling</b>	JobService (ServiceCapabilities)	boolean	An indication of whether scheduling of jobs is supported.
<b>Schema</b>	JsonSchemaFile	string	The @odata.type name this schema describes.
<b>Scheme</b>	ComponentIntegrity (Actions > TPMGetSignedMeasurements (Action))	string	The signing scheme to use for the TPM attestation key.
<b>SearchSettings</b>	AccountService (ActiveDirectory > LDAPService), AccountService (LDAP > LDAPService), AccountService (OAuth2 > LDAPService), AccountService (TACACSPplus > LDAPService), ExternalAccountProvider (LDAPService)	object	The required settings to search an external LDAP service.
<b>SecondaryCoolantConnectors</b>	CoolingLoop, CoolingUnit	object	A link to the secondary coolant connectors for this equipment.
<b>SecondaryDNS</b>	NetworkDeviceFunction (iSCSIBoot)	string	The IPv6 or IPv4 address of the secondary DNS server for the iSCSI boot initiator.
<b>SecondaryLUN</b>	NetworkDeviceFunction (iSCSIBoot)	integer	The logical unit number (LUN) for the secondary iSCSI boot target.
<b>SecondarySpeedPercent</b>	Fan	object	The fan speed (percent) of the second rotor in a multi-rotor fan.
<b>SecondaryTargetIPAddress</b>	NetworkDeviceFunction (iSCSIBoot)	string	The IPv4 or IPv6 address for the secondary iSCSI boot target.
<b>SecondaryTargetName</b>	NetworkDeviceFunction (iSCSIBoot)	string	The name of the iSCSI secondary boot target.
<b>SecondaryTargetTCPPort</b>	NetworkDeviceFunction (iSCSIBoot)	integer	The TCP port for the secondary iSCSI boot target.
<b>SecondaryVLANEnable</b>	NetworkDeviceFunction (iSCSIBoot)	boolean	An indication of whether the secondary VLAN is enabled.
<b>SecondaryVLANId</b>	NetworkDeviceFunction (iSCSIBoot)	integer	The 802.1q VLAN ID to use for iSCSI boot from the secondary target.

Property Name	Defined In Schema(s)	Type	Description
<b>SecretKey</b>	AccountService (MultiFactorAuth > GoogleAuthenticator)	string	The secret key to use when communicating with the Google Authenticator server. This property is <code>null</code> in responses.
	AccountService (MultiFactorAuth > MicrosoftAuthenticator)	string	The secret key to use when communicating with the Microsoft Authenticator server. This property is <code>null</code> in responses.
<b>SecretKeySet</b>	AccountService (MultiFactorAuth > GoogleAuthenticator), AccountService (MultiFactorAuth > MicrosoftAuthenticator)	boolean	Indicates if the <code>SecretKey</code> property is set.
	ManagerAccount	boolean	Indicates if the secret key for Time-based One-Time Password (TOTP) multi-factor authentication is set.
<b>SectionType</b>	Event (Events > CPER), LogEntry (CPER)	string	The CPER Section Type.
<b>SecureBoot</b>	ComputerSystem	object	The link to the UEFI Secure Boot associated with this system.
<b>SecureBootCurrentBoot</b>	SecureBoot	string (enum)	The UEFI Secure Boot state during the current boot cycle.
<b>SecureBootDatabases</b>	SecureBoot	object	A link to the collection of UEFI Secure Boot databases.
<b>SecureBootDesiredMode</b>	SecureBoot	string (enum)	The desired UEFI Secure Boot Mode for the next boot.
<b>SecureBootEnable</b>	SecureBoot	boolean	An indication of whether UEFI Secure Boot is enabled.
<b>SecureBootMode</b>	SecureBoot	string (enum)	The current UEFI Secure Boot Mode.
<b>SecureErase (Action)</b>	Drive (Actions)	object	This action securely erases the contents of the drive.
<b>SecureEraseUnit (Action)</b>	Memory (Actions)	object	This contains the action for securely erasing given regions using the NIST SP800-88 Purge: Cryptographic Erase.
<b>SecureHashAllowList</b>	Key (NVMeoF)	array	The secure hash algorithms allowed with the usage of this key.

Property Name	Defined In Schema(s)	Type	Description
	KeyPolicy (NVMeoF)	array	The secure hash algorithms that this key policy allows.
<b>SecureSessionEnabled</b>	SecurityPolicy (SPDM)	boolean	An indication of whether SPDM secure sessions with devices is enabled.
<b>SecurID</b>	AccountService (MultiFactorAuth)	object	The settings related to RSA SecurID multi-factor authentication.
<b>Security</b>	ComputerSystem (Actions > ExportConfiguration (Action)), CoolingUnit (Actions > ExportConfiguration (Action)), PowerDistribution (Actions > ExportConfiguration (Action))	string (enum)	The policy to apply when exporting secure information.
<b>SecurityCapabilities</b>	Memory	object	Security capabilities of the memory device.
<b>SecurityIDOwned</b>	Drive	boolean	Indicates if the TCG-defined security ID (SID) was changed from its default value, flagging the drive as owned.
<b>SecurityKey</b>	Storage (Actions > SetControllerPassword (Action))	string	The security key for the controller. This parameter is not needed if the controller does not have a security key.
<b>SecurityMode</b>	Manager	string (enum)	The security compliance mode that the manager is currently configured to enforce.
	Manager (Actions > UpdateSecurityMode (Action))	string (enum)	The security mode to apply to the manager.
<b>SecurityPolicy</b>	Manager	object	The security policy settings for this manager.
<b>SecurityProtocol</b>	StorageController (Actions > SecurityReceive (Action)), StorageController (Actions > SecuritySend (Action))	integer	The security protocol number.
<b>SecurityProtocolAllowList</b>	KeyPolicy (NVMeoF)	array	The security protocols that this key policy allows.

Property Name	Defined In Schema(s)	Type	Description
<b>SecurityProtocolSpecific</b>	StorageController (Actions > SecurityReceive (Action)), StorageController (Actions > SecuritySend (Action))	integer	The security protocol-specific parameter.
<b>SecurityProtocolType</b>	Key (NVMeoF)	string (enum)	The security protocol that this key uses.
<b>SecurityReceive (Action)</b>	StorageController (Actions)	object	This action transfers security protocol data from the controller. The data transferred from the controller contains the status and data result of one or more <code>SecuritySend</code> action requests that were previously submitted to the controller.
<b>SecuritySend</b>	Drive (NVMe > ConfigurationLockState), Storage (NVMeSubsystemProperties > ConfigurationLockState)	string (enum)	The lock state of the NVMe-defined Security Send command.
<b>SecuritySend (Action)</b>	StorageController (Actions)	object	This action transfers security protocol data to the controller. The data transferred to the controller contains security protocol-specific commands to be performed by the controller.
<b>SecurityState</b>	Memory	string (enum)	The current security state of this memory device.
<b>SecurityStates</b>	Memory (SecurityCapabilities)	array	Security states supported by the memory device.
	Memory	object	The security states of this memory device.
<b>SecurityTransportAllowList</b>	KeyPolicy (NVMeoF)	array	The security transports that this key policy allows.
<b>SecurityVersionNumber</b>	ComponentIntegrity (SPDM > MeasurementSet > Measurements)	string	The security version number the measurement represents.
<b>SegmentNumber</b>	PCleFunction	string	The segment number of this PCIe function.

Property Name	Defined In Schema(s)	Type	Description
<b>SelectedNetworkPort</b>	Manager (Links)	object	The network port currently used by this manager. This allows selection of shared or dedicated ports for managers that support one or the other. For managers that always have their dedicated port enabled, this allows the selection of which shared port to use.
<b>SelectQuery</b>	ServiceRoot (ProtocolFeaturesSupported)	boolean	An indication of whether the service supports the <code>\$select</code> query parameter.
<b>SelfTest (Action)</b>	Battery (Actions)	object	This action performs a self-test of the battery.
<b>SemanticsSupported</b>	CXLLogicalDevice	array	The semantics supported by this CXL logical device.
<b>SendCommunityEnabled</b>	AddressPool (Ethernet > EBGp), AddressPool (Ethernet > MultiProtocolEBGP), AddressPool (Ethernet > MultiProtocolIBGP)	boolean	Indicates whether community attributes are sent.
<b>SendDefaultRouteEnabled</b>	AddressPool (Ethernet > EBGp > BGPRoute), AddressPool (Ethernet > MultiProtocolEBGP > BGPRoute), AddressPool (Ethernet > MultiProtocolIBGP > BGPRoute)	boolean	Send default route status.
<b>SendHeartbeat</b>	EventDestination	boolean	Send a heartbeat event periodically to the destination.
<b>SendTrigger (Action)</b>	AutomationNode (Actions)	object	Sends a trigger to the node.
<b>SensingFrequency</b>	LeakDetector	number	The time interval between readings of the physical leak detector.
	Sensor	number	The time interval between readings of the physical sensor.
<b>SensingInterval</b>	Sensor	string	The time interval between readings of the sensor.
	MetricDefinition	string	The time interval between when a metric is updated.
<b>Sensor</b>	Control	object	The sensor reading associated with this control.

Property Name	Defined In Schema(s)	Type	Description
<b>SensorGroup</b>	Sensor	object	The group of sensors that provide readings for this sensor.
<b>SensorNumber</b>	Power (Voltages)	integer	A numerical identifier to represent the voltage sensor.
	LogEntry	integer	The IPMI-defined sensor number.
	Thermal (Fans)	integer	The numerical identifier for this fan speed sensor.
	Thermal (Temperatures)	integer	The numerical identifier of the temperature sensor.
<b>SensorResetTime</b>	<i>various</i> (Circuit (EnergykWh), Circuit (PolyPhaseEnergykWh > Line1ToLine2) ... )	string	The date and time when the time-based properties were last reset.
<b>Sensors</b>	PowerDistribution	object	A link to the collection of sensors located in the equipment and sub-components.
	Chassis	object	The link to the collection of sensors located in the equipment and sub-components.
<b>SensorType</b>	LogEntry	string (enum)	The sensor type to which the log entry pertains if the entry type is <code>SEL</code> .
<b>SequenceNumber</b>	MemoryExtent, MemoryRegion (MemoryExtents)	integer	The memory extent sequence number.
<b>SerialConsole</b>	Manager	object	The serial console service that this manager provides.
	ComputerSystem	object	The serial console services that this system provides.
<b>SerialInterface</b>	ConnectionMethod (Links)	object	The link to the serial interface for this connection method.
<b>SerialInterfaces</b>	Manager	object	The link to a collection of serial interfaces that this manager uses for serial and console communication.
<b>SerialNumber</b>	Memory	string	The product serial number of this device.

Property Name	Defined In Schema(s)	Type	Description
	LogEntry	string	The serial number associated with the source of this log entry.
	Battery	string	The serial number for this battery.
	Cable	string	The serial number for this cable.
	Drive	string	The serial number for this drive.
	CoolingUnit, PowerDistribution	string	The serial number for this equipment.
	FabricAdapter	string	The serial number for this fabric adapter.
	Fan, Thermal (Fans)	string	The serial number for this fan.
	Filter	string	The serial number for this filter.
	GraphicsController	string	The serial number for this graphics controller.
	Heater	string	The serial number for this heater.
	License	string	The serial number for this license.
	NetworkAdapter	string	The serial number for this network adapter.
	PCleDevice	string	The serial number for this PCIe device.
	Power (PowerSupplies), PowerSupply	string	The serial number for this power supply.
	Pump	string	The serial number for this pump.
	Reservoir	string	The serial number for this reservoir.
	Storage (StorageControllers), StorageController	string	The serial number for this storage controller.
	Switch	string	The serial number for this switch.
	ComputerSystem	string	The serial number for this system.
	Port (SFP)	string	The serial number for this transceiver.
	USBController	string	The serial number for this USB controller.

Property Name	Defined In Schema(s)	Type	Description
	Assembly (Assemblies)	string	The serial number of the assembly.
	Certificate	string	The serial number of the certificate.
	Chassis	string	The serial number of the chassis.
	CoolantConnector	string	The serial number of the component.
	LeakDetector	string	The serial number of the leak detector.
	Manager	string	The serial number of the manager.
	Processor	string	The serial number of the processor.
	Sensor	string	The serial number of the sensor.
	TrustedComponent	string	The serial number of the trusted component.
	MediaController	string	The serial number of this media controller.
<b>Server</b>	SecurityPolicy (TLS)	object	The TLS policy where the manager acts as a TLS server for communication with clients.
<b>ServerAddress</b>	EventService (SMTP)	string	The address of the SMTP server.
<b>ServerEndpoints</b>	Volume (Links)	array	An array of references to the server Endpoints associated with this volume.
<b>ServerId</b>	SerialInterface (Modbus)	integer	The server identifier for this Modbus RTU interface.
	ManagerNetworkProtocol (Modbus)	integer	The server identifier for this Modbus TCP protocol interface.
<b>ServerSentEventUri</b>	EventService	string	The link to a URI for receiving Server-Sent Event representations for the events that this service generates.
<b>ServerURI</b>	CertificateEnrollment	string	The URI of the certificate enrollment server.
	AccountService (MultiFactorAuth > SecurID)	string	The URI of the RSA SecurID server.

Property Name	Defined In Schema(s)	Type	Description
<b>ServiceAddresses</b>	AccountService (ActiveDirectory), AccountService (LDAP), AccountService (OAuth2), AccountService (TACACSplus), ExternalAccountProvider	array	The addresses of the user account providers to which this external account provider links. The format of this field depends on the type of external account provider.
<b>ServiceCapabilities</b>	JobService	object	The supported capabilities of this job service implementation.
<b>ServiceConditions</b>	ServiceRoot	object	The link to the service conditions.
<b>ServicedDate</b>	CoolingLoop (Coolant)	string	The date the coolant was last serviced.
	Battery	string	The date this battery was put into service.
	Filter	string	The date this filter was put into service.
<b>ServiceEnabled</b>	EventService (SMTP)	boolean	An indication if SMTP for event delivery is enabled.
	CertificateService (AutomaticCertificateEnrollment)	boolean	An indication of whether automatic enrollment is enabled.
	AccountService	boolean	An indication of whether the account service is enabled. If <code>true</code> , it is enabled. If <code>false</code> , it is disabled and users cannot be created, deleted, or modified, and new sessions cannot be started. However, established sessions might still continue to run. Any service, such as the session service, that attempts to access the disabled account service fails. However, this does not affect HTTP Basic Authentication connections.
	AggregationService	boolean	An indication of whether the aggregation service is enabled.
	Manager (CommandShell), Manager (GraphicalConsole), Manager (SerialConsole)	boolean	An indication of whether the service is enabled for this manager.

Property Name	Defined In Schema(s)	Type	Description
	ComputerSystem (GraphicalConsole), ComputerSystem (IPMIHostInterface), ComputerSystem (SerialConsole > IPMI), ComputerSystem (SerialConsole > SSH), ComputerSystem (SerialConsole > Telnet), ComputerSystem (SerialConsole > WebSocket), ComputerSystem (VirtualMediaConfig)	boolean	An indication of whether the service is enabled for this system.
	<i>various</i> (AccountService (ActiveDirectory), AccountService (LDAP) ... )	boolean	An indication of whether this service is enabled.
	EventService	boolean	An indication of whether this service is enabled. If <code>false</code> , events are no longer published, new SSE connections cannot be established, and existing SSE connections are terminated.
	SessionService	boolean	An indication of whether this service is enabled. If <code>true</code> , this service is enabled. If <code>false</code> , it is disabled, and new sessions cannot be created, old sessions cannot be deleted, and established sessions can continue operating.
<b>ServiceEntryPointUUID</b>	Manager	string	The UUID of the Redfish service that is hosted by this manager.
<b>ServiceHours</b>	CoolingLoop (Coolant)	number	The hours of service this coolant has provided.
	Filter	number	The hours of service this filter has provided.
	Pump	number	The hours of service this pump has provided.
<b>ServiceIdentification</b>	Manager	string	A product instance identifier displayed in the Redfish service root.
	ServiceRoot	string	The vendor or user-provided product and service identifier.

Property Name	Defined In Schema(s)	Type	Description
<b>ServiceProviderNotified</b>	LogEntry	boolean	Indicates if the log entry has been sent to the service provider.
<b>ServiceRootUptimeSeconds</b>	ManagerDiagnosticData	number	The wall-clock time the service root hosted by this manager has been running in seconds.
<b>ServiceUseNotification</b>	Manager	string	The usage notification message displayed in the Redfish service root.
	ServiceRoot	string	The usage notification message for this service.
<b>Session</b>	OutboundConnection (Links)	object	The link to the session for this outbound connection.
<b>SessionAccountPassword</b>	ManagerAccount (Actions > ChangePassword (Action))	string	The password of the account tied to the current session.
<b>SessionAlgorithm</b>	ComponentIntegrity (SPDM > ComponentCommunication > Sessions), ComponentIntegrity (TPM > ComponentCommunication > Sessions)	string	The algorithm the session is using to secure the communication channel.
<b>SessionId</b>	ComponentIntegrity (SPDM > ComponentCommunication > Sessions), ComponentIntegrity (TPM > ComponentCommunication > Sessions)	integer	The identifier for an active session or communication channel between two components.
<b>Sessions</b>	ComponentIntegrity (SPDM > ComponentCommunication), ComponentIntegrity (TPM > ComponentCommunication)	array	The active sessions or communication channels between two components.
	ServiceRoot (Links), SessionService	object	The link to a collection of sessions.
<b>SessionService</b>	ServiceRoot	object	The link to the sessions service.
<b>SessionTimeout</b>	SessionService	integer (seconds)	The number of seconds of inactivity that a session can have before the session service closes the session due to inactivity.
<b>SessionType</b>	Session	string (enum)	The active session type.

Property Name	Defined In Schema(s)	Type	Description
	ComponentIntegrity (SPDM > ComponentCommunication > Sessions), ComponentIntegrity (TPM > ComponentCommunication > Sessions)	string (enum)	The type of session or communication channel between two components.
<b>Set</b>	Bios (Passwords > Boot), Bios (Passwords > Setup)	boolean	Indicates if this password is set.
<b>SetControllerPassword (Action)</b>	Storage (Actions)	object	This action sets the controller boot password for a host-based storage controller.
<b>SetDefaultBootOrder (Action)</b>	Aggregate (Actions)	object	This action is used to restore the boot order to the default state for the computer systems that are members of this aggregate.
	AggregationService (Actions)	object	This action is used to restore the boot order to the default state for the specified computer systems.
	ComputerSystem (Actions)	object	This action sets the <code>BootOrder</code> property to the default settings.
<b>SetEncryptionKey (Action)</b>	Storage (Actions)	object	This action sets the local encryption key for the storage subsystem.
<b>SetMasterPassphrase (Action)</b>	Memory (Actions)	object	Sets the master passphrase for the given region.
<b>SetMode (Action)</b>	CoolingUnit (Actions)	object	This action sets the operating mode of the cooling unit.
	Pump (Actions)	object	This action sets the operating mode of the pump.
<b>SetPassphrase (Action)</b>	Memory (Actions)	object	Set passphrase for the given regions.
	CXLLogicalDevice (Actions)	object	Sets the passphrase for the CXL logical device.
<b>SetPersonalityKey (Action)</b>	Drive (Actions), Storage (Actions)	object	This action sets the personality key for the NVMe subsystem.
<b>SetPoint</b>	<i>various</i> (AutomationInstrumentation (NodeControl), AutomationInstrumentation (PID) ... )	number	The desired set point of the control.

Property Name	Defined In Schema(s)	Type	Description
<b>SetPointAccuracy</b>	Control	number	Accuracy (+/-) of the set point.
<b>SetPointError</b>	Control	number	The error (difference) from the desired set point of the control.
<b>SetPointType</b>	Control	string (enum)	The set point type used to operate the control.
<b>SetPointUnits</b>	AutomationInstrumentation (NodeControl), Control	string	The units of the set point and related properties in UCUM c/s format.
<b>SetPointUpdateTime</b>	Control	string	The date and time that the set point was changed.
<b>SetPredictedMediaLifeLeftThreshold (Action)</b>	Storage (Actions)	object	This action configures the <code>PredictedMediaLifeLeftThreshold</code> for all drives attached to this storage subsystem.
<b>SettingMax</b>	Control, Memory (OperatingSpeedRangeMHz), Processor (OperatingSpeedRangeMHz)	number	The maximum set point in the allowed range.
<b>SettingMin</b>	Control, Memory (OperatingSpeedRangeMHz), Processor (OperatingSpeedRangeMHz)	number	The minimum set point in the allowed range.
<b>Setup</b>	Bios (Passwords)	object	Information about the password to enter the setup menu.
<b>Severities</b>	EventDestination	array	The list of severities that are sent to this event destination.
	EventService	array	The list of severities that can be specified in the <code>Severities</code> array in a subscription.
<b>Severity</b>	EventService (Actions > SubmitTestEvent (Action))	string	The severity for the event to add.
	Event (Events)	string	The severity of the event.
	Triggers (DiscreteTriggers)	string (enum)	The severity of the event message.
	LogEntry	string (enum)	The severity of the log entry.

Property Name	Defined In Schema(s)	Type	Description
<b>SFP</b>	Port	object	The small form-factor pluggable (SFP) device associated with this port.
<b>SFTP</b>	ManagerNetworkProtocol	object	The settings for this manager's Secure Shell File Transfer Protocol (SFTP) support.
<b>ShareableRegion</b>	MemoryRegion	boolean	An indication of whether this memory region can be shared across multiple hosts.
<b>SharedBytes</b>	ManagerDiagnosticData (MemoryStatistics)	integer (bytes)	The amount of shared memory in bytes.
<b>SharedNamespaceControllerAttachmentSupported</b>	Storage (NVMeSubsystemProperties)	boolean	Indicates whether the subsystem supports shared namespace controller attachment, allowing a shared namespace to be attached concurrently to two or more controllers in an NVMe subsystem.
<b>SharedNetworkPorts</b>	Manager	object	The shared network ports of the manager.
<b>SharedWithManagerCLI</b>	ComputerSystem (SerialConsole > IPMI), ComputerSystem (SerialConsole > SSH), ComputerSystem (SerialConsole > Telnet)	boolean	Indicates whether the serial console service is shared with access to the manager's command-line interface (CLI).
<b>SharingCapable</b>	ResourceBlock (CompositionStatus)	boolean	An indication of whether this resource block can participate in multiple compositions simultaneously.
<b>SharingEnabled</b>	ResourceBlock (CompositionStatus)	boolean	An indication of whether this resource block is allowed to participate in multiple compositions simultaneously.
<b>ShutdownThresholdPercentage</b>	AddressPool (Ethernet > EBGp > BGPNeighbor > MaxPrefix), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor > MaxPrefix), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor > MaxPrefix)	number (%)	Shutdown threshold status.

Property Name	Defined In Schema(s)	Type	Description
<b>SID</b>	Endpoint (ConnectedEntities > GenZ > GCID)	string	The subnet identifier portion of the GCID for the entity.
<b>SignalDetected</b>	Port	boolean	An indication of whether a signal is detected on this interface.
	NetworkPort	boolean	An indication of whether the port has detected enough signal on enough lanes to establish a link.
<b>SignalType</b>	SerialInterface	string (enum)	The type of signal used for the communication connection.
<b>SignatureAlgorithm</b>	Certificate	string	The algorithm used for creating the signature of the certificate.
<b>SignatureAlgorithms</b>	SecurityPolicy (TLS > Client > Allowed > Algorithms), SecurityPolicy (TLS > Client > Denied > Algorithms), SecurityPolicy (TLS > Server > Allowed > Algorithms), SecurityPolicy (TLS > Server > Denied > Algorithms)	array	The TLS signature algorithms.
<b>Signatures</b>	SecureBootDatabase	object	A link to the collection of signatures contained in this UEFI Secure Boot database.
<b>SignatureString</b>	Signature	string	The string for the signature.
<b>SignatureType</b>	Signature	string	The format of the signature.
<b>SignatureTypeRegistry</b>	Signature	string (enum)	The type of the signature.
<b>SimpleStorage</b>	ResourceBlock	array	An array of links to the simple storage available in this resource block.
	ComputerSystem	object	The link to the collection of storage devices associated with this system.
	Storage (Links)	object	The link to the simple storage instance that corresponds to this storage.
<b>SimpleUpdate (Action)</b>	UpdateService (Actions)	object	This action updates software components.
<b>SizeBytes</b>	SoftwareInventory	integer	The size of the software image in bytes.

Property Name	Defined In Schema(s)	Type	Description
	ContainerImage	integer (bytes)	The size of this container image in bytes.
<b>SizeMiB</b>	Memory (Regions)	integer (mebibytes)	Size of this memory region in mebibytes (MiB).
	MemoryChunks (InterleaveSets)	integer (mebibytes)	Size of this memory region measured in mebibytes (MiB).
<b>SKU</b>	FabricAdapter	string	The manufacturer SKU for this fabric adapter.
	NetworkAdapter	string	The manufacturer SKU for this network adapter.
	ComputerSystem	string	The manufacturer SKU for this system.
	Cable	string	The SKU for this cable.
	Drive	string	The SKU for this drive.
	GraphicsController	string	The SKU for this graphics controller.
	License	string	The SKU for this license.
	PCleDevice	string	The SKU for this PCIe device.
	Storage (StorageControllers), StorageController	string	The SKU for this storage controller.
	Switch	string	The SKU for this switch.
	USBController	string	The SKU for this USB controller.
	Assembly (Assemblies)	string	The SKU of the assembly.
	Chassis	string	The SKU of the chassis.
	CoolantConnector	string	The SKU of the component.
	LeakDetector	string	The SKU of the leak detector.
	Sensor	string	The SKU of the sensor.
	TrustedComponent	string	The SKU of the trusted component.
<b>Slot</b>	Memory (MemoryLocation)	integer	The slot number to which the memory device is connected.
	PCleDevice	object	Information about the slot for this PCIe device.

Property Name	Defined In Schema(s)	Type	Description
<b>SlotCapableProtocols</b>	Drive	array	The drive protocols capable in this slot.
<b>SlotFormFactor</b>	Drive	string (enum)	The form factor of the slot.
<b>SlotId</b>	Certificate (SPDM)	integer	Slot identifier of the certificate.
	ComponentIntegrity (Actions > SPDMGetSignedMeasurements (Action))	integer	The slot identifier for the certificate containing the private key to generate the signature over the measurements.
	Processor (FPGA > ReconfigurationSlots)	string	The FPGA reconfiguration slot identifier.
<b>Slots</b>	PCleSlots	array	An array of PCI Slot information.
<b>SlotType</b>	PCleSlots (Slots)	string (enum)	The PCIe slot type for this slot.
	PCleDevice (Slot)	string (enum)	The PCIe slot type.
<b>SMTP</b>	EventService	object	Settings for SMTP event delivery.
<b>SNMP</b>	EventDestination	object	Settings for an SNMP event destination.
	AggregationSource	object	SNMP settings of the aggregation source.
	ManagerNetworkProtocol	object	The settings for this manager's SNMP support.
	ManagerAccount	object	The SNMP settings for this account.
<b>Socket</b>	Memory (MemoryLocation)	integer	The socket number to which the memory device is connected.
	Processor	string	The socket or location of the processor.
<b>SoftwareId</b>	SoftwareInventory	string	The implementation-specific label that identifies this software.
<b>SoftwareImage</b>	Application (Links)	object	The link to the software image for this application.
	ContainerImage (Links)	object	The link to the software image for this container image.

Property Name	Defined In Schema(s)	Type	Description
	OperatingSystem (Links)	object	The link to the software image for this operating system.
<b>SoftwareImages</b>	Bios (Links)	array	The images that are associated with this BIOS.
	NetworkAdapter (Controllers > Links)	array	The images that are associated with this controller.
	Drive (Links)	array	The images that are associated with this drive.
	Manager (Links)	array	The images that are associated with this manager.
	TrustedComponent (Links)	array	The images that are associated with this trusted component.
<b>SoftwareInventory</b>	UpdateService	object	An inventory of software.
<b>Source</b>	Container (MountPoints)	string	The file system path from the hosting system that is provided to this container.
<b>SourceCircuit</b>	Circuit (Links)	object	A link to the circuit that provides power to this circuit.
<b>SourceMetric</b>	MetricDefinition (CalculationParameters)	string	The URI with wildcards and property identifiers of the metric property used as the input into the calculation. If the URI has wildcards, the wildcards are substituted as specified in the <code>wildcards</code> property.
<b>SourcePort</b>	AddressPool (Ethernet > BFDSingleHopOnly)	integer	Bidirectional Forwarding Detection (BFD) source port.
<b>SourcePortLower</b>	AllowDeny	integer	The TCP, UDP, or other source port to which this rule begins application, inclusive.
<b>SourcePortUpper</b>	AllowDeny	integer	The TCP, UDP or other source port to which this rule ends application, inclusive.
<b>SpareBlock</b>	MemoryMetrics (HealthData > AlarmTrips)	boolean	An indication of whether the spare block capacity crossing alarm trip was detected.

Property Name	Defined In Schema(s)	Type	Description
	MemoryMetrics (CXL > AlertCapabilities)	boolean	Indicates whether spare block conditions generate an alert to the CXL Fabric Manager or host.
<b>SpareCapacityUnderThreshold</b>	StorageControllerMetrics (NVMeSMART > EGCriticalWarningSummary)	boolean	An indication of whether the available spare capacity of one or more Endurance Groups is below the threshold.
<b>SpareCapacityWornOut</b>	StorageController (NVMeControllerProperties > NVMeSMARTCriticalWarnings)	boolean	Indicates that the available spare capacity has fallen below the threshold.
<b>SpareDeviceCount</b>	Memory	integer	Number of unused spare devices available in the memory device.
<b>SparePartNumber</b>	Battery	string	The spare part number for this battery.
	FabricAdapter	string	The spare part number for this fabric adapter.
	Fan, Thermal (Fans)	string	The spare part number for this fan.
	Filter	string	The spare part number for this filter.
	Heater	string	The spare part number for this heater.
	Power (PowerSupplies), PowerSupply	string	The spare part number for this power supply.
	Pump	string	The spare part number for this pump.
	Reservoir	string	The spare part number for this reservoir.
	Assembly (Assemblies)	string	The spare part number of the assembly.
	Chassis	string	The spare part number of the chassis.
	CoolantConnector	string	The spare part number of the component.
	Drive	string	The spare part number of the drive.
	GraphicsController	string	The spare part number of the graphics controller.

Property Name	Defined In Schema(s)	Type	Description
	LeakDetector	string	The spare part number of the leak detector.
	Manager	string	The spare part number of the manager.
	Memory	string	The spare part number of the memory.
	PCleDevice	string	The spare part number of the PCIe device.
	Processor	string	The spare part number of the processor.
	Sensor	string	The spare part number of the sensor.
	USBController	string	The spare part number of the USB controller.
<b>SpareResourceSets</b>	Volume (Links)	array	An array of references to SpareResourceSets.
<b>SPDM</b>	ComponentIntegrity	object	Integrity information about the SPDM Responder as reported by an SPDM Requester.
	Certificate	object	SPDM-related information for the certificate.
	SecurityPolicy	object	The SPDM policy.
<b>SPDMGetSignedMeasurements (Action)</b>	ComponentIntegrity (Actions)	object	This action generates an SPDM cryptographic signed statement over the given nonce and measurements of the SPDM Responder.
<b>SpecificEventExistsInGroup</b>	Event (Events)	boolean	Indicates this event is equivalent to a more specific event in this event group.
	LogEntry	boolean	Indicates this log entry is equivalent to a more specific log entry within the same <code>EventGroupId</code> .
<b>SpecificHeatkJoulesPerKgK</b>	CoolingLoop (Coolant)	number (kJ/kg/K)	The specific heat capacity (kJ/(kg*K)) of the coolant.
<b>SpeedControlPercent</b>	Pump	object	The desired pump speed (%).

Property Name	Defined In Schema(s)	Type	Description
<b>SpeedGbps</b>	Storage (StorageControllers), StorageController	number (Gbit/s)	The maximum speed of the storage controller's device interface.
<b>SpeedLimitMHz</b>	Processor	integer (MHz)	The clock limit of the processor in MHz.
<b>SpeedLocked</b>	Processor	boolean	Indicates whether the clock speed of the processor is fixed at the value specified in the <code>SpeedLimitMHz</code> property.
<b>SpeedMbps</b>	EthernetInterface	integer (Mbit/s)	The current speed, in Mbit/s, of this interface.
<b>SpeedMHz</b>	Processor (ProcessorMemory)	integer	The operating speed of the memory in MHz.
<b>SpeedPercent</b>	Fan	object	The fan speed (percent).
<b>SpeedRPM</b>	EnvironmentMetrics (FanSpeedsPercent), Fan (SecondarySpeedPercent), Fan (SpeedPercent), PowerSupplyMetrics (FanSpeedPercent), PowerSupplyMetrics (FanSpeedsPercent), Pump (PumpSpeedPercent), Sensor	number ({rev}/min)	The rotational speed.
<b>SplitReplication (Action)</b>	Volume (Actions)	object	This action is used to split the replication relationship and suspend data synchronization between a source and target volume.
<b>SRIOV</b>	NetworkAdapter (Controllers > ControllerCapabilities > VirtualizationOffload)	object	Single-root input/output virtualization (SR-IOV) capabilities.
<b>SRIOVEnabled</b>	NetworkAdapter (Controllers > ControllerCapabilities > VirtualizationOffload > SRIOV)	boolean	An indication of whether single root input/output virtualization (SR-IOV) is enabled for this controller.
<b>SRIOVVEPACapable</b>	NetworkAdapter (Controllers > ControllerCapabilities > VirtualizationOffload > SRIOV)	boolean	An indication of whether this controller supports single root input/output virtualization (SR-IOV) in Virtual Ethernet Port Aggregator (VEPA) mode.
<b>SSDP</b>	ManagerNetworkProtocol	object	The settings for this manager's SSDP support.

Property Name	Defined In Schema(s)	Type	Description
<b>SSDT</b>	FabricAdapter (GenZ)	object	The Single Subnet Destination Table for the component.
<b>SSEFilterPropertiesSupported</b>	EventService	object	The set of properties that are supported in the <code>\$filter</code> query parameter for the <code>ServerSentEventUri</code> .
<b>SSEIncludeOriginOfConditionSupported</b>	EventService	boolean	An indication of whether the service supports the <code>includeoriginofcondition</code> query parameter for the <code>ServerSentEventUri</code> .
<b>SSH</b>	Key	object	SSH specific properties.
	ComputerSystem (SerialConsole)	object	The connection details for an SSH serial console service.
	ManagerNetworkProtocol	object	The settings for this manager's Secure Shell (SSH) protocol support.
<b>SSHKeyAttribute</b>	AccountService (ActiveDirectory > LDAPService > SearchSettings), AccountService (LDAP > LDAPService > SearchSettings), AccountService (OAuth2 > LDAPService > SearchSettings), AccountService (TACACSplus > LDAPService > SearchSettings), ExternalAccountProvider (LDAPService > SearchSettings)	string	The attribute name that contains the LDAP user's SSH public key entry.
<b>SSHSettings</b>	AggregationSource	object	Settings for an aggregation source using SSH as part of the associated connection method.
<b>Stage</b>	UpdateService (Actions > SimpleUpdate (Action))	boolean	An indication of whether the service stages the image on target devices for a client to activate at a later time.
<b>Staged</b>	SoftwareInventory	boolean	This image is ready to be activated to one or more devices.
<b>StagedNonVolatileSizeMiB</b>	Memory (CXL)	integer (mebibytes)	Total device non-volatile memory capacity in MiB staged for next activation. The value is in multiples of 256 MiB.

Property Name	Defined In Schema(s)	Type	Description
<b>StagedTargets</b>	SoftwareInventory (Links)	array	An array of devices where this software image is staged and ready to be activated.
<b>StagedVersion</b>	PCleDevice	string	The staged firmware version for this PCIe device; this firmware is not yet active.
<b>StagedVolatileSizeMiB</b>	Memory (CXL)	integer (mebibytes)	Total device volatile memory capacity in MiB staged for next activation. This value is in multiples of 256 MiB.
<b>StaleRoutesTimeSeconds</b>	AddressPool (Ethernet > EBGp > GracefulRestart), AddressPool (Ethernet > MultiProtocolEBGP > GracefulRestart), AddressPool (Ethernet > MultiProtocolIBGP > GracefulRestart)	integer	Stale route timer in seconds.
<b>Standard</b>	Port (Ethernet > PoE)	string (enum)	The IEEE 802.3 PoE standard in use by this port.
<b>Start (Action)</b>	AutomationNode (Actions)	object	Starts the node.
<b>StartDateTime</b>	Manager (DaylightSavingTime)	string	The start date and time with UTC offset of daylight saving time.
<b>StartingPhysicalPort</b>	NetworkAdapter (PortSplitting > CurrentConfiguration), NetworkAdapter (PortSplitting > SupportedConfigurations > Subconfigurations)	integer	The first physical port to which this subconfiguration applies.
<b>StartTime</b>	Application	string	The date and time when the application started running.
	Container	string	The date and time when the container started running.
	JobDocument (Actions > SubmitJob (Action))	string	The date and time when the job is scheduled to start.
	Job	string	The date and time when the job was started or is scheduled to start.
	Task	string	The date and time when the task was started.
	Job (Actions > Resubmit (Action))	string	The time to start the job.

Property Name	Defined In Schema(s)	Type	Description
<b>StartUpdate (Action)</b>	UpdateService (Actions)	object	This action starts updating all images that have been previously invoked using an <code>OperationApplyTime</code> value of <code>OnStartUpdateRequest</code> .
<b>State</b>	CertificateEnrollment (CSRParameters), CertificateService (Actions > GenerateCSR (Action))	string	The state, province, or region of the organization making the request.
	Certificate (Issuer), Certificate (Subject)	string	The state, province, or region of the organization of the entity.
<b>StateChangeCount</b>	StorageControllerMetrics	integer	The number of state changes for this storage controller.
	StorageMetrics	number	The number of state changes for this storage subsystem.
<b>StatefulSession</b>	AllowDeny	boolean	Indicates if this is a permission that only applies to stateful connections.
<b>StatelessAddressAutoConfig</b>	EthernetInterface	object	Stateless address autoconfiguration (SLAAC) parameters for this interface.
<b>StateOfHealthPercent</b>	Battery	object	The state of health (percent) of this battery.
<b>StaticNameServers</b>	EthernetInterface	array	The statically-defined set of DNS server IPv4 and IPv6 addresses.
<b>Status</b>	Volume	object	The property contains the status of the Volume.
	AutomationInstrumentation, AutomationNode	object	The status and health of a resource and its children.
	<i>various</i> (AccelerationFunction, AccountService ... )	object	The status and health of the resource and its subordinate or dependent resources.
	License	object	The status of the license.
<b>StatusIndicator</b>	Drive	string (enum)	The state of the status indicator, which communicates status information about this drive.
<b>Step</b>	Processor (ProcessorId)	string	The step value for this processor.

Property Name	Defined In Schema(s)	Type	Description
<b>StepOrder</b>	Job	array	The serialized execution order of the job steps.
<b>Steps</b>	Job	object	The link to a collection of steps for this job.
<b>Stop (Action)</b>	AutomationNode (Actions)	object	Stops the node.
<b>StopBits</b>	SerialInterface	string (enum)	The period of time before the next start bit is transmitted.
<b>StopBootOnFault</b>	ComputerSystem (Boot)	string (enum)	If the boot should stop on a fault.
<b>Storage</b>	ResourceBlock	array	An array of links to the storage available in this resource block.
	Chassis (Links)	array	An array of links to the storage subsystems connected to or inside this chassis.
	Drive (Links)	object	A link to the storage subsystem to which this drive belongs.
	ServiceRoot	object	The link to a collection of storage subsystems.
	ComputerSystem	object	The link to the collection of storage devices associated with this system.
	SimpleStorage (Links)	object	The link to the storage instance that corresponds to this simple storage.
	Volume (AccessCapabilities)	string (enum)	Values of StorageAccessCapability describe abilities to read or write storage.
<b>StorageControllers</b>	Heater (Links)	array	An array of links to the storage controllers heated by this heater.
	PCIeFunction (Links)	array	An array of links to the storage controllers that this PCIe function produces.
	Battery (Links)	array	An array of links to the storage controllers to which this battery provides power during a power-loss event.
	Storage	array	The set of storage controllers that this resource represents.

Property Name	Defined In Schema(s)	Type	Description
<b>StorageGroups</b>	Volume (Links)	array	An array of references to the StorageGroups associated with this volume.
	Storage	object	All of the storage groups, each of which contains a set of volumes and endpoints that are managed as a group for mapping and masking, that belong to this storage subsystem.
	Volume	object	An array of references to Storage Groups that includes this volume.
<b>StoragePools</b>	Drive (Links)	array	An array of links to the storage pools to which this drive belongs.
	Storage	object	The set of all storage pools that are allocated by this storage subsystem. A storage pool is the set of storage capacity that can be used to produce volumes or other storage pools.
<b>StorageServices</b>	Storage (StorageControllers > Links)	array	An array of links to the storage services that connect to this controller.
	Storage (Links)	array	An array of links to the storage services that connect to this storage subsystem.
	ComputerSystem (HostedServices)	object	The link to a collection of storage services that this computer system supports.
	ServiceRoot	object	The link to a collection of storage services.
<b>StorageSystems</b>	ServiceRoot	object	The link to a collection of storage systems.
<b>StoredChargeAmpHours</b>	BatteryMetrics	object	The charge (Ah) stored in this battery.
<b>StoredEnergyWattHours</b>	BatteryMetrics	object	The energy (Wh) stored in this battery.

Property Name	Defined In Schema(s)	Type	Description
<b>StrictAccountTypes</b>	ManagerAccount	boolean	Indicates if the service needs to use the account types exactly as specified when the account is created or updated.
<b>StripSizeBytes</b>	Volume (Actions > ChangeRAIDLAYOUT (Action))	integer	The number of blocks (bytes) requested for new strip size.
	Volume	integer (bytes)	The number of blocks (bytes) in a strip in a disk array that uses striped data mapping.
<b>Subconfigurations</b>	NetworkAdapter (PortSplitting > SupportedConfigurations)	array	The set of subconfigurations that collectively define a port splitting configuration for this controller.
<b>SubContext</b>	RegisteredClient	string	Additional client-supplied data for providing contextual information for its own use.
<b>Subexpressions</b>	AttributeRegistry (RegistryEntries > Dependencies > Dependency > MapFrom)	array	The subexpressions to use to evaluate this dependency expression.
<b>Subfeeds</b>	PowerDistribution	object	A link to the subfeed circuits for this equipment.
<b>Subject</b>	Certificate	object	The subject of the certificate.
<b>Subjects</b>	Certificate (Links)	array	An array of links to certificates that were issued by the CA that is represented by this certificate.
<b>SubmitJob (Action)</b>	JobDocument (Actions)	object	Creates a new job based on the contents of this job document and additional parameters.
<b>SubmitTestEvent (Action)</b>	EventService (Actions)	object	This action generates a test event.
<b>SubmitTestMetricReport (Action)</b>	TelemetryService (Actions)	object	This action generates a metric report.
<b>SubModel</b>	ComputerSystem	string	The sub-model for this system.
<b>SubordinateOverrides</b>	PrivilegeRegistry (Mappings)	array	The privilege overrides of the subordinate resource.
<b>SubordinateResources</b>	EventService (SSEFilterPropertiesSupported)	boolean	An indication of whether the service supports filtering by the <code>SubordinateResources</code> property.

Property Name	Defined In Schema(s)	Type	Description
	EventDestination	boolean	An indication of whether the subscription is for events in the <code>OriginResources</code> array and its subordinate resources. If <code>true</code> and the <code>OriginResources</code> array is specified, the subscription is for events in the <code>OriginResources</code> array and its subordinate resources. Note that resources associated through the Links section are not considered subordinate. If <code>false</code> and the <code>OriginResources</code> array is specified, the subscription is for events in the <code>OriginResources</code> array only. If the <code>OriginResources</code> array is not present, this property has no relevance.
<b>SubordinateResourcesSupported</b>	EventService	boolean	An indication of whether the service supports the <code>SubordinateResources</code> property on both event subscriptions and generated events.
<b>SupportsPerPort</b>	NetworkAdapter (PortSplitting > CurrentConfiguration), NetworkAdapter (PortSplitting > SupportedConfigurations > Subconfigurations)	integer	The number of subports created from each port in this subconfiguration.
<b>SubProcessors</b>	Processor	object	The link to the collection of sub-processors associated with this processor, such as cores or threads, that are part of a processor.
<b>Subscriptions</b>	EventService	object	The link to a collection of event destinations.
<b>SubscriptionType</b>	EventDestination	string (enum)	The subscription type for events.
<b>SubsidiaryJobs</b>	Job (Links)	array	An array of links to the jobs created by this job.
<b>SubsystemDeviceID</b>	Memory	string	Subsystem device ID.
<b>SubsystemId</b>	Endpoint (ConnectedEntities > EntityPcild), Endpoint (Pcild), PCleFunction	string	The Subsystem ID of this PCIe function.

Property Name	Defined In Schema(s)	Type	Description
<b>SubsystemVendorId</b>	Endpoint (ConnectedEntities > EntityPcId), Endpoint (PcId), PCIeFunction	string	The Subsystem Vendor ID of this PCIe function.
<b>SubsystemVendorID</b>	Memory	string	SubSystem vendor ID.
<b>SubTasks</b>	Task	object	The link to a collection of sub-tasks for this task.
<b>SupplyEquipmentNames</b>	CoolingLoop	array	An array of names of upstream devices that supply coolant to this cooling loop.
<b>SupplyingComputerSystems</b>	ComputerSystem (Links)	array	An array of links to computer systems that contribute, in whole or in part, to the implementation of this computer system.
<b>SupplyingResourceBlocks</b>	ResourceBlock (Links)	array	An array of links to resource blocks that this resource block depends on.
<b>SupplyPressurePa</b>	CoolantConnector	object	The supply pressure (kPa).
<b>SupplyTemperatureCelsius</b>	CoolantConnector	object	The supply temperature (C).
<b>SupplyTemperatureControlCelsius</b>	CoolantConnector	object	The desired supply temperature (C).
<b>SupplyVoltage</b>	PortMetrics (Transceivers)	number (volts)	The supply voltage for the transceiver.
<b>SupportedAccountTypes</b>	AccountService	array	The account types supported by the service.
<b>SupportedCollectionFunctions</b>	TelemetryService	array	The functions that can be performed over each metric.
<b>SupportedConfigurations</b>	NetworkAdapter (PortSplitting)	array	The port splitting configurations this controller supports.
<b>SupportedControllerProtocols</b>	Storage (StorageControllers), StorageController	array	The supported set of protocols for communicating with this storage controller.
<b>SupportedCXLModes</b>	Port (CXL)	array	The supported device modes.
<b>SupportedDeviceProtocols</b>	Storage (StorageControllers), StorageController	array	The protocols that the storage controller can use to communicate with attached devices.
<b>SupportedEthernetCapabilities</b>	NetworkPort, Port (Ethernet)	array	The set of Ethernet capabilities that this port supports.

Property Name	Defined In Schema(s)	Type	Description
<b>SupportedExecutors</b>	JobDocument (Links)	array	An array of links to the executors that are capable of running jobs instantiated from this job document.
<b>SupportedImageTypes</b>	OperatingSystem (ContainerEngines), OperatingSystem (VirtualMachineEngines)	array	The supported image types for this container engine.
<b>SupportedLinkCapabilities</b>	NetworkPort	array	The link capabilities of this port.
<b>SupportedMTUSizes</b>	NetworkDeviceFunction (InfiniBand)	array	The maximum transmission unit (MTU) sizes supported for this network device function.
<b>SupportedOEMAccountTypes</b>	AccountService	array	The OEM account types supported by the service.
<b>SupportedOEMTelemetryDataTypes</b>	TelemetryService	array	A list of supported OEM-defined telemetry data types.
<b>SupportedProtocols</b>	Switch	array	The protocols this switch supports.
<b>SupportedRAIDTypes</b>	Storage (StorageControllers), StorageController	array	The set of RAID types supported by the storage controller.
<b>SupportedSFPTypes</b>	Port (SFP)	array	The types of transceivers that can be attached to this port.
<b>SupportedSystems</b>	AttributeRegistry	array	An array of systems that this attribute registry supports.
<b>SupportedTelemetryDataTypes</b>	TelemetryService	array	A list of supported telemetry data types.
<b>SupportedUpdateImageFormats</b>	UpdateService	array	The image format types supported by the service.
<b>Supports128BitHostId</b>	StorageController (NVMeControllerProperties > NVMeControllerAttributes)	boolean	Indicates whether or not the controller supports a 128-bit Host Identifier.
<b>SupportsAtomicTransactionSize</b>	Volume (NVMeNamespaceProperties > NamespaceFeatures)	boolean	Indicates that the NVM fields for Namespace preferred write granularity (NPWG), write alignment (NPWA), deallocate granularity (NPDG), deallocate alignment (NPDA) and optimal write size (NOWS) are defined for this namespace and should be used by the host for I/O optimization.

Property Name	Defined In Schema(s)	Type	Description
<b>SupportsDeallocatedOrUnwrittenLBEError</b>	Volume (NVMeNamespaceProperties > NamespaceFeatures)	boolean	This property indicates that the controller supports deallocated or unwritten logical block error for this namespace.
<b>SupportsEnduranceGroups</b>	StorageController (NVMeControllerProperties > NVMeControllerAttributes)	boolean	Indicates whether or not the controller supports Endurance Groups.
<b>SupportsExceedingPowerOfNonOperationalState</b>	StorageController (NVMeControllerProperties > NVMeControllerAttributes)	boolean	Indicates whether or not the controller supports exceeding Power of Non-Operational State in order to execute controller-initiated background operations in a non-operational power state.
<b>SupportsIOPerformanceHints</b>	Volume (NVMeNamespaceProperties > NamespaceFeatures)	boolean	Indicates that the Namespace Atomic Write Unit Normal (NAWUN), Namespace Atomic Write Unit Power Fail (NAWUPF), and Namespace Atomic Compare and Write Unit (NACWU) fields are defined for this namespace and should be used by the host for this namespace instead of the controller-level properties AWUN, AWUPF, and ACWU.
	Volume (NVMeNamespaceProperties)	boolean	Indicates whether the namespace supports IO performance hints.
<b>SupportsMultipleNamespaceAttachments</b>	Volume (NVMeNamespaceProperties)	boolean	Indicates whether the namespace may be attached to two or more controllers.
<b>SupportsNGUIDReuse</b>	Volume (NVMeNamespaceProperties > NamespaceFeatures)	boolean	This property indicates that the namespace supports the use of an NGUID (namespace globally unique identifier) value.
<b>SupportsNVMSets</b>	StorageController (NVMeControllerProperties > NVMeControllerAttributes)	boolean	Indicates whether or not the controller supports NVM Sets.
<b>SupportsPredictableLatencyMode</b>	StorageController (NVMeControllerProperties > NVMeControllerAttributes)	boolean	Indicates whether or not the controller supports Predictable Latency Mode.

Property Name	Defined In Schema(s)	Type	Description
<b>SupportsReadRecoveryLevels</b>	StorageController (NVMeControllerProperties > NVMeControllerAttributes)	boolean	Indicates whether or not the controller supports Read Recovery Levels.
<b>SupportsReservations</b>	StorageController (NVMeControllerProperties > NVMeControllerAttributes)	boolean	Indicates if the controller supports reservations.
<b>SupportsSQAssociations</b>	StorageController (NVMeControllerProperties > NVMeControllerAttributes)	boolean	Indicates whether or not the controller supports SQ Associations.
<b>SupportsThinProvisioning</b>	Volume (NVMeNamespaceProperties > NamespaceFeatures)	boolean	This property indicates whether or not the NVMe Namespace supports thin provisioning.
<b>SupportsTrafficBasedKeepAlive</b>	StorageController (NVMeControllerProperties > NVMeControllerAttributes)	boolean	Indicates whether or not the controller supports restarting the Keep Alive Timer if traffic is processed from an admin command or I/O during a Keep Alive Timeout interval.
<b>SuppressRepeatedMetricValue</b>	MetricReportDefinition	boolean	An indication of whether any metrics are suppressed from the generated metric report. If <code>true</code> , any metric that equals the same value in the previously generated metric report is suppressed from the current report. Also, duplicate metrics are suppressed. If <code>false</code> , no metrics are suppressed from the current report. The current report might contain no metrics if all metrics equal the values in the previously generated metric report.
<b>Surname</b>	CertificateEnrollment (CSRParameters), CertificateService (Actions > GenerateCSR (Action))	string	The surname of the user making the request.
<b>Suspend (Action)</b>	Job (Actions)	object	Suspends the job.
<b>SuspendReplication (Action)</b>	Volume (Actions)	object	This action is used to suspend active data synchronization between a source and target volume, without otherwise altering the replication relationship.

Property Name	Defined In Schema(s)	Type	Description
<b>SuspendSubscription (Action)</b>	EventDestination (Actions)	object	This action suspends an event subscription.
<b>SustainedBytesPerSecond</b>	NetworkDeviceFunction (Limits)	integer	The maximum number of sustained bytes per second for this network device function.
<b>SustainedPacketsPerSecond</b>	NetworkDeviceFunction (Limits)	integer	The maximum number of sustained packets per second for this network device function.
<b>Switch</b>	PCleDevice (Links)	object	The link to a switch that is associated with this PCIe device.
<b>Switches</b>	Chassis (Links)	array	An array of links to the switches located in this chassis.
	Fabric	object	The collection of links to the switches that this fabric contains.
<b>Switchgear</b>	Facility (Links)	array	An array of links to the switchgear in this facility.
	PowerDomain (Links)	array	An array of links to the switchgear in this power domain.
	PowerEquipment	object	A link to a collection of switchgear.
<b>SwitchType</b>	Switch	string (enum)	The protocol being sent over this switch.
<b>SyslogFacility</b>	EventDestination (SyslogFilters > LogFacilities), LogService (SyslogFilters > LogFacilities)	string (enum)	The syslog facility code is an enumeration of program types.
<b>SyslogFilters</b>	EventDestination	array	A list of filters applied to syslog messages before sending to a remote syslog server. An empty list indicates all syslog messages are sent.
	LogService	array	A list of syslog message filters to be logged locally.
<b>SystemCapabilities</b>	Port (Ethernet > LLDPReceive)	array	The system capabilities received from the remote partner across this link.
	Port (Ethernet > LLDPTransmit)	array	The system capabilities to be transmitted from this endpoint.

Property Name	Defined In Schema(s)	Type	Description
<b>SystemDescription</b>	Port (Ethernet > LLDPReceive)	string	The system description received from the remote partner across this link.
	Port (Ethernet > LLDPTransmit)	string	The system description to be transmitted from this endpoint.
<b>SystemGUID</b>	NetworkDeviceFunction (InfiniBand)	string	This is the currently configured system GUID of the network device function.
<b>SystemId</b>	AttributeRegistry (SupportedSystems)	string	The ID of the systems to which this attribute registry applies.
<b>SystemInterface</b>	Processor	object	The interface between the system and the processor.
<b>SystemMACRange</b>	AddressPool (Ethernet > IPv4)	object	The MAC address range for systems in this subnet.
<b>SystemName</b>	Port (Ethernet > LLDPReceive)	string	The system name received from the remote partner across this link.
	Port (Ethernet > LLDPTransmit)	string	The system name to be transmitted from this endpoint.
<b>Systems</b>	AggregationService (Actions > SetDefaultBootOrder (Action))	array	The computer systems to restore.
	ServiceRoot	object	The link to a collection of systems.
<b>SystemType</b>	ComputerSystem	string (enum)	The type of computer system that this resource represents.
<b>TACACSplus</b>	AccountService	object	The first TACACS+ external account provider that this account service supports.
<b>TACACSplusService</b>	AccountService (ActiveDirectory), AccountService (LDAP), AccountService (OAuth2), AccountService (TACACSplus), ExternalAccountProvider	object	The additional information needed to parse a TACACS+ services.
<b>Tag</b>	CXLLogicalDevice (Actions > DynamicCapacityAdd (Action))	string	The tag assigned to the dynamic capacity to add.
	CXLLogicalDevice (Actions > DynamicCapacityRelease (Action))	string	The tag assigned to the dynamic capacity to release.

Property Name	Defined In Schema(s)	Type	Description
	PCleDevice (Actions > CXLReferenceDCMemory (Action))	string	The tag of the memory extents to reference.
	MemoryExtent, MemoryRegion (MemoryExtents)	string	The tag of this memory extent.
<b>TargetCHAPPassword</b>	Connection (ConnectionKeys > CHAP)	string	The target shared secret for mutual (2-way) CHAP authentication. The value is <code>null</code> in responses.
<b>TargetComponentURI</b>	ComponentIntegrity	string	The link to the component whose integrity that this resource reports.
<b>TargetConfigurationLockLevel</b>	Drive, Storage	string (enum)	Indicates the target configuration lock level for the drive based upon the state of the <code>ConfigurationLock</code> property. Other properties, such as <code>ConfigurationLockState</code> , contain additional information regarding the status of the configuration lock.
<b>TargetDevice</b>	LogService (Actions > CollectDiagnosticData (Action))	object	The link to the device to collect diagnostic data.
<b>TargetDevices</b>	TelemetryService (Actions > CollectTelemetryData (Action))	array	An array of devices from which to collect telemetry data.
<b>TargetEndpointGroupIdentifier</b>	EndpointGroup	integer	The SCSI-defined identifier for this group.
<b>TargetEndpointGroups</b>	Connection (Links)	array	An array of links to the target endpoint groups that are associated with this connection.
<b>TargetEndpoints</b>	Connection (Links)	array	An array of links to the target endpoints that are associated with this connection.
<b>TargetID</b>	Switch (CXL > PIDTargetList)	integer	The identifier of the PID target for use in CXL 'Configure PID Assignment'.
<b>TargetInfoViaDHCP</b>	NetworkDeviceFunction (iSCSIBoot)	boolean	An indication of whether the iSCSI boot target name, LUN, IP address, and netmask should be obtained from DHCP.
<b>Targets</b>	UpdateService (Actions > SimpleUpdate (Action))	array	An array of URIs that indicate where to apply the update image.

Property Name	Defined In Schema(s)	Type	Description
	PrivilegeRegistry (Mappings > PropertyOverrides), PrivilegeRegistry (Mappings > ResourceURIOverrides), PrivilegeRegistry (Mappings > SubordinateOverrides)	array	The set of URIs, resource types, or properties.
	SoftwareInventory (Actions > Cancel (Action))	array	The target devices for which to cancel the pending activation. If not specified, the service cancels the pending activation for all applicable devices.
	SoftwareInventory (Actions > Activate (Action))	array	The target devices to activate this software image. If not specified, the service activates this software image on all applicable devices.
	UpdateService (Actions > Activate (Action))	array	The target software inventory instances to activate on staged devices.
<b>TargetServices</b>	License (Links)	array	An array of links to the managers where the license is installed.
	LicenseService (Actions > Install (Action))	array	An array of links to the managers where the license will be installed.
<b>TargetStoragePool</b>	Volume (Actions > CreateReplicaTarget (Action))	string	The Uri to the existing target Storage Pool.
<b>TargetType</b>	Switch (CXL > PIDTargetList)	string (enum)	The port type for the assigned PID.
<b>TargetUri</b>	Job (Payload)	string	The link to the target for this job.
	Task (Payload)	string	The URI of the target for this task.
<b>TargetURI</b>	LogService (Actions > CollectDiagnosticData (Action)), LogService (Actions > PushDiagnosticData (Action))	string	The URI to access when sending the diagnostic data.
<b>TargetURIs</b>	AggregationService (Actions > Reset (Action))	array	An array of links to the resources being reset.

Property Name	Defined In Schema(s)	Type	Description
<b>TargetVolume</b>	Volume (Actions > AssignReplicaTarget (Action)), Volume (Actions > RemoveReplicaRelationship (Action)), Volume (Actions > ResumeReplication (Action)), Volume (Actions > ReverseReplicationRelationship (Action)), Volume (Actions > SplitReplication (Action)), Volume (Actions > SuspendReplication (Action))	string	The Uri to the existing target volume.
<b>TaskAutoDeleteTimeoutMinutes</b>	TaskService	integer	The number of minutes after which a completed task is deleted by the service.
<b>TaskMonitor</b>	Task	string	The URI of the task monitor for this task.
<b>TaskMonitorAutoExpirySeconds</b>	TaskService	integer (seconds)	The number of seconds after reading a task monitor for a completed task until the service deletes the task monitor.
<b>Tasks</b>	ServiceRoot	object	The link to the task service.
	TaskService	object	The links to the collection of tasks.
<b>TaskState</b>	Task	string (enum)	The state of the task.
<b>TaskStatus</b>	Task	string (enum)	The completion status of the task.
<b>TCPMaxSegmentSizeBytes</b>	AddressPool (Ethernet > EBGp > BGPNeighbor), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor)	integer	TCP max segment size in bytes.
<b>TDPWatts</b>	Processor	integer (watts)	The nominal Thermal Design Power (TDP) in watt units.
	OperatingConfig	integer (watts)	The thermal design point of the processor in watt units.
<b>TeamMode</b>	EthernetInterface	string (enum)	The team mode for this interface.

Property Name	Defined In Schema(s)	Type	Description
<b>TelemetryData</b>	TelemetryService	object	The link to the collection of data telemetry.
<b>TelemetryDataType</b>	TelemetryData	string (enum)	The type of telemetry data available in the <code>AdditionalData</code> property or retrieved from the URI specified by the <code>AdditionalDataURI</code> property.
	TelemetryService (Actions > CollectTelemetryData (Action))	string (enum)	The type of telemetry data to collect.
<b>TelemetryService</b>	ServiceRoot	object	The link to the telemetry service.
<b>Telnet</b>	ComputerSystem (SerialConsole)	object	The connection details for a Telnet serial console service.
	ManagerNetworkProtocol	object	The settings for this manager's Telnet protocol support.
<b>Temperature</b>	MemoryMetrics (HealthData > AlarmTrips)	boolean	An indication of whether a temperature threshold alarm trip was detected.
	MemoryMetrics (CXL > AlertCapabilities)	boolean	Indicates whether temperature conditions generate an alert to the CXL Fabric Manager or host.
<b>TemperatureCelsius</b>	ProcessorMetrics	number (Celsius)	The temperature of the processor.
	AutomationInstrumentation, EnvironmentMetrics, PowerDistributionMetrics	object	Temperature (Celsius).
	BatteryMetrics	object	The temperature (C) for this battery.
	PowerSupplyMetrics	object	The temperature (C) for this power supply.
<b>TemperatureReadingsCelsius</b>	HeaterMetrics, ThermalMetrics	array	The temperatures (in degree Celsius units) from all related sensors for this device.
<b>Temperatures</b>	Thermal	array	The set of temperature sensors for this chassis.
<b>TemperatureSensorsCelsius</b>	StorageControllerMetrics (NVMeSMART)	array (Celsius)	The temperature sensor readings in degree Celsius units for this storage controller.

Property Name	Defined In Schema(s)	Type	Description
<b>TemperatureSummaryCelsius</b>	ThermalMetrics	object	The summary temperature readings for this chassis.
<b>TemperatureThresholdCondition</b>	StorageController (NVMeControllerProperties > NVMeSMARTCriticalWarnings)	boolean	A temperature in the NVM subsystem is either above a upper temperature limit or below a lower temperature limit.
<b>TemporaryThroughputReductionEnabled</b>	PCIeDevice (CXLDevice), Port (CXL)	boolean	Indicates whether temporary throughput reduction is enabled.
<b>TemporaryThroughputReductionSupported</b>	PCIeDevice (CXLDevice)	boolean	Indicates whether temporary throughput reduction is supported.
	CXLLogicalDevice (QoSTelemetryCapabilities)	boolean	Indicates whether the device supports the CXL Specification-defined 'Temporary Throughput Reduction' mechanism.
	Port (CXL > QoSTelemetryCapabilities)	boolean	Indicates whether the port supports the CXL Specification-defined 'Temporary Throughput Reduction' mechanism.
<b>TestEventSubscription (Action)</b>	EventService (Actions)	object	This action generates a test event using the pre-defined test message.
<b>THDPercent</b>	<i>various</i> (AutomationInstrumentation (CurrentAmps), AutomationInstrumentation (Voltage) ... )	number (%)	The total harmonic distortion percent (% THD).
<b>Thermal</b>	Chassis	object	The link to the thermal properties, such as fans, cooling, and sensors, for this chassis.
<b>ThermalDirection</b>	Chassis	string (enum)	Indicates the thermal management path through the chassis.
<b>ThermalEquipment</b>	ServiceRoot	object	The link to a set of cooling equipment.
<b>ThermalLimitThrottleDuration</b>	ProcessorMetrics	string	The total duration of throttling caused by a thermal limit of the processor since reset.
<b>ThermalManagedByParent</b>	Chassis	boolean	Indicates that the chassis is thermally managed by the parent chassis.

Property Name	Defined In Schema(s)	Type	Description
<b>ThermalMetrics</b>	ThermalSubsystem	object	The link to the summary of thermal metrics for this subsystem.
<b>ThermalMgmtTemp1TotalTimeSeconds</b>	StorageControllerMetrics (NVMeSMART)	integer	The number of seconds the controller transitioned to lower power states or performed vendor-specific thermal-management actions while minimizing the impact on performance in order to attempt to reduce the composite temperature.
<b>ThermalMgmtTemp1TransitionCount</b>	StorageControllerMetrics (NVMeSMART)	integer	The number of times the controller transitioned to lower power states or performed vendor-specific thermal-management actions while minimizing the impact on performance in order to attempt to reduce the composite temperature.
<b>ThermalMgmtTemp2TotalTimeSeconds</b>	StorageControllerMetrics (NVMeSMART)	integer	The number of seconds the controller transitioned to lower power states or performed vendor-specific thermal-management actions regardless of the impact on performance in order to attempt to reduce the composite temperature.
<b>ThermalMgmtTemp2TransitionCount</b>	StorageControllerMetrics (NVMeSMART)	integer	The number of times the controller transitioned to lower power states or performed vendor-specific thermal-management actions regardless of the impact on performance in order to attempt to reduce the composite temperature.
<b>ThermalSubsystem</b>	Chassis	object	The link to the thermal subsystem properties for this chassis.
<b>ThinProvisioningSavingsBytes</b>	StorageMetrics	integer (bytes)	Current thin provisioning savings on the storage system in bytes.
<b>ThreadingEnabled</b>	ComputerSystem (ProcessorSummary)	boolean	An indication of whether threading is enabled on all processors in this system.
<b>Threshold</b>	VCATEntry (VCEnties)	string	The configured threshold.

Property Name	Defined In Schema(s)	Type	Description
<b>Thresholds</b>	DriveMetrics (PredictedMediaLifeLeftPercent), Sensor	object	The set of thresholds defined for this sensor.
<b>ThresholdWarningOnlyEnabled</b>	AddressPool (Ethernet > EBGp > BGPNeighbor > MaxPrefix), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor > MaxPrefix), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor > MaxPrefix)	boolean	Threshold warning only status.
<b>ThrottleCauses</b>	Processor	array	The causes of the processor being throttled.
<b>Throttled</b>	Processor	boolean	An indication of whether the processor is throttled.
<b>ThrottlingCelsius</b>	ProcessorMetrics	number (Celsius)	The CPU margin to throttle (temperature offset in degree Celsius units).
<b>ThroughputReductionSupport</b>	PCleDevice (CXLDevice)	boolean	Indicates whether the CXL device supports throughput reduction.
<b>TimeBasedOneTimePassword</b>	AccountService (MultiFactorAuth)	object	The settings related to Time-based One-Time Password (TOTP) multi-factor authentication.
	ManagerAccount (Actions > VerifyTimeBasedOneTimePassword (Action))	string	The Time-based One-Time Password (TOTP) to verify.
<b>TimeoutAction</b>	ComputerSystem (HostWatchdogTimer)	string (enum)	The action to perform when the watchdog timer reaches its timeout value.
<b>TimeoutSeconds</b>	AccountService (ActiveDirectory), AccountService (LDAP), AccountService (OAuth2), AccountService (TACACSplus), ExternalAccountProvider	integer	The period of time, in seconds, this account service will wait for a response from an address of a user account provider before timing out.
<b>TimeSeconds</b>	AddressPool (Ethernet > EBGp > GracefulRestart), AddressPool (Ethernet > MultiProtocolEBGP > GracefulRestart), AddressPool (Ethernet > MultiProtocolIBGP > GracefulRestart)	integer	Graceful restart timer in seconds.

Property Name	Defined In Schema(s)	Type	Description
<b>Timestamp</b>	MetricReport (MetricValues), TelemetryService (Actions > SubmitTestMetricReport (Action) > GeneratedMetricReportValues)	string	The date and time when the metric is obtained. A management application can establish a time series of metric data by retrieving the instances of metric value and sorting them according to their timestamp.
	TelemetryData	string	The date and time when the telemetry data was generated.
	MetricReport	string	The time associated with the metric report in its entirety. The time of the metric report can be relevant when the time of individual metrics are minimally different.
	PCleDevice (CXLDevice)	string	The timestamp set on the CXL device.
<b>TimestampAccuracy</b>	MetricDefinition	string	The accuracy of the timestamp.
<b>TimeStepSeconds</b>	AccountService (MultiFactorAuth > TimeBasedOneTimePassword)	integer	The time step, in seconds, for calculating the one-time password.
<b>TimeZoneName</b>	Manager (DaylightSavingTime)	string	The time zone of the manager when daylight saving time is in effect.
	Manager	string	The time zone of the manager.
<b>TLS</b>	SecurityPolicy	object	The TLS policy.
<b>Token</b>	Session	string	The multi-factor authentication token for this session. The value is <code>null</code> in responses.
	AccountService (ActiveDirectory > Authentication), AccountService (LDAP > Authentication), AccountService (OAuth2 > Authentication), AccountService (TACACSplus > Authentication), ExternalAccountProvider (Authentication)	string	The token for this service. A <code>PATCH</code> or <code>PUT</code> operation writes the token. This property is <code>null</code> in responses.
<b>TopProcesses</b>	ManagerDiagnosticData	array	The statistics of the top processes of this manager.

Property Name	Defined In Schema(s)	Type	Description
<b>TopSkipQuery</b>	ServiceRoot (ProtocolFeaturesSupported)	boolean	An indication of whether the service supports both the <code>\$top</code> and <code>\$skip</code> query parameters.
<b>TotalAvailableCoreCount</b>	OperatingConfig	integer	The number of cores in the processor that can be configured.
<b>TotalBytes</b>	ManagerDiagnosticData (MemoryStatistics)	integer (bytes)	The total amount of memory in bytes.
<b>TotalCacheSizeMiB</b>	Storage (StorageControllers > CacheSummary), StorageController (CacheSummary)	integer (mebibytes)	The total configured cache memory, measured in MiB.
	Processor (MemorySummary)	integer (mebibytes)	Total size of cache memory of this processor.
<b>TotalCores</b>	Processor	integer	The total number of cores that this processor contains.
<b>TotalDynamicCapacityMiB</b>	PCleDevice (CXLDevice > DynamicCapacity)	integer (mebibytes)	The total memory media capacity of the CXL device available for dynamic assignment in mebibytes (MiB).
<b>TotalEnabledCores</b>	Processor	integer	The total number of enabled cores that this processor contains.
<b>TotalEnabledThreads</b>	Processor	integer	The total number of enabled execution threads contained in this processor.
<b>TotalHDMDecoders</b>	Switch (CXL)	integer	The total number of HDM (Host Device Memory) decoders available per upstream port.
<b>TotalMemorySizeMiB</b>	Processor (MemorySummary)	integer (mebibytes)	Total size of non-cache volatile or non-volatile memory attached to this processor. Examples include DRAMs and NV-DIMMs that are not configured as block storage.
<b>TotalNumbervPPBs</b>	Switch (CXL)	integer	The total number of virtual PCI-to-PCI bridges (vPPBs) supported in this switch.
<b>TotalPhysicalPorts</b>	NetworkAdapter (PortAggregation)	integer	The total number of physical ports.

Property Name	Defined In Schema(s)	Type	Description
<b>TotalPrePowerOnHeatingTimeSeconds</b>	ThermalMetrics (HeaterSummary)	integer	The total number of seconds all the heaters in the thermal subsystem were active while the respective devices they heat were powered off.
<b>TotalRuntimeHeatingTimeSeconds</b>	ThermalMetrics (HeaterSummary)	integer	The total number of seconds all the heaters in the thermal subsystem were active while the respective devices they heat were powered on.
<b>TotalSupportedExtents</b>	CXLLogicalDevice	integer	The total number of extents supported on this logical device.
<b>TotalSupportedTags</b>	CXLLogicalDevice	integer	The total number of tags supported on this logical device.
<b>TotalSwitchWidth</b>	Switch	integer	The total number of lanes, phys, or other physical transport links that this switch contains.
<b>TotalSystemMemoryGiB</b>	ComputerSystem (MemorySummary)	number (GiBy)	The total configured operating system-accessible memory (RAM), measured in GiB.
<b>TotalSystemPersistentMemoryGiB</b>	ComputerSystem (MemorySummary)	number (GiBy)	The total configured, system-accessible persistent memory, measured in GiB.
<b>TotalThreads</b>	Processor	integer	The total number of execution threads that this processor supports.
<b>TotalTransactionCount</b>	ManagerDiagnosticData (I2CBuses)	integer	The total number of transactions on this I2C bus.
<b>TPM</b>	ComponentIntegrity	object	Integrity information about the Trusted Platform Module (TPM).
	TrustedComponent	object	TPM-specific information for this trusted component.
<b>TPMClear (Action)</b>	TrustedComponent (Actions)	object	This action resets all user-accessible TPM settings to factory defaults.
<b>TPMGetEventLog (Action)</b>	TrustedComponent (Actions)	object	This action retrieves the event log for TPM 2.0 devices.

Property Name	Defined In Schema(s)	Type	Description
<b>TPMGetSignedMeasurements (Action)</b>	ComponentIntegrity (Actions)	object	This action generates a TPM cryptographic signed statement over the given nonce and PCRs of the TPM for TPM 2.0 devices.
<b>Transceivers</b>	PortMetrics	array	The metrics for the transceivers in this port. Each member represents a single transceiver.
<b>TransferConfiguration</b>	PowerDistribution	object	The configuration settings for an automatic transfer switch.
<b>TransferControl (Action)</b>	PowerDistribution (Actions)	object	This action transfers control to the alternative input circuit.
<b>TransferCriteria</b>	PowerDistribution	object	The criteria used to initiate a transfer for an automatic transfer switch.
<b>TransferDelaySeconds</b>	PowerDistribution (TransferConfiguration)	integer	The time in seconds to delay the automatic transfer from the preferred mains circuit to the alternate mains circuit when the preferred mains circuit is disqualified.
<b>TransferInhibit</b>	PowerDistribution (TransferConfiguration)	boolean	Indicates if any transfer is inhibited.
<b>TransferMethod</b>	VirtualMedia (Actions > InsertMedia (Action)), VirtualMedia	string (enum)	The transfer method to use with the image.
<b>TransferProtocol</b>	LicenseService (Actions > Install (Action))	string (enum)	The network protocol that the license service uses to retrieve the license file located at the URI provided in <code>LicenseFileURI</code> . This parameter is ignored if the URI provided in <code>LicenseFileURI</code> contains a scheme.
	LogService (Actions > CollectDiagnosticData (Action)), LogService (Actions > PushDiagnosticData (Action))	string (enum)	The network protocol that the service uses to send the diagnostic data.

Property Name	Defined In Schema(s)	Type	Description
	UpdateService (Actions > SimpleUpdate (Action))	string (enum)	The network protocol that the update service uses to retrieve the software image file located at the URI specified by the <code>ImageURI</code> parameter. This parameter is ignored if the URI provided in <code>ImageURI</code> contains a scheme.
<b>TransferProtocolType</b>	VirtualMedia (Actions > InsertMedia (Action))	string (enum)	The network protocol to use with the URI specified by the <code>Image</code> parameter.
	VirtualMedia	string (enum)	The network protocol to use with the URI specified by the <code>Image</code> property.
<b>TransferSensitivity</b>	PowerDistribution (TransferCriteria)	string (enum)	The sensitivity to voltage waveform quality to satisfy the criterion for initiating a transfer.
<b>TransferSwitches</b>	Facility (Links)	array	An array of links to the transfer switches in this facility.
	PowerDomain (Links)	array	An array of links to the transfer switches in this power domain.
	PowerEquipment	object	A link to a collection of transfer switches.
<b>TransformationRatePercent</b>	Storage (StorageControllers > ControllerRates)	integer	The percentage of controller resources used for transforming volumes from one configuration to another.
	StorageController (ControllerRates)	integer (%)	The percentage of controller resources used for transforming volumes from one configuration to another.
<b>TransportProtocol</b>	Endpoint (IPTransportDetails)	string (enum)	The protocol used by the connection entity.
<b>TrapCommunity</b>	AggregationSource (SNMP), EventDestination (SNMP)	string	The SNMP trap community string.
<b>TrapPort</b>	ManagerNetworkProtocol (SNMP)	integer	The SNMP trap port.

Property Name	Defined In Schema(s)	Type	Description
<b>TreatAsWithdrawEnabled</b>	AddressPool (Ethernet > EBGp > BGPNeighbor), AddressPool (Ethernet > MultiProtocolEBGP > BGPNeighbor), AddressPool (Ethernet > MultiProtocolIBGP > BGPNeighbor)	boolean	Border Gateway Protocol (BGP) treat as withdraw status.
<b>TriggerActionEnum</b>	Triggers (TriggerActions)	string (enum)	The actions to perform when a trigger condition is met.
<b>TriggerActionMessage</b>	Triggers	string (enum)	The message issued as part of the trigger actions.
<b>TriggerActions</b>	Triggers	array	The actions that the trigger initiates.
<b>TriggerEnabled</b>	Triggers	boolean	An indication of whether the trigger is enabled.
<b>Triggers</b>	MetricReportDefinition (Links)	array	The triggers that cause this metric report definition to generate a new metric report upon a trigger occurrence when the <code>TriggerActions</code> property contains <code>RedfishMetricReport</code> .
	TelemetryService	object	The link to the collection of triggers that apply to metrics.
<b>TrustedCertificates</b>	SecurityPolicy (SPDM)	object	The trusted SPDM device certificates.
	SecurityPolicy (TLS > Client), SecurityPolicy (TLS > Server)	object	The trusted TLS server certificates.
<b>TrustedComponents</b>	ComputerSystem (Links)	array	An array of links to the trusted components for this system.
	Chassis	object	The link to the trusted components in this chassis.
<b>TrustedComponentType</b>	TrustedComponent	string (enum)	The type of trusted component, such as any physical distinction about the trusted component.
<b>TrustedModuleRequiredToBoot</b>	ComputerSystem (Boot)	string (enum)	The Trusted Module boot requirement.
<b>TrustedModules</b>	ComputerSystem	array	An array of trusted modules in the system.

Property Name	Defined In Schema(s)	Type	Description
<b>TrustedPublicHostKeys</b>	AggregationSource (SSHSettings)	object	A link to the trusted public host keys of the remote service corresponding to the aggregation source. These trusted public host keys are used for authentication of the remote service with SSH. An SSH public host key of the remote service can be added to this collection to allow for public key-based SSH authentication.
<b>TunnelingProtocol</b>	ConnectionMethod	string (enum)	The tunneling protocol used for this connection method.
<b>TurboProfile</b>	OperatingConfig	array	The turbo profiles for the processor. A turbo profile is the maximum turbo clock speed as a function of the number of active cores.
<b>TurboState</b>	Processor	string (enum)	The state of turbo for this processor.
<b>TXAvgQueueDepthPercent</b>	NetworkDeviceFunctionMetrics	number (%)	The average TX queue depth as the percentage.
<b>TXBBCredits</b>	PortMetrics (FibreChannel)	integer	The number of transmit buffer-to-buffer credits the port is configured to use.
<b>TXBBCreditZero</b>	PortMetrics (FibreChannel)	integer	The number of times the transmit buffer-to-buffer credit count transitioned to zero.
<b>TXBBCreditZeroDurationMilliseconds</b>	PortMetrics (FibreChannel)	integer (ms)	The total amount of time the port has been blocked from transmitting due to lack of buffer credits.
<b>TXBiasCurrentMilliAmps</b>	PortMetrics (Transceivers > ByLane)	number (mA)	The TX bias current value of the transceiver for the lane identified as <code>LaneId</code> .
	PortMetrics (Transceivers)	number (mA)	The TX bias current value of the transceiver, aggregated across all lanes of this port.
<b>TXBroadcastFrames</b>	PortMetrics (Networking)	integer	The total number of good broadcast frames transmitted on a port since reset.
<b>TXBytes</b>	NetworkDeviceFunctionMetrics	integer (bytes)	The total number of bytes sent on a network function.

Property Name	Defined In Schema(s)	Type	Description
	PortMetrics	integer (bytes)	The total number of bytes transmitted on a port since reset.
	NetworkAdapterMetrics	integer (bytes)	The total number of bytes transmitted since reset.
<b>TXCongestionFPINs</b>	NetworkDeviceFunctionMetrics (FibreChannel)	integer	The total number of Congestion Fabric Performance Impact Notifications (FPINs) sent.
<b>TXDeliveryFPINs</b>	NetworkDeviceFunctionMetrics (FibreChannel)	integer	The total number of Delivery Fabric Performance Impact Notifications (FPINs) sent.
<b>TXDiscards</b>	PortMetrics (Networking)	integer	The total number of frames discarded in a port's transmit path since reset.
<b>TXErrors</b>	PortMetrics	integer	The total number of transmission errors on a port since reset.
<b>TXExcessiveCollisions</b>	PortMetrics (Networking)	integer	The number of times a single transmitted frame encountered more than 15 collisions.
<b>TXExchanges</b>	NetworkDeviceFunctionMetrics (FibreChannel), PortMetrics (FibreChannel)	integer	The total number of Fibre Channel exchanges transmitted.
<b>TXFrames</b>	NetworkDeviceFunctionMetrics	integer	The total number of frames sent on a network function.
	PortMetrics (Networking)	integer	The total number of frames transmitted on a port since reset.
<b>TXLateCollisions</b>	PortMetrics (Networking)	integer	The total number of collisions that occurred after one slot time as defined by IEEE 802.3.
<b>TXLinkIntegrityFPINs</b>	NetworkDeviceFunctionMetrics (FibreChannel)	integer	The total number of Link Integrity Fabric Performance Impact Notifications (FPINs) sent.
<b>TXMulticastFrames</b>	NetworkDeviceFunctionMetrics	integer	The total number of good multicast frames transmitted on a network function since reset.
	PortMetrics (Networking)	integer	The total number of good multicast frames transmitted on a port since reset.

Property Name	Defined In Schema(s)	Type	Description
	NetworkAdapterMetrics	integer	The total number of good multicast frames transmitted since reset.
<b>TXMultipleCollisions</b>	PortMetrics (Networking)	integer	The times that a transmitted frame encountered 2-15 collisions.
<b>TXOutputPowerMilliWatts</b>	PortMetrics (Transceivers > ByLane)	number (milliwatts)	The TX output power value of the transceiver for the lane identified as <code>LaneId</code> .
	PortMetrics (Transceivers)	number (milliwatts)	The TX output power value of the transceiver, aggregated across all lanes of this port.
<b>TXPauseXOFFFrames</b>	PortMetrics (Networking)	integer	The total number of XOFF frames transmitted to the network.
<b>TXPauseXONFrames</b>	PortMetrics (Networking)	integer	The total number of XON frames transmitted to the network.
<b>TXPeerCongestionFPINs</b>	NetworkDeviceFunctionMetrics (FibreChannel)	integer	The total number of Peer Congestion Fabric Performance Impact Notifications (FPINs) sent.
<b>TXPFCFrames</b>	PortMetrics (Networking)	integer	The total number of priority flow control (PFC) frames sent on a port since reset.
<b>TXQueuesEmpty</b>	NetworkDeviceFunctionMetrics	boolean	Whether all TX queues for a network function are empty.
<b>TXQueuesFull</b>	NetworkDeviceFunctionMetrics	integer	The number of TX queues that are full.
<b>TXSequences</b>	NetworkDeviceFunctionMetrics (FibreChannel), PortMetrics (FibreChannel)	integer	The total number of Fibre Channel sequences transmitted.
<b>TXSingleCollisions</b>	PortMetrics (Networking)	integer	The times that a successfully transmitted frame encountered a single collision.
<b>TXStompedECRC</b>	PortMetrics (GenZ)	integer	The total number of packets that this interface stomped the ECRC field.
<b>TXUnicastFrames</b>	NetworkDeviceFunctionMetrics	integer	The total number of good unicast frames transmitted on a network function since reset.

Property Name	Defined In Schema(s)	Type	Description
	PortMetrics (Networking)	integer	The total number of good unicast frames transmitted on a port since reset.
	NetworkAdapterMetrics	integer	The total number of good unicast frames transmitted since reset.
<b>Type</b>	Volume (NVMeNamespaceProperties)	string (enum)	Identifies the type of namespace.
	AttributeRegistry (RegistryEntries > Attributes)	string (enum)	The attribute type.
	ContainerImage	string (enum)	The image type of this container image.
	OperatingSystem (ContainerEngines)	string (enum)	The type of container engine.
	OperatingSystem	string (enum)	The type of operating system.
	AttributeRegistry (RegistryEntries > Dependencies)	string (enum)	The type of the dependency structure.
	Port (SFP)	string (enum)	The type of transceiver that is attached to this port.
	OperatingSystem (VirtualMachineEngines)	string (enum)	The type of virtual machine engine.
<b>UALink</b>	Port	object	The UALink properties of the port.
	Processor	object	The UALink properties of the processor.
<b>UefiDevicePath</b>	EthernetInterface	string	The UEFI device path for this interface.
	AttributeRegistry (RegistryEntries > Attributes)	string	The UEFI device path that qualifies this attribute.
	SimpleStorage	string	The UEFI device path to access this storage controller.
	BootOption	string	The UEFI device path to access this UEFI boot option.
<b>UefiDevicePaths</b>	SoftwareInventory	array	The list of UEFI device paths of the components associated with this software inventory item.

Property Name	Defined In Schema(s)	Type	Description
<b>UefiKeywordName</b>	AttributeRegistry (RegistryEntries > Attributes)	string	The UEFI keyword string for this attribute.
<b>UefiNamespaceId</b>	AttributeRegistry (RegistryEntries > Attributes)	string	The UEFI namespace ID for the attribute.
<b>UefiSignatureOwner</b>	Certificate	string	The UEFI signature owner for this certificate.
	Signature	string	The UEFI signature owner for this signature.
<b>UefiTargetBootSourceOverride</b>	ComputerSystem (Boot)	string	The UEFI device path of the device from which to boot when <code>BootSourceOverrideTarget</code> is <code>UefiTarget</code> .
<b>UnassignedVolumes</b>	Storage (Links)	array	The set of volumes in this storage subsystem that are not assigned to a physical function.
<b>UnbalancedCurrentPercent</b>	Circuit	object	The current imbalance (percent) between phases.
<b>UnbalancedVoltagePercent</b>	Circuit	object	The voltage imbalance (percent) between phases.
<b>UncorrectableCoreErrorCount</b>	ProcessorMetrics (CoreMetrics), ProcessorMetrics	integer	The number of uncorrectable core errors.
<b>UncorrectableECCError</b>	MemoryMetrics (HealthData > AlarmTrips)	boolean	An indication of whether the uncorrectable error threshold alarm trip was detected.
	MemoryMetrics (CXL > AlertCapabilities)	boolean	Indicates whether uncorrectable ECC errors generate an alert to the CXL Fabric Manager or host.
<b>UncorrectableECCErrorCount</b>	ProcessorMetrics (CacheMetricsTotal > LifeTime)	integer	The number of uncorrectable errors for the lifetime of the cache memory.
	StorageControllerMetrics	integer	The number of uncorrectable errors for the lifetime of the memory of the storage controller.
	MemoryMetrics (LifeTime), SwitchMetrics (InternalMemoryMetrics > LifeTime)	integer	The number of uncorrectable errors for the lifetime of the memory.

Property Name	Defined In Schema(s)	Type	Description
	ProcessorMetrics (CacheMetricsTotal > CurrentPeriod)	integer	The number of uncorrectable errors of cache memory since reset or <code>ClearCurrentPeriod</code> action for this processor.
	SwitchMetrics (InternalMemoryMetrics > CurrentPeriod)	integer	The number of uncorrectable errors of memory since reset.
	ManagerDiagnosticData (MemoryECCStatistics), MemoryMetrics (CurrentPeriod)	integer	The number of uncorrectable errors since reset.
<b>UncorrectableFECErrors</b>	PortMetrics (FibreChannel)	integer	The total number of uncorrectable forward error correction (FEC) errors.
<b>UncorrectableIOReadErrorCount</b>	DriveMetrics	integer	The number of uncorrectable read errors for the lifetime of the drive.
<b>UncorrectableIOWriteErrorCount</b>	DriveMetrics	integer	The number of uncorrectable write errors for the lifetime of the drive.
<b>UncorrectableOtherErrorCount</b>	ProcessorMetrics (CoreMetrics), ProcessorMetrics	integer	The number of uncorrectable errors of all other components.
<b>UncorrectableParityErrorCount</b>	StorageControllerMetrics	integer	The number of uncorrectable parity errors for the lifetime of the memory of the storage controller.
<b>UnderlayMulticastEnabled</b>	AddressPool (Ethernet > BGPEvpn)	boolean	Underlay multicast status.
<b>UnderNominalFrequencyHz</b>	PowerDistribution (TransferCriteria)	number (Hz)	The frequency in hertz units under the nominal value that satisfies a criterion for transfer.
<b>UnderVoltageRMSPercentage</b>	PowerDistribution (TransferCriteria)	number (%)	The negative percentage of voltage RMS under the nominal value that satisfies a criterion for transfer.
<b>UnfreezeAuthenticationModes</b>	Drive (NVMe > ActivePersonalities), Storage (NVMeSubsystemProperties > ActivePersonalities)	array	The authentication modes supported to unfreeze this personality.
<b>UnfreezePersonality (Action)</b>	Drive (Actions), Storage (Actions)	object	This action unfreezes a personality for the NVMe subsystem.
<b>UnhaltedCycles</b>	ProcessorMetrics (CoreMetrics)	number	The unhalted cycles count of this core.

Property Name	Defined In Schema(s)	Type	Description
<b>Units</b>	MetricDefinition	string	The units of measure for this metric.
<b>UnknownUnicastSuppressionEnabled</b>	AddressPool (Ethernet > BGPEvpn)	boolean	Suppression of unknown unicast packets.
<b>Unlock (Action)</b>	CXLLogicalDevice (Actions)	object	Unlocks the CXL logical device.
<b>UnlockUnit (Action)</b>	Memory (Actions)	object	This contains the action for unlocking given regions.
<b>UnsafeShutdowns</b>	StorageControllerMetrics (NVMeSMART)	integer	The number of unsafe shutdowns.
<b>UnstructuredName</b>	CertificateEnrollment (CSRParameters), CertificateService (Actions > GenerateCSR (Action))	string	The unstructured name of the subject.
<b>Updateable</b>	SoftwareInventory	boolean	An indication of whether the update service can update this software.
<b>UpdateSecurityMode (Action)</b>	Manager (Actions)	object	The update security mode action updates the security mode for the manager. This can cause the manager to reset and reset other settings to factory defaults. Services might require the <code>ResetToDefaults</code> action to clear the security mode.
<b>UpdateService</b>	ServiceRoot	object	The link to the update service.
<b>UpdateServiceCapabilities</b>	UpdateService	object	A link to the capabilities of the update service.
<b>UPLIWatchdogTimerMicroseconds</b>	Port (UALink)	integer (us)	The time limit, in microseconds, for the UPLI (UALink Protocol Level Interface) watchdog for the port.
<b>Upper</b>	AddressPool (Ethernet > EBGp > ASNumberRange), AddressPool (Ethernet > MultiProtocolEBGP > ASNumberRange), AddressPool (Ethernet > MultiProtocolIBGP > ASNumberRange)	integer	Upper Autonomous System (AS) number.
	AddressPool (Ethernet > BGPEvpn > ESINumberRange)	integer	Upper Ethernet Segment Identifier (ESI) number.

Property Name	Defined In Schema(s)	Type	Description
	AddressPool (Ethernet > BGPEvpn > EVINumberRange)	integer	Upper Ethernet Virtual Private Network (EVPN) Instance (EVI) number.
	AddressPool (Ethernet > BGPEvpn > RouteDistinguisherRange)	integer	Upper Route Distinguisher (RD) number.
	AddressPool (Ethernet > BGPEvpn > RouteTargetRange)	integer	Upper Route Target (RT) number.
	AddressPool (Ethernet > BGPEvpn > VLANIdentifierAddressRange), AddressPool (Ethernet > IPv4 > VLANIdentifierAddressRange)	integer	Virtual LAN (VLAN) tag upper value.
	AddressPool (Ethernet > BGPEvpn > GatewayIPAddressRange)	string	The upper IPv4 address.
	AddressPool (Ethernet > IPv4 > SystemMACRange)	string	The upper system MAC address.
	AddressPool (Ethernet > IPv4 > EBGPAAddressRange), AddressPool (Ethernet > IPv4 > FabricLinkAddressRange), AddressPool (Ethernet > IPv4 > HostAddressRange), AddressPool (Ethernet > IPv4 > IBGPAAddressRange), AddressPool (Ethernet > IPv4 > LoopbackAddressRange), AddressPool (Ethernet > IPv4 > ManagementAddressRange)	string	Upper IPv4 network address.
<b>UpperBound</b>	AttributeRegistry (RegistryEntries > Attributes)	integer	The upper limit for an integer attribute.
<b>UpperCaution</b>	Sensor (Thresholds)	object	The value at which the reading is above normal range.
<b>UpperCautionUser</b>	Sensor (Thresholds)	object	A user-defined value at which the reading is considered above normal range.
<b>UpperCritical</b>	Triggers (NumericThresholds)	object	The value at which the reading is above normal range and requires attention.

Property Name	Defined In Schema(s)	Type	Description
	Sensor (Thresholds)	object	The value at which the reading is above normal range but not yet fatal.
<b>UpperCriticalUser</b>	Sensor (Thresholds)	object	A user-defined value at which the reading is considered above normal range but not yet fatal.
<b>UpperFatal</b>	Sensor (Thresholds)	object	The value at which the reading is above normal range and fatal.
<b>UpperThresholdCritical</b>	Thermal (Fans)	integer	The value at which the reading is above normal range but not yet fatal.
	Thermal (Temperatures)	number (Celsius)	The value at which the reading is above normal range but not yet fatal.
	Power (Voltages)	number (volts)	The value at which the reading is above normal range but not yet fatal.
<b>UpperThresholdFatal</b>	Thermal (Fans)	integer	The value at which the reading is above normal range and fatal.
	Thermal (Temperatures)	number (Celsius)	The value at which the reading is above normal range and fatal.
	Power (Voltages)	number (volts)	The value at which the reading is above normal range and fatal.
<b>UpperThresholdNonCritical</b>	Thermal (Fans)	integer	The value at which the reading is above normal range.
	Thermal (Temperatures)	number (Celsius)	The value at which the reading is above normal range.
	Power (Voltages)	number (volts)	The value at which the reading is above normal range.
<b>UpperThresholdUser</b>	Thermal (Temperatures)	integer (Celsius)	The value at which the reading is above the user-defined range.
<b>UpperWarning</b>	Triggers (NumericThresholds)	object	The value at which the reading is above normal range.
<b>UpstreamChassis</b>	Cable (Links)	array	An array of links to the upstream chassis connected to this cable.

Property Name	Defined In Schema(s)	Type	Description
<b>UpstreamConnectorTypes</b>	Cable	array	The connector types this cable supports.
<b>UpstreamName</b>	Cable	string	The identifier for the downstream resource.
<b>UpstreamPorts</b>	Cable (Links)	array	An array of links to the upstream ports connected to this cable.
<b>UpstreamResources</b>	Cable (Links)	array	An array of links to the upstream resources connected to this cable.
<b>UptimeSeconds</b>	OperatingSystem	integer	The wall-clock time this operating system has been running in seconds.
	ManagerDiagnosticData (TopProcesses)	number	The wall-clock time this process has been running in seconds.
<b>Uri</b>	JsonSchemaFile (Location)	string	The link to locally available URI for schema.
	MessageRegistryFile (Location)	string	The link to locally available URI for the registry.
<b>USBControllers</b>	ComputerSystem	object	The link to a collection of USB controllers for this system.
<b>USBPorts</b>	Manager	object	The USB ports of the manager.
<b>UseCases</b>	ComputerSystem (Composition)	array	The composition use cases in which this computer system can participate.
<b>UsedBytes</b>	ManagerDiagnosticData (MemoryStatistics)	integer (bytes)	The amount of used memory in bytes.
<b>UseDNSServers</b>	EthernetInterface (DHCPv6)	boolean	An indication of whether the interface uses DHCP v6-supplied DNS servers.
	EthernetInterface (DHCPv4)	boolean	An indication of whether this interface uses DHCP v4-supplied DNS servers.
<b>UseDomainName</b>	EthernetInterface (DHCPv4)	boolean	An indication of whether this interface uses a DHCP v4-supplied domain name.

Property Name	Defined In Schema(s)	Type	Description
	EthernetInterface (DHCPv6)	boolean	An indication of whether this interface uses a DHCP v6-supplied domain name.
<b>UseGateway</b>	EthernetInterface (DHCPv4)	boolean	An indication of whether this interface uses a DHCP v4-supplied gateway.
<b>UseMultiplePathsEnabled</b>	AddressPool (Ethernet > EBGp > MultiplePaths), AddressPool (Ethernet > MultiProtocolEBGP > MultiplePaths), AddressPool (Ethernet > MultiProtocolIBGP > MultiplePaths)	boolean	Border Gateway Protocol (BGP) multiple paths status.
<b>UseNTPServers</b>	EthernetInterface (DHCPv4)	boolean	An indication of whether the interface uses DHCP v4-supplied NTP servers.
	EthernetInterface (DHCPv6)	boolean	An indication of whether the interface uses DHCP v6-supplied NTP servers.
<b>UseRapidCommit</b>	EthernetInterface (DHCPv6)	boolean	An indication of whether the interface uses DHCP v6 rapid commit mode for stateful mode address assignments. Do not enable this option in networks where more than one DHCP v6 server is configured to provide address assignments.
<b>UserAuthenticationMethod</b>	AggregationSource (SSHSettings)	string (enum)	The client user authentication method.
<b>UserAuthenticationSource</b>	Event (Events)	string	The source of authentication for the username property associated with the event record.
	LogEntry	string	The source of authentication for the username property associated with the log entry.
<b>UserDescription</b>	Key	string	A user-defined string to describe this key.
	Cable	string	The description of this cable.
<b>UserLabel</b>	<i>various</i> (Cable, Chassis (Doors > Front) ... )	string	A user-assigned label.

Property Name	Defined In Schema(s)	Type	Description
<b>Username</b>	EventService (SMTP)	string	The username for authentication with the SMTP server.
	ManagerNetworkProtocol (Proxy)	string	The username for the proxy.
	AccountService (ActiveDirectory > Authentication), AccountService (LDAP > Authentication), AccountService (OAuth2 > Authentication), AccountService (TACACSPplus > Authentication), ExternalAccountProvider (Authentication)	string	The username for the service.
	Event (Events)	string	The username of the account associated with the event record.
	LogEntry	string	The username of the account associated with the log entry.
	ComputerSystem (KeyManagement > KMIPServers)	string	The username to access the KMIP server.
<b>UserName</b>	UpdateService (Actions > SimpleUpdate (Action))	string	The username to access the URI specified by the <code>ImageURI</code> parameter.
	LicenseService (Actions > Install (Action))	string	The username to access the URI specified by the <code>LicenseFileURI</code> parameter.
	AggregationSource	string	The username for accessing the aggregation source.
	Session	string	The username for the account for this session.
	ManagerAccount	string	The username for the account.
	VirtualMedia (Actions > InsertMedia (Action))	string	The username to access the URI specified by the <code>Image</code> parameter.
	VirtualMedia	string	The username to access the URI specified by the <code>Image</code> property.
	LogService (Actions > CollectDiagnosticData (Action)), LogService (Actions > PushDiagnosticData (Action))	string	The username to access the URI specified by the <code>TargetURI</code> parameter.

Property Name	Defined In Schema(s)	Type	Description
<b>UsernameAttribute</b>	AccountService (ActiveDirectory > LDAPService > SearchSettings), AccountService (LDAP > LDAPService > SearchSettings), AccountService (OAuth2 > LDAPService > SearchSettings), AccountService (TACACsPlus > LDAPService > SearchSettings), ExternalAccountProvider (LDAPService > SearchSettings)	string	The attribute name that contains the LDAP username entry.
<b>UserPassphraseAttemptCountReached</b>	Memory (SecurityStates)	boolean	An indication of whether an incorrect user passphrase attempt count has been reached.
<b>UserPercent</b>	ManagerDiagnosticData (ProcessorStatistics)	number (%)	The percentage of CPU time spent in user mode.
	ProcessorMetrics	number (%)	The percentage of time spent in user mode.
<b>UserSpaceTimeSeconds</b>	ManagerDiagnosticData (BootTimeStatistics)	number	The number of seconds the manager spent in the user space boot stage.
<b>UserSpecifiedJobs</b>	JobService (ServiceCapabilities)	boolean	An indication of whether user-specified jobs are supported.
<b>UserTimeSeconds</b>	ManagerDiagnosticData (TopProcesses)	number	The number of seconds this process executed in user space.
<b>UseStaticRoutes</b>	EthernetInterface (DHCPv4)	boolean	An indication of whether the interface uses DHCP v4-supplied static routes.
<b>UUID</b>	AccelerationFunction	string	The UUID for this acceleration function.
	Chassis	string	The UUID for this chassis.
	PowerDistribution	string	The UUID for this equipment.
	FabricAdapter	string	The UUID for this fabric adapter.
	Fabric	string	The UUID for this fabric.
	Manager	string	The UUID for this manager.
	MediaController	string	The UUID for this media controller.
	PCleDevice	string	The UUID for this PCIe device.

Property Name	Defined In Schema(s)	Type	Description
	Processor	string	The UUID for this processor.
	Processor (FPGA > ReconfigurationSlots)	string	The UUID for this reconfiguration slot.
	Switch	string	The UUID for this switch.
	ComputerSystem	string	The UUID for this system.
	TrustedComponent	string	The UUID for this trusted component.
	ServiceRoot	string	Unique identifier for a service instance. When SSDP is used, this value contains the same UUID returned in an HTTP 200 OK response from an SSDP M-SEARCH request during discovery.
<b>Valid</b>	RouteSetEntry	boolean	An indication of whether the entry is valid.
<b>Validate (Action)</b>	Job (Actions)	object	Validates the job.
<b>ValidatedExecutors</b>	Job (Links)	array	An array of links to the executors that have been validated to run this job.
<b>ValidationPolicy</b>	JobService	string (enum)	The policy for how document-based jobs are validated.
<b>ValidNotAfter</b>	Certificate	string	The date when the certificate is no longer valid.
<b>ValidNotBefore</b>	Certificate	string	The date when the certificate becomes valid.
<b>Value</b>	AttributeRegistry (RegistryEntries > Attributes)	array	An array of the possible values for enumerated attribute values.
	Triggers (DiscreteTriggers)	string	The discrete metric value that constitutes a trigger event.
<b>ValueDisplayName</b>	AttributeRegistry (RegistryEntries > Attributes > Value)	string	A user-readable display string of the value for the attribute in the defined language.

Property Name	Defined In Schema(s)	Type	Description
<b>ValueExpression</b>	AttributeRegistry (RegistryEntries > Attributes)	string	A valid regular expression, according to the Perl regular expression dialect, that validates the attribute value. Applies to only string and integer attributes.
<b>ValueHint</b>	JobDocument (ParameterMetadata)	string	A hint value for the parameter.
<b>ValueName</b>	AttributeRegistry (RegistryEntries > Attributes > Value)	string	The unique value name for the attribute.
<b>Values</b>	MetricDefinition (Wildcards), MetricReportDefinition (Wildcards)	array	An array of values to substitute for the wildcard. * indicates all possible values for the wildcard.
	Triggers (Wildcards)	array	An array of values to substitute for the wildcard. A single value of * matches all resources.
<b>ValveControl (Action)</b>	CoolantConnector (Actions)	object	This action sets the state of the connector.
<b>ValvePositionControlPercent</b>	CoolantConnector	object	The desired valve position (% open).
<b>ValvePositionPercent</b>	CoolantConnector	object	The valve position (% open) of this connector.
<b>ValveState</b>	CoolantConnector (Actions > ValveControl (Action))	string (enum)	The desired state of the connector.
<b>ValveStateReason</b>	CoolantConnector (Actions > ValveControl (Action))	string (enum)	The reason for the desired state of the connector.
<b>VCAction</b>	RouteSetEntry	integer	The Virtual Channel Action index.
<b>VCAT</b>	Port (GenZ)	object	The Virtual Channel Action Table for the port.
<b>VCEntries</b>	VCATEntry	array	An array of entries of the Virtual Channel Action Table.
<b>VCMask</b>	VCATEntry (VCEntries)	string	The bits corresponding to the supported Virtual Channel.
<b>VCS</b>	Switch (CXL)	object	Virtual CXL Switch (VCS) properties for this switch.
<b>VcsID</b>	Switch (CXL > PIDTargetList)	integer	The virtual CXL switch identifier of the target port.

Property Name	Defined In Schema(s)	Type	Description
<b>VCSId</b>	VirtualCXLSwitch	string	The Virtual CXL Switch identifier.
<b>VelocitySensor</b>	AutomationNode (Links)	object	A link to the velocity sensor.
<b>Vendor</b>	Cable	string	The manufacturer of this cable.
	Assembly (Assemblies)	string	The vendor of the assembly.
	Application	string	The vendor of this application.
<b>VendorId</b>	ServiceRoot	string	The vendor or manufacturer associated with this Redfish service.
	Endpoint (ConnectedEntities > EntityPcild), Endpoint (Pcild), PCIeFunction	string	The Vendor ID of this PCIe function.
	NetworkPort	string	The vendor Identification for this port.
	Processor (ProcessorId)	string	The vendor identification for this processor.
<b>VendorID</b>	Memory	string	Vendor ID.
<b>VendorOUI</b>	Port (SFP)	string	The IEEE OUI of the vendor of this SFP.
<b>VerificationStatus</b>	ComponentIntegrity (SPDM > IdentityAuthentication > ResponderAuthentication), ComponentIntegrity (TPM > IdentityAuthentication)	string (enum)	The status of the verification of the identity of the component.
<b>VerifyCertificate</b>	SecurityPolicy (TLS > Client), SecurityPolicy (TLS > Server)	boolean	An indication of whether the manager will verify the certificate of the remote TLS endpoint.
	SecurityPolicy (SPDM)	boolean	An indication of whether the manager will verify the certificate of the SPDM endpoint.
	EventDestination	boolean	An indication of whether the service will verify the certificate of the server referenced by the <code>Destination</code> property prior to sending the event.

Property Name	Defined In Schema(s)	Type	Description
	VirtualMedia	boolean	An indication of whether the service will verify the certificate of the server referenced by the <code>Image</code> property prior to completing the remote media connection.
	CertificateEnrollment	boolean	An indication of whether the service will verify the certificate of the server referenced by the <code>ServerURI</code> property.
<b>VerifyRemoteServerCertificate</b>	UpdateService	boolean	An indication of whether the service will verify the certificate of the server referenced by the <code>ImageURI</code> parameter in <code>SimpleUpdate</code> prior to sending the transfer request.
<b>VerifyRemoteServerSSHKey</b>	UpdateService	boolean	An indication of whether the service will verify the SSH key of the server referenced by the <code>ImageURI</code> parameter in <code>SimpleUpdate</code> prior to sending the transfer request.
<b>VerifyTimeBasedOneTimePassword (Action)</b>	ManagerAccount (Actions)	object	This action verifies a user-provided Time-based One-Time Password (TOTP). This is to ensure the client's copy of the secret key is aligned with the secret key stored by the service.
<b>Version</b>	AccelerationFunction	string	The acceleration function version.
	Assembly (Assemblies)	string	The hardware version of the assembly.
	Processor	string	The hardware version of the processor.
	Battery	string	The hardware version of this battery.
	Chassis	string	The hardware version of this chassis.
	CoolingUnit, PowerDistribution, Pump	string	The hardware version of this equipment.
	Manager	string	The hardware version of this manager.

Property Name	Defined In Schema(s)	Type	Description
	PowerSupply	string	The hardware version of this power supply.
	Port (SFP)	string	The hardware version of this SFP.
	OperatingSystem (Kernel)	string	The version of the kernel.
	Application, ContainerImage	string	The version of this application.
	OperatingSystem (ContainerEngines)	string	The version of this container engine.
	JobDocument	string	The version of this job document.
	SoftwareInventory	string	The version of this software.
	OperatingSystem (VirtualMachineEngines)	string	The version of this virtual machine engine.
<b>Versions</b>	SecurityPolicy (SPDM > Allowed), SecurityPolicy (SPDM > Denied)	array	The SPDM versions.
	SecurityPolicy (TLS > Client > Allowed), SecurityPolicy (TLS > Client > Denied), SecurityPolicy (TLS > Server > Allowed), SecurityPolicy (TLS > Server > Denied)	array	The TLS versions.
<b>VersionScheme</b>	SoftwareInventory	string (enum)	The format of the version.
<b>VirtualCXLSwitches</b>	Switch (CXL)	object	The link to the collection of Virtual CXL Switches (VCS) for this CXL switch.
<b>VirtualFunction</b>	NetworkAdapter (Controllers > ControllerCapabilities > VirtualizationOffload)	object	The virtual function of the controller.
<b>VirtualFunctionAllocation</b>	NetworkDeviceFunction	integer	The number of virtual functions allocated to this device.
<b>VirtualFunctionsEnabled</b>	NetworkDeviceFunction	boolean	An indication of whether single root input/output virtualization (SR-IOV) virtual functions are enabled for this network device function.
<b>Virtualization</b>	ComputerSystem	object	The information about the virtualization abilities of this system.

Property Name	Defined In Schema(s)	Type	Description
<b>VirtualizationOffload</b>	NetworkAdapter (Controllers > ControllerCapabilities)	object	Virtualization offload for this controller.
<b>VirtualMachineEngines</b>	OperatingSystem	array	The virtual machine engines running in this operating system.
<b>VirtualMachines</b>	ComputerSystem (Links)	array	An array of links to the virtual machines this system is hosting.
<b>VirtualMedia</b>	Manager	object	The link to the virtual media services for this particular manager.
	ComputerSystem	object	The link to the virtual media services for this system.
	ManagerNetworkProtocol	object	The settings for this manager's virtual media support that apply to all system instances controlled by this manager.
<b>VirtualMediaConfig</b>	ComputerSystem	object	The information about the virtual media service of this system.
<b>VLAN</b>	EthernetInterface	object	If this network interface supports more than one VLAN, this property is absent. VLAN collections appear in the <code>Links</code> property of this resource.
	NetworkDeviceFunction (Ethernet)	object	The VLAN information for this interface. If this network interface supports more than one VLAN, this property is not present.
<b>VLANEnable</b>	VlanNetworkInterface	boolean	An indication of whether this VLAN is enabled for this interface.
<b>VLANId</b>	VlanNetworkInterface	integer	The ID for this VLAN.
<b>VLANIdentifierAddressRange</b>	AddressPool (Ethernet > BGPEvpn)	object	Virtual LAN (VLAN) tag related address range applicable to this Ethernet fabric or for end-host subnets.
	AddressPool (Ethernet > IPv4)	object	Virtual LAN (VLAN) tag related addressing for this Ethernet fabric or for end-host networks.
<b>VLANPriority</b>	VlanNetworkInterface	integer	The priority for this VLAN.

Property Name	Defined In Schema(s)	Type	Description
<b>VLANs</b>	EthernetInterface	object	The link to a collection of VLANs, which applies only if the interface supports more than one VLAN. If this property applies, the <code>VLANEnabled</code> and <code>VLANId</code> properties do not apply.
	NetworkDeviceFunction (Ethernet)	object	The link to a collection of VLANs. This property is used only if the interface supports more than one VLAN.
<b>VolatileRegionNumberLimit</b>	Memory	integer	Total number of volatile regions this memory device can support.
<b>VolatileRegionSizeLimitMiB</b>	Memory	integer (mebibytes)	Total size of volatile regions in mebibytes (MiB).
<b>VolatileRegionSizeMaxMiB</b>	Memory	integer (mebibytes)	Maximum size of a single volatile region in mebibytes (MiB).
<b>VolatileSizeLimitMiB</b>	Memory	integer (mebibytes)	The total volatile memory capacity in mebibytes (MiB).
<b>VolatileSizeMiB</b>	Memory	integer (mebibytes)	Total size of the volatile portion memory in MiB.
<b>Voltage</b>	Circuit	object	The voltage (V) for this circuit.
	EnvironmentMetrics	object	The voltage (V) for this device.
	AutomationInstrumentation	object	The voltage (V) for this node.
	Outlet	object	The voltage (V) for this outlet.
	LeakDetector	object	The voltage (V) measurement for this leak detector.
<b>VoltageControl</b>	PowerSupply (OutputRails)	object	The desired output voltage (V).
<b>Voltages</b>	Power	array	The set of voltage sensors for this chassis.
<b>VoltageType</b>	Circuit	string (enum)	The type of voltage applied to the circuit.
	Outlet	string (enum)	The type of voltage applied to the outlet.
	Sensor	string (enum)	The voltage type for this sensor.

Property Name	Defined In Schema(s)	Type	Description
<b>VoltageVolts</b>	PortMetrics (PoE)	number (volts)	The current voltage on this port.
<b>Volume</b>	Connection (VolumeInfo), StorageController (NVMeControllerProperties > ANACCharacteristics)	object	The specified volume.
	Connection (Actions > AddVolumeInfo (Action))	object	The volume to add.
	Connection (Actions > RemoveVolumeInfo (Action))	object	The volume to remove.
<b>VolumeAssignmentPolicy</b>	Storage (MPF)	string (enum)	The current volume assignment policy configured for the storage controller in this storage subsystem.
<b>VolumeInfo</b>	Connection	array	The set of volumes and access capabilities specified for this connection.
<b>VolumeName</b>	Volume (Actions > CreateReplicaTarget (Action))	string	The Name for the new target volume.
<b>Volumes</b>	Drive (Links)	array	An array of links to the volumes that this drive either wholly or only partially contains.
	Storage	object	The set of volumes that the storage controllers produce.
<b>VolumeType</b>	Volume	string (enum)	The type of this volume.
<b>VolumeUsage</b>	Volume	string (enum)	Indicates the Volume usage type setting for the Volume.
<b>VPDWrite</b>	Drive (NVMe > ConfigurationLockState), Storage (NVMeSubsystemProperties > ConfigurationLockState)	string (enum)	The lock state of the NVMe-MI-defined VPD Write command.
<b>VPPBId</b>	VirtualPCI2PCIBridge	string	The Virtual PCI-PCI Bridge identifier.
<b>VPPBs</b>	VirtualCXLSwitch	object	The link to the collection of vPPBs (Virtual PCI-to-PCI Bridges) for this Virtual CXL Switch.

Property Name	Defined In Schema(s)	Type	Description
<b>Wait (Action)</b>	AutomationNode (Actions)	object	Signals the node to wait for the next instruction.
<b>WakeOnLANEnabled</b>	NetworkPort	boolean	An indication of whether Wake on LAN (WoL) is enabled for this network port.
	Port (Ethernet)	boolean	Indicates whether Wake on LAN (WoL) is enabled on this port.
<b>WarningAction</b>	ComputerSystem (HostWatchdogTimer)	string (enum)	The action to perform when the watchdog timer is close to reaching its timeout value. This action typically occurs from three to ten seconds before to the timeout value, but the exact timing is dependent on the implementation.
<b>WarningCompositeTempTimeMinutes</b>	StorageControllerMetrics (NVMeSMART)	integer	The amount of time in minutes that the controller has been operational and that the composite temperature has been greater than or equal to the warning composite temperature threshold.
<b>WarningReactionType</b>	LeakDetector	string (enum)	The reaction to perform when a warning-level leak is detected.
<b>WarningText</b>	AttributeRegistry (RegistryEntries > Attributes)	string	The warning text for the attribute.
<b>WavelengthNanometers</b>	PortMetrics (Transceivers)	string (nm)	The laser wavelength, in nanometers, for the transceiver.
<b>WebSocket</b>	ComputerSystem (SerialConsole)	object	The connection details for a WebSocket serial console service.
<b>WebSocketPingIntervalMinutes</b>	OutboundConnection	integer	Interval for sending the WebSocket ping opcode in minutes. The value 0 indicates the ping opcode is not sent.
<b>WeightKg</b>	Chassis	number (kg)	The weight of the chassis.
<b>Width</b>	Port	integer	The number of lanes, phys, or other physical transport links that this port contains.

Property Name	Defined In Schema(s)	Type	Description
<b>WidthMm</b>	Chassis	number (mm)	The width of the chassis.
<b>Wildcards</b>	MetricReportDefinition	array	The set of wildcards and their substitution values for the entries in the <code>MetricProperties</code> property.
	MetricDefinition, Triggers	array	The wildcards and their substitution values for the entries in the <code>MetricProperties</code> array property.
<b>WriteCacheEnabled</b>	Drive	boolean	An indication of whether the drive write cache is enabled.
<b>WriteCachePolicy</b>	Volume	string (enum)	Indicates the write cache policy setting for the Volume.
<b>WriteCacheState</b>	Volume	string (enum)	Indicates the WriteCacheState policy setting for the Volume.
<b>WriteHoleProtectionPolicy</b>	Volume	string (enum)	The policy that the RAID volume is using to address the write hole issue.
<b>WriteOKiBytes</b>	DriveMetrics	integer (KiBy)	The number of kibibytes written.
<b>WriteOnly</b>	AttributeRegistry (RegistryEntries > Attributes)	boolean	An indication of whether this attribute is write-only. A write-only attribute reverts to its initial value after settings are applied.
<b>WriteProtected</b>	VirtualMedia	boolean	An indication of whether the media is write-protected.
	VirtualMedia (Actions > InsertMedia (Action))	boolean	An indication of whether the remote media is treated as write-protected. The default is <code>true</code> .
	SoftwareInventory	boolean	Indicates if the software is write-protected.
<b>WWNN</b>	NetworkDeviceFunction (FibreChannel)	string	The currently configured World Wide Node Name (WWNN) address of this function.

Property Name	Defined In Schema(s)	Type	Description
<b>WWNSource</b>	NetworkDeviceFunction (FibreChannel)	string (enum)	The configuration source of the World Wide Names (WWN) for this World Wide Node Name (WWNN) and World Wide Port Name (WWPN) connection.
<b>WWPN</b>	NetworkDeviceFunction (FibreChannel)	string	The currently configured World Wide Port Name (WWPN) address of this function.
	NetworkDeviceFunction (FibreChannel > BootTargets)	string	The World Wide Port Name (WWPN) from which to boot.
<b>ZoneETag</b>	Zone (Actions > AddEndpoint (Action)), Zone (Actions > RemoveEndpoint (Action))	string	The current ETag of the zone.
<b>Zones</b>	ResourceBlock (Links)	array	An array of links to the zones in which this resource block is bound.
	AddressPool (Links)	array	An array of links to the zones that this address pool contains.
	Endpoint (Links)	array	The zones to which this endpoint belongs.
	Fabric	object	The collection of links to the zones that this fabric contains.
<b>ZoneType</b>	Zone	string (enum)	The type of zone.

## 4 Redfish documentation generator

---

This document was created using the Redfish Documentation Generator utility, which uses the contents of the Redfish schema files (in JSON schema format) to automatically generate the bulk of the text. The source code for the utility is available for download at DMTF's GitHub repository located at <https://www.github.com/DMTF/Redfish-Tools>.

## 5 ANNEX A (informative) Change log

Version	Date	Description
2026.1	2026-04-02	Document built from Redfish Schemas in DSP8010 release 2026.1.
2025.4	2025-12-04	Document built from Redfish Schemas in DSP8010 release 2025.4.
2025.3	2025-09-04	Document built from Redfish Schemas in DSP8010 release 2025.3.
2025.2	2025-05-01	Document built from Redfish Schemas in DSP8010 release 2025.2.
2025.1	2025-02-05	Document built from Redfish Schemas in DSP8010 release 2025.1.
2024.4	2024-11-27	Document built from Redfish Schemas in DSP8010 release 2024.4.
2024.3	2024-08-01	Document built from Redfish Schemas in DSP8010 release 2024.3.
2024.2	2024-06-06	Document built from Redfish Schemas in DSP8010 release 2024.2.
2024.1	2024-04-04	Document built from Redfish Schemas in DSP8010 release 2024.1.
2023.3	2023-11-30	Document built from Redfish Schemas in DSP8010 release 2023.3.
2023.2	2023-08-11	Document built from Redfish Schemas in DSP8010 release 2023.2.
2023.1	2023-04-06	Document built from Redfish Schemas in DSP8010 release 2023.1.
2022.3	2022-12-08	Document built from Redfish Schemas in DSP8010 release 2022.3.
2022.2	2022-08-04	Document built from Redfish Schemas in DSP8010 release 2022.2.
2022.1	2022-04-15	Document built from Redfish Schemas in DSP8010 release 2022.1.
2021.4	2021-12-02	Document built from Redfish Schemas in DSP8010 release 2021.4.
2021.3	2021-10-15	Document built from Redfish Schemas in DSP8010 release 2021.3.
2021.2	2021-08-13	Document built from Redfish Schemas in DSP8010 release 2021.2.
2021.1	2021-04-16	Document built from Redfish Schemas in DSP8010 release 2021.1.
		Document formatting updated for Documentation Generator v3.
2020.4	2020-12-01	Document built from Redfish Schemas in DSP8010 release 2020.4.
2020.3	2020-08-14	Document built from Redfish Schemas in DSP8010 release 2020.3.
2020.2	2020-05-08	Document built from Redfish Schemas in DSP8010 release 2020.2.
2020.1	2020-03-27	Document built from Redfish Schemas in DSP8010 release 2020.1.
2019.4	2019-12-06	Document built from Redfish Schemas in DSP8010 release 2019.4.

Version	Date	Description
2019.3	2019-10-11	Document built from Redfish Schemas in DSP8010 release 2019.3.
2019.2	2019-09-13	Document built from Redfish Schemas in DSP8010 release 2019.2. Editorial corrections.
2019.1	2019-05-03	Document built from Redfish Schemas in DSP8010 release 2019.1.
2018.3	2019-01-15	Initial release. Document built from Redfish Schemas in DSP8010 release 2018.3.